Full download: http://manualplace.com/download/grove-pat-load-moment-indicator-iflex5-operator-manual/



OPERATOR'S MANUAL

P/N 031-300-190-147 REV E- 11/12/2008

NOTICE

PAT America, Inc. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and/or its fitness for a particular purpose.

PAT America, Inc. will not be liable for errors contained in this manual or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual. This document contains proprietary information, which is protected by copyright, and all rights are reserved.

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of PAT America, Inc.

PAT America, Inc. reserves proprietary rights to all drawings, photos and the data contained therein. The drawings, photos and data are confidential and cannot be used or reproduced without the written consent of PAT America, Inc. The drawings and/or photos are subject to technical modification without prior notice.

All information in this document is subject to change without notice.

MANUAL REVISIONS

REV	DATE	NAME	DESCRIPTION
-	2/22/02	MO	ECN 02-64
Α	11/11/02	CH	ECN 02-278
В	05/19/03	SB	ECN 03-065
С	02/22/05	MS	ECN 05-041
D	01/06/06	SB	ECN 05-217
Е	11/12/08	WG	ECN 08-179

© 2006 Hirschmann, Chambersburg, PA 17201, USA

