

Hitachi Ex300 1 Spare Parts

Full download: <http://manualplace.com/download/hitachi-ex300-1-spare-parts/>

Hitachi EX300-1

BUCKET

BUCKET PINS

BUCKET LINKAGES

BUCKET LINKAGES

DIPPER STICK

BOOM

BUCKET CYLINDER

DIPPER STICK CYLINDER

BOOM LIFT CYLINDER

CAB

SEAT

INSTRUMENT PANEL

RELAYS

COMPUTER

WIRING LOOM

HAND SERVO CONTROLS

HEATER A/C

BONNET

DOORS

FUEL TANK

HYDRAULIC TANK

BELLY PLATES

DIESEL ENGINE

RADIATOR

HYDRAULIC OIL COOLER

HYDRAULIC PUMPS

HYD PUMP DRIVE GEARBOX

SLEW MOTOR

SLEW MOTOR GEARBOX

CONTROL VALVE

CENTRE JOINT

SLEW BEARING

TRACK CHAINS & GROUSERS

TOP ROLLERS

FRONT IDLERS

RECOIL SPRINGS

TRACK ADJUSTERS

BOTTOM ROLLERS

TRACK MOTORS

FINAL DRIVES


DRIVE SPROCKETS

BATTERIES

HOSES

Other Parts Books

Bucket




100	{	00A	~	1
		01	~	1
		02	~	1
		03	~	1

ITEM	PART NO.	PART NAME
	9071708	BUCKET ASS'Y
00	8037019	BUCKET
00A	4195699	ADAPTER;TOOTH
00B	4143531	STOPPER
01	4512365	POINT;TOOTH
02	4512366	PIN;LOCK
03	4501625	RUBBER;LOCK
04	2021232	CUTTER;SIDE
05	2021233	CUTTER;SIDE
06	J932265	BOLT
07	J951022	NUT
08	A590922	WASHER;SPRING
09	4143522	BOSS
10	4143524	SHIM 1.0
11	4143525	SHIM 0.5
12	4143523	PLATE
13	J901645	BOLT
14	A590916	WASHER;SPRING
15	4179110	PIN;KNOCK
100	9056408	KIT;POINT

[Home Page](#)

Bucket Pins




ITEM	PART NO.	PART NAME
------	----------	-----------

00A-I	7017643	ARM ASS'Y
00A	6008137	ARM
00B	3026077	BUSHING
00C	4143372	SPACER
00D	3026075	BUSHING
00E	4143370	SPACER
00F	3026076	BUSHING
00G	4143371	SPACER
00H	4143531	STOPPER
00I	4067720	STOPPER
01A-C	8037697	LINK (WITH BUSHING)
01A	2023924	LINK
01B	3037259	BUSHING
01C	3028854	BUSHING
02A-C	8037698	LINK (WITH BUSHING)
02A	2023925	LINK
02B	3037259	BUSHING
02C	3028854	BUSHING
03	8026311	LINK
04	3026104	LINK
05	4155763	SPACER
06	3037538	PIN
07	3026126	PIN
08	3037539	PIN
09	3037540	PIN
10	3037541	PIN
10	3041581	PIN
11	3037542	PIN
11	3041580	PIN
13	M222005	BOLT
14	M222004	BOLT
15	J591020	NUT
19	4100180	O-RING
22	4074008	SEAL;DUST
23	4067901	SEAL;DUST
25	J75481	FITTING
26	J75581	FITTING

28	4189839	SHIM 1.2
29	4189838	SHIM 2.3
30	4101281	SHIM 1.2
31	4142950	SHIM 2.3
32	J75481	FITTING

[Home Page](#)

Bucket Linkages



ITEM	PART NO.	PART NAME
------	----------	-----------

00A-I	7017643	ARM ASS'Y
00A	6008137	ARM
00B	3026077	BUSHING
00C	4143372	SPACER
00D	3026075	BUSHING
00E	4143370	SPACER
00F	3026076	BUSHING
00G	4143371	SPACER
00H	4143531	STOPPER
00I	4067720	STOPPER
01A-C	8037697	LINK (WITH BUSHING)
01A	2023924	LINK
01B	3037259	BUSHING
01C	3028854	BUSHING
02A-C	8037698	LINK (WITH BUSHING)
02A	2023925	LINK
02B	3037259	BUSHING
02C	3028854	BUSHING
03	8026311	LINK
04	3026104	LINK
05	4155763	SPACER
06	3037538	PIN
07	3026126	PIN
08	3037539	PIN
09	3037540	PIN
10	3037541	PIN
10	3041581	PIN
11	3037542	PIN
11	3041580	PIN
13	M222005	BOLT
14	M222004	BOLT
15	J591020	NUT
19	4100180	O-RING
22	4074008	SEAL;DUST
23	4067901	SEAL;DUST
25	J75481	FITTING
26	J75581	FITTING

Hitachi Ex300 1 Spare PartsFull download: <http://manualplace.com/download/hitachi-ex300-1-spare-parts/>

28	4189839	SHIM 1.2
29	4189838	SHIM 2.3
30	4101281	SHIM 1.2
31	4142950	SHIM 2.3
32	J75481	FITTING

[Home Page](#)
