

**HITACHI**

# **Training Text**

**ZAXIS**

**200-3 class**

**240-3 class**

**270-3 class**

**GENERAL INFORMATION**

**Technical Training Center**

# Contents

Overview (Front) .....	1
Overview (Side).....	1
Overview (Rear) .....	3
Cab (STD).....	3
Air Conditioner (Fresh Air Filter).....	5
Air Conditioner (Circulating Air Filter) .....	5
Cab Interior .....	7
Cab Floor .....	7
Emergency Engine Stop Switch .....	9
Multi-Function Monitor.....	9
Switch Panel (Right) .....	11
Switch Panel (Left) .....	11
Pilot Control Shut-Off Lever .....	13
Pilot Valve & Shut-Off Switch .....	13
Rear Tray .....	15
Electrical Parts in Cab .....	15
Engine Compartment with Cover .....	17
Engine.....	17
Cooled EGR System Sensors .....	19
Crank Speed Sensor & Sensors.....	19
Coolant Temp. Sensor.....	21
Common Rail Pressure Sensor.....	21
Main Fuel / Pre-Fuel Filter & Fuel Pump .....	23
Engine Oil Filter.....	23
Engine Oil Drain .....	25
Engine Oil Drainer .....	25
Utility Space .....	27
Engine Control Module (ECM) .....	27
Air Cleaner and Element .....	29

# Contents

Air Cleaner Restriction Switch.....	29
Atmospheric Pressure Sensor.....	31
Intake Air Temperature Sensor.....	31
Cooling System (Inter Cooler and Radiator, Oil Cooler).....	33
Air Conditioner Condenser and Fuel Cooler.....	33
Battery and Relays.....	35
Pump Compartment.....	35
Pump Device.....	37
Pump Regulator.....	37
Pilot Filter.....	39
Main Component Layout.....	39
Control Valve.....	41
Main and Overload Relief Valve.....	41
Arm Roll-In Pressure Sensor.....	43
Boom-Up Pressure Sensor.....	43
Signal Control Valve.....	45
Swing Device.....	45
Hydraulic Oil Tank.....	47
Hydraulic Oil Temperature Sensor.....	47
Fuel Tank.....	49
Fuel Level Gauge Sensor.....	49
Automatic Fuel Device (Option).....	51
Undercarriage.....	53
Track Frame.....	53
Track Link and Rollers.....	55
Front Idler.....	55
Travel Device.....	57
Travel Motor.....	57
Center Joint (1).....	59

# Contents

Center Joint (2) .....	59
Front Attachment (Standard) .....	61
Attachment Piping (Standard) .....	61
Hose Rupture Valve for Mono Boom Type (Option) .....	63

**OVERVIEW (FRONT)**



**OVERVIEW (SIDE)**



001

002

**New Model Configuration**

