SECURITY SYSTEM

P/N: 08E51-SV4-100-F



s the cut pages sample. Download all 30 page(s) at: ManualPlace.com

Contents

Introduction 3	Disarming	
Precautions 4	Disarming Methods	
Remote Control Transmitter	Remote Controlled Disarming	19
Controls and Functions6	Disarm/Valet Switch Disarming	
Battery Replacement 8	(DuringAlarming)	20
Remote Control Code Programming	Disarming During the Entry Delay	
Remote Control Code Programming How to Program Remote Control	Time	21
Transmitters9	Panic	21
System Controls	Valet (Auto/Auto Lock Mode)	23
Main Unit Switched 12	Tripped Sensor Warning And	
Glass Breakage Detector 13	Indication	
Disarm/Valet Switches 13	Tripped Sensor Warnings	24
Arming	Tripped Sensor Incication	24
Arming Methods 14	Last Tripped Sensor Recall	
Manual Arming (Remote Controlled) 14	Optional Items	
Auto Arming (Passive) 15	Soft Chirp Siren	26
Auto Arming and Locking (Passive) 16	Hood Switch	26
Alarm Mode	Remote Control Transmitter	26
Alarm Triggered Mode 18	Glossary	27

Please write the serial number of the remote control and the main unit below. Keep this booklet as a record of your purchase.

Remote Control No.:

Main Unit No.: ____

Introduction

Congratulations on your purchase of this Honda Security System. Your Honda Security System is the product of years of research and development. It will give you many years of reliable performance, protection, and convenience.

The system consists of two major components: a main unit and a remote control transmitter.

The main unit is the "brain" of the system . The built-in programmable microprocessor monitors your vehicle for optimal protection while offering various options to tailor the system to the preferences of different users.

The pocket-sized remote control allows you to turn the system on and off from the outside the vehicle while simultaneously locking and including the doors*. The transmitter can also be used to Intentionally activate the horn or optional siren in case of an emergency.

To take full advantage of your Honda Security System, we encourage you to read this manual thoroughly.

* For vehicles equipped with power door locks.

Due to the expertise required to properly install the Honda Security System, we highly recommend that the installation be performed by your Honda dealer. Proper wiring and component placement are essential for optimum system performance.

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) This device must accept any interference that may be received including interference that may cause undesired operation.