
Manual Transmission 1



Manual transmission



TRMT-1ET6H

Index

Subject	Page
Purpose of transmissions	3
Gear drive	4
Shift mechanism	5
Synchronizer	8
Power flow	9
Clutches system	11
Different clutch systems	12
Concentric slave cylinder	13
Self adjusting clutch	15
Double mass fly wheel	16
Clutch inspection and replacement	17
Drive train layouts	18
Rear wheel drive	19
Differentials	20
Locking differentials	22
Multi plate locking differential	23
Helical type locking differential	24
Front wheel drive	25
Service and maintenance	26
Hyundai transmissions	27
Transmission application table	29




Purpose of transmissions

I

20

10

0



1000

100 km/h 150

50

1000 2000 3000 4000 1/min 6000

In order to make a car move, it has to overcome several resistances. The three main resistances against vehicle movement are the: Rolling resistance, it is low at good tarmac and high at heavy off-road road condition. Air resistance: it is low at low speed and high at high speed. It does not increase linear with the speed, but by the power of 2 in relation with the speed: at double speed the air resistance is four times higher etc. The air resistance of a vehicle depends also on its shape, expressed by the Cw value. This value is measured in a wind channel. The vehicle is positioned on a force measuring device, while it is subject to a defined wind speed.

Gradient resistance on inclined roads; the steeper the road the higher is the resistance. The maximum climbing ability may be restricted in the case of trailer towing. The sum of all resistances requires a power train performance according to the dynamic condition of the vehicle. As the engine has a limited range of sufficient power and torque, as well as a maximum engine speed allowance, a system to adopt to adjust the torque and speed to the actual requirements. This device is called transmission.

The transmission changes the engine speed and torque to the value required to drive the car. To overcome the inertia force of the vehicle from standstill to motion, high torque at low wheel speed is needed. The transmission changes the relatively high speed /low torque of the engine to low speed / high torque. Once the car is in motion and is accelerating less torque but higher speed is required, therefore a transmission has several gears with different gear ratios to cope with these requirements.