
# REPAIR MANUAL FOR IVECO NEF ENGINES F4GE0454C - F4GE0484G



Every information, illustration and specification contained in the present manual is based on the most recent information available at the time of printing.

# INTRODUCTION -


#### TO THE READER

- ☐ This manual was written for a skilled technician and contains all the technical information needed to repair this vehicle.
- Read this manual carefully for the information concerning repairing operations.
- For any question or comment, or should you notice any mistake concerning the content of this manual, please contact an Authorised Dealer.

#### **FURTHER REFERENCES**

## **PAGE NUMBER**

Every page carries a number on the top right corner. Every page contains the following information:



### **SYMBOLS**

This manual contains safety warning symbols and indications referring to possible injuries or vehicle damages.



This symbol regards safety.

Use great care when you see this symbol because possible injuries to the personnel may occur. Strictly observe the precautions marked with this symbol.

The safety warning symbol is used also to draw attention on the weight of a component or an element. Make sure you are always using the right equipment and lifting techniques when handling heavy loads, in order to prevent injuries or damages.

# - INTRODUCTION -

# **UNIT OF MEASURE**

This manual adopts the units of measure based on the International System.

The MKSA system units of measure are indicated within brackets after the units of measure of the International System.

Example: 24.5 Mpa (250 kgf/cm2).

The following table converts the International System units of measure in some of the main units belonging to other systems.

Quantity	To convert from (IS)	in (Others)	Multiply by	Quantity	To convert from (IS)	in (Others)	Multiply by
Longth	mm	in	0.03937	Pressure	MPa	kgf/cm <sup>2</sup>	10.197
Length	mm	ft	0.003281	Fressure	MPa	psi	145.0
	L	US gal	0.2642	Power	kW	PS	1.360
Volume	L	US qt	1.057	Fower	kW	HP	1.341
	m <sup>3</sup>	yd <sup>3</sup>	1.308	Temperature	°C	°F	°C x 1.8 + 32
Mass	kg	lb	2.205	Spood	km/h	mph	0.6214
Force	N	kgf	0.10197	Speed	min <sup>-1</sup>	rpm	1.0
Force	N	lbf	0.2248	Capacity	L/min	US gpm	0.2642
Torque	N.m	kgf.m	0.10197	Capacity	mL/rev	cc/rev	1.0
	N.m	lbf.ft	0.7375				

# **ENGINES**

## **INDEX OF SECTIONS**



Section 1 - Diagnostics

EW-1-1



Section 2 - Engine F4GE0454C - F4GE0484G overhaul

EW-2-1



**Section 3** - Recharging and start-up

EW-3-1

# **DIAGNOSTICS**




# **INDEX**

Diagnostics	EW-1-3

#### **DIAGNOSTICS-**

#### Main engine operating anomalies:

- 1 Engine won't start;
- 2 Engine overheats;
- 3 Engine lacks power and works erratically;
- 4 Engine exhaust smoke black or dark grey;
- 5 Engine exhaust smoke grey (verging on white);
- 6 Engine exhaust smoke light blue;
- 7 Engine knocks irregularly;
- 8 Engine stops;
- 9 Engine exceeds max. revs number;
- 10 Excessive or insufficient oil pressure;
- 11 Excessive fuel consumption;
- 12 Engine won't stop.



Full download/iveco-nef-engine-f4ge0454c-f4ge0484g-repair-manual/

