

HP4872

-UN-01JAN94



JOHN DEERE 9400 MAXIMIZER™ COMBINE

(1989-)

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE 900 SERIES PLATFORM PARTS CATALOG - PC-2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 40 SERIES CORN HEAD PARTS CATALOG - PC-1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE 50A SERIES ROW-CROP HEAD PARTS CATALOG - PC-1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE THREE-ROLLER BELT PICKUP PARTS CATALOG - PC-2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE 918 AND 920 DRAPER PLATFORMS PARTS CATALOG - PC-2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 90 SERIES CORN HEAD PARTS CATALOG - PC-2404.

IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9400 MAXIMIZER™ COMBINE. VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION PLATE (PIN) IS LOCATED NEAR RIGHT-HAND SIDE OF THE TOOL BOX.
AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9400X630101
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9400 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

630101 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)


COMBINE - TYPE OF PRODUCT

COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS. ALL RIGHTS RESERVED.

THE ENGINE SERIAL NUMBER IS LOCATED ON THE RIGHT-HAND SIDE OF THE ENGINE BLOCK.

9400 ENGINE SERIAL NUMBER

HP4063 -UN-01JAN94



1. NUMBER OF CYLINDERS -6-
2. CUBIC INCH DISPLACEMENT -359
3. TYPE OF AIR INTAKE -T- TURBOCHARGED
4. FACTORY USER -H- HARVESTER
5. ENGINE VERSION (FIRST) -
6. ENGINE SERIAL NUMBER -
7. ENGINE MANUFACTURER -T- DUBUQUE

PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES PART MAY BE USED: FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING SERIAL NUMBER LISTED.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED..
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER IS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

FOR INDIVIDUAL HEADER PARTS CATALOGS REFER TO:

PC-2104 - PARTS CATALOG FOR JOHN DEERE 900 SERIES PLATFORMS

PC-2210 - PARTS CATALOG FOR JOHN DEERE THREE ROLLER BELT PICK-UP

PC-2212 - PARTS CATALOG FOR JOHN DEERE 918 DRAPER PLATFORMS

PC-1747 - PARTS CATALOG FOR JOHN DEERE 50A SERIES ROW-CROP HEADS


PC-1223 - PARTS CATALOG FOR JOHN DEERE 40 SERIES CORN HEADS

PC-2404 - PARTS CATALOG FOR JOHN DEERE 90 SERIES CORN HEADS

ENGINE SERIAL NUMBER PLATE

TP8011

-UN-01JAN94



- | | |
|--|---|
| 1. DESIGNATES ENGINE MANUFACTURER | T-JOHN DEERE DUBUQUE WORKS |
| 2. DESIGNATES NUMBER OF CYLINDERS AND LITERS | 5059 (5.9 LITER) 6068 (6.8 LITER) |
| 3. DESIGNATES FUEL TYPE OR SPECIAL CONDITION | DF NON-TURBOCHARGED DIESEL ENGINE TF TURBOCHARGED DIESEL ENGINE |
| 4. DESIGNATES ENGINE SERIAL NUMBER | 123456 |
| 5. DESIGNATES THE ENGINE APPLICATION AND FACTORY USER. | 6059AH001 (-337245) 6068HH001 (337246-701275) 6068HH050 (701276-) |

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™
DIAL-A-MATIC™
HARVESTRAK™
CONTOUR MASTER™

POSI-TORQ™
TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE FAN, INTERCOOLER AND SCREENS

SECTION 24 - 6359 AND 6068 ENGINES

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - SEPARATOR SHELL

SECTION 90 - OPERATOR'S STATION

SECTION 110 - FEEDER HOUSE

SECTION 120 - THRESHING AND SEPARATION

SECTION 121 - DRIVES

SECTION 125 - RESIDUE DISPOSAL

SECTION 130 - CLEAN GRAIN ELEVATOR, GRAIN TANK AND UNLOADING AUGER

SECTION 160 - DIAL-A-MATIC HEADER HEIGHT CONTROL

SECTION 170 - DECALS, BELTS AND CHAINS

SECTION 180 - NUMERICAL INDEX

ALPHABETICAL INDEX

| GRID | A | PAGE | GRID | PAGE | |
|------|---|----------|------|--|----------|
| 5F4 | A/C COMPRESSOR (650101-) R134A | 90 - 92 | 2D9 | AIR CONDITIONER WIRING HARNESS (-660100) | 40 - 22 |
| 5F5 | A/C COMPRESSOR COVER (650101-) R134A | 90 - 93 | 2D11 | AIR CONDITIONER WIRING HARNESS (660101-) | 40 - 24 |
| 5F4 | A/C COMPRESSOR DIODE (650101-) R134A | 90 - 92 | 5C22 | AIR CONDITIONING AND HEATER DUCTS | 90 - 33 |
| 5F4 | A/C COMPRESSOR MANIFOLD (650101-) R134A | 90 - 92 | 4F3 | AIR CONDITIONING CONDENSER AND OIL COOLER | 70 - 90 |
| 5F5 | A/C COMPRESSOR PULLEY (650101-) R134A | 90 - 93 | 5E18 | AIR CONDITIONING SYSTEM | 90 - 80 |
| 5F4 | A/C COMPRESSOR SEAL (650101-) R134A | 90 - 92 | 5E20 | AIR CONDITIONING SYSTEM (-650100) R-12 REFRIGERANT | 90 - 82 |
| 5F7 | A/C COMPRESSOR SEAL KIT (650101-) | 90 - 95 | 5E22 | AIR CONDITIONING SYSTEM (650101-) R134A REFRIGERANT | 90 - 84 |
| 1C7 | A/C CONDENSER, AIR INTER COOLER AND RADIATOR WITH OIL COOLER | 20 - 20 | 5E16 | AIR CONDITIONING/HEATER AND PRESSURIZING FAN | 90 - 78 |
| 2E17 | A/C HIGH PRESSURE SWITCH, 6068 UPPER PARTS | 40 - 56 | 5E14 | AIR CONDITIONING/HEATER HOUSING AND FILTERS | 90 - 76 |
| 2E17 | A/C HIGH PRESSURE SWITCH, 6359 UPPER PARTS | 40 - 56 | 1G4 | AIR INTAKE | 24 - 95 |
| 1D6 | ACCESS COVER, INJECTION PUMP GEAR | 24 - 18 | 1G5 | AIR INTAKE | 24 - 96 |
| 4C23 | ACCUMULATOR AND MOUNTING, ONE GALLON (655101-) | 70 - 34 | 1G6 | AIR INTAKE SYSTEM | 24 - 97 |
| 4C21 | ACCUMULATOR HOSES AND LINES (-655100) (ONE-HALF GALLON) | 70 - 32 | 1C7 | AIR INTER COOLER, RADIATOR WITH OIL COOLER AND A/C CONDENSER | 20 - 20 |
| 4C23 | ACCUMULATOR HOSES AND LINES (655101-)(ONE GALLON) | 70 - 34 | 5D16 | AIR SEAT SUSPENSION (660101-) | 90 - 52 |
| 4B15 | ACCUMULATOR PRESSURE GAUGE | 70 - 2 | 5D18 | AIR SEAT SUSPENSION KITS (665101-) | 90 - 54 |
| 4B15 | ACCUMULATOR PRESSURE GAUGE WIRING HARNESS | 70 - 2 | 5D20 | AIR SEAT SUSPENSION KITS (665101-) | 90 - 56 |
| 4C21 | ACCUMULATOR, DUAL AND MOUNTING (-655100) (ONE-HALF GALLON) | 70 - 32 | 5D22 | AIR SEAT SUSPENSION KITS (665101-) | 90 - 58 |
| 4C19 | ACCUMULATOR, ONE-HALF GALLON (SINGLE) | 70 - 30 | 5D24 | AIR SEAT SUSPENSION KITS (665101-) | 90 - 60 |
| 3F8 | ACTUATOR, PARK BRAKE (-640100) | 60 - 2 | 2D11 | AIR SEAT WIRING HARNESS (660101-) | 40 - 24 |
| 1F11 | ADAPTER, EXHAUST | 24 - 76 | 5D18 | AIR SUSPENSION KITS, SEAT (665101-) | 90 - 54 |
| 2E3 | ADAPTER, WIRING HARNESS (CONTOUR MASTER) | 40 - 42 | 5D20 | AIR SUSPENSION KITS, SEAT (665101-) | 90 - 56 |
| 1H9 | ADAPTER,ENGINE COOLANT | 24 - 126 | 5D22 | AIR SUSPENSION KITS, SEAT (665101-) | 90 - 58 |
| 1E15 | ADAPTER,ENGINE OIL FILTER | 24 - 52 | 5D24 | AIR SUSPENSION KITS, SEAT (665101-) | 90 - 60 |
| 3G19 | ADJUSTABLE REAR AXLE | 60 - 38 | 5D16 | AIR SUSPENSION, SEAT (660101-) | 90 - 52 |
| 3G23 | ADJUSTABLE REAR AXLE STEERING TIE RODS | 60 - 42 | 112 | ALTERNATOR ADJUSTING STRAP | 24 - 156 |
| 5D12 | ADJUSTER, OPERATOR'S SEAT LEVER | 90 - 48 | 2F5 | ALTERNATOR AND SHEAVE (-650100) | 40 - 68 |
| 6G19 | ADJUSTING BRACKET, CYLINDER DRIVE, INTERMEDIATE | 121 - 42 | 2F3 | ALTERNATOR AND VOLTAGE REGULATOR(90 AMP) MOTOROLA-PRESTOLITE (-650100) | 40 - 66 |
| 5E5 | ADJUSTING MECHANISM, ARMREST (R.H.) (640101-) | 90 - 66 | 1111 | ALTERNATOR MOUNTING BRACKETS | 24 - 154 |
| 5E3 | ADJUSTING MECHANISM, ARMREST, R.H. (-640100) | 90 - 64 | 1112 | ALTERNATOR MOUNTING BRACKETS | 24 - 156 |
| 2F9 | ADJUSTING MOTOR, CONCAVE | 40 - 72 | 2F6 | ALTERNATOR, SHEAVE AND BELT BOSCH (650101-) | 40 - 69 |
| 2F1 | ADJUSTING MOTOR, SEPARATOR FAN DRIVE | 40 - 64 | 2F7 | ALTERNATOR, VOLTAGE REGULATOR (95 AMP) BOSCH (650101-) | 40 - 70 |
| 1112 | ADJUSTING STRAP, ALTERNATOR | 24 - 156 | 2D3 | ANTENNA, SPEAKERS AND RADIO | 40 - 16 |
| 2D13 | AIR CINDITIONER THERMOSTAT KIT (630101-640100) | 40 - 26 | 6G11 | ARM, LOCKOUT, DUAL-RANGE | 121 - 34 |
| 2B22 | AIR CLEANER AND INTAKE TUBES - GRAIN | 30 - 12 | 1H25 | ARMATURE | 24 - 143 |
| 2B24 | AIR CLEANER AND INTAKE TUBES - GRAIN | 30 - 14 | 117 | ARMATURE, STARTING MOTOR DRIVE | 24 - 150 |
| 2E17 | AIR CLEANER PLUGGED SWITCH, 6068 UPPER PARTS | 40 - 56 | 5E7 | ARMREST (L.H.) | 90 - 68 |
| 2E17 | AIR CLEANER PLUGGED SWITCH, 6359 UPPER PARTS | 40 - 56 | 5E3 | ARMREST ADJUSTING MECHANISM (R.H.) (-640100) | 90 - 64 |
| 1J8 | AIR CONDITIOING COMPRESSOR BRACKET | 24 - 178 | 5E5 | ARMREST ADJUSTING MECHANISM (R.H.) (640101-) | 90 - 66 |
| 2D9 | AIR CONDITIONER AND HEATER (WIRING HARNESS)(-660100) | 40 - 22 | 2D1 | ARMREST PANEL, OPERATOR'S | 40 - 14 |
| 2D17 | AIR CONDITIONER AND HEATER SWITCH | 40 - 30 | 2D1 | ARMREST ROCKER SWITCHES | 40 - 14 |
| 2D15 | AIR CONDITIONER PRESSURIZER FAN KIT (640101-650100) | 40 - 28 | 2C23 | ARMREST WIRING HARNESS | 40 - 12 |
| | | | 5E1 | ARMREST WITH GLOVE BOX (R.H.) | 90 - 62 |

ALPHABETICAL INDEX - CONTINUED

| <i>GRID</i> | | <i>PAGE</i> | <i>GRID</i> | | <i>PAGE</i> |
|-------------|--|-------------|-------------|--|-------------|
| 7H19 | BELTS, UPPER TAILINGS AUGER | 170 - 5 | 5C3 | CAB FRAME AND SUPPORT | 90 - 14 |
| 7H16 | BELTS, WALKER | 170 - 2 | 5F10 | CAB HARDWARE KIT | 90 - 98 |
| 4D13 | BI-DIRECTIONAL MODULE, SOLENOID CONTROL VALVE, REEL LIFT AND CYLINDER SPEED | 70 - 48 | 5B21 | CAB INTERIOR TRIM PANELS | 90 - 8 |
| 1D16 | BLOCK, CYLINDER | 24 - 28 | 5C17 | CAB L.H. LANDING AND MIRROR (650201-) | 90 - 28 |
| 1D17 | BLOCK, CYLINDER | 24 - 30 | 5C15 | CAB LANDING AND MIRROR (-650100) | 90 - 26 |
| 1D18 | BLOCK, CYLINDER | 24 - 31 | 5C19 | CAB LANDING AND MIRROR (R.H.) | 90 - 30 |
| 1D19 | BLOCK, CYLINDER | 24 - 32 | 2C12 | CAB LIGHT, DOME | 40 - 1 |
| 1D20 | BLOCK, CYLINDER | 24 - 33 | 5D7 | CAB OPERATOR'S SEAT AND BACKREST | 90 - 42 |
| 1D21 | BLOCK, CYLINDER | 24 - 34 | 5B15 | CAB PANELS AND FLOOR MAT | 90 - 2 |
| 1E3 | BLOCK, CYLINDER | 24 - 40 | 2C17 | CAB POST INSTRUMENT PANEL | 40 - 6 |
| 1C3 | BLOCK, ENGINE COOLANT HEATER | 20 - 16 | 5C23 | CAB POST INSTRUMENT PANEL | 90 - 34 |
| 1D23 | BLOCK, SHORT ENGINE | 24 - 36 | 5B19 | CAB REAR AND SIDE SEALS | 90 - 6 |
| 1E1 | BLOCK, SHORT ENGINE | 24 - 38 | 5C5 | CAB ROOF AND SUPPORTS | 90 - 16 |
| 3D3 | BLOCK, VALVE | 50 - 42 | 2C19 | CAB ROOF LIGHTS | 40 - 8 |
| 2F21 | BOARDS, ELECTRONIC | 40 - 84 | 5D14 | CAB SEAT HEIGHT ADJUSTER (VERTICAL CONTROL) | 90 - 50 |
| 2F7 | BOSCH ALTERNATOR AND VOLTAGE REGULATOR (95 AMP) (650101-) | 40 - 70 | 5B17 | CAB SOUND DEADENING, FOAM AND SEALS | 90 - 4 |
| 5C13 | BOX, TOOL (660101-) | 90 - 24 | 2C13 | CAB WIRING HARNESS | 40 - 2 |
| 3F25 | BRACKET, BRAKE CABLE SUPPORT (645101-) | 60 - 19 | 5C1 | CAB, COMPLETE | 90 - 12 |
| 5G24 | BRACKET, FEEDER CONVEYOR | 110 - 38 | 6C18 | CABLE, CONCAVE INDICATOR, AND BRACKETS | 120 - 32 |
| 4C19 | BRACKET, SINGLE ACCUMULATOR MOUNTING | 70 - 30 | 2G5 | CABLE, WIRING | 40 - 92 |
| 2E5 | BRACKET, STRAW CHOPPER SENSOR | 40 - 44 | 2F13 | CABLES, BATTERY | 40 - 76 |
| 1114 | BRACKET, TENSIONER | 24 - 158 | 3B17 | CABLES, CONTROL, HYDROSTATIC DRIVE (-645100) | 50 - 4 |
| 1J8 | BRACKET, AIR CONDITIONING COMPRESSOR | 24 - 178 | 3B19 | CABLES, HYDROSTATIC DRIVE CONTROL (645101-) | 50 - 6 |
| 1112 | BRACKETS, ALTERNATOR MOUNTING | 24 - 156 | 3D4 | CAM LOBE MOTOR (STEERABLE MOTOR) | 50 - 43 |
| 6C18 | BRACKETS, CONCAVE INDICATOR AND CABLE | 120 - 32 | 3D11 | CAM, CARRIER, AND PISTON (STEERABLE MOTOR) | 50 - 50 |
| 2E13 | BRACKETS, LOW SHAFT SPEED SENSORS | 40 - 52 | 1C23 | CAMSHAFT | 24 - 10 |
| 4E3 | BRACKETS, SOLENOID CONTROL VALVE | 70 - 64 | 1C24 | CAMSHAFT | 24 - 11 |
| 3F25 | BRAKE CABLE SUPPORT BRACKET (645101-) | 60 - 19 | 1C23 | CAMSHAFT GEAR | 24 - 10 |
| 3F20 | BRAKE CYLINDER, MASTER | 60 - 14 | 1C24 | CAMSHAFT GEAR | 24 - 11 |
| 3F16 | BRAKE CYLINDERS, MASTER AND BRAKE PEDALS | 60 - 10 | 7G3 | CAP, GRAIN TANK CLEAN OUT CHUTE | 130 - 32 |
| 3F12 | BRAKE LINES AND HOSES, PARKING, UPPER (-640100) | 60 - 6 | 1D17 | CAP, MAIN BEARING | 24 - 30 |
| 3F18 | BRAKE LINES, MASTER CYLINDER AND RESERVOIR | 60 - 12 | 1D19 | CAP, MAIN BEARING | 24 - 32 |
| 3F14 | BRAKE PEDAL AND SEAL, PARKING | 60 - 8 | 1D20 | CAP, MAIN BEARING | 24 - 33 |
| 3F16 | BRAKE PEDALS AND CYLINDERS, MASTER | 60 - 10 | 1D21 | CAP, MAIN BEARING | 24 - 34 |
| 3F22 | BRAKE SHOES AND DRUM (LEFT-HAND ILLUSTRATED) | 60 - 16 | 1D3 | CAP, OIL FILLER | 24 - 15 |
| 3F24 | BRAKE SLAVE CYLINDER | 60 - 18 | 1E10 | CAP, ENGINE OIL FILL | 24 - 47 |
| 3F8 | BRAKE, PARK, ACTUATOR (-640100) | 60 - 2 | 1E3 | CAP, MAIN BEARING | 24 - 40 |
| 3F10 | BRAKE, PARKING, LINES (-640100) | 60 - 4 | 3D13 | CAPS, YOKE AND PIVOTS (STEERABLE MOTOR) | 50 - 52 |
| 3F7 | BRAKE, PARKING, VALVE (-640100) | 60 - 1 | 3D11 | CARRIER, PISTON, AND CAM (STEERABLE MOTOR) | 50 - 50 |
| 2F17 | BREAKERS, CIRCUIT, ENGINE COMPARTMENT | 40 - 80 | 3E19 | CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES | 50 - 84 |
| 2F14 | BREAKERS, CIRCUIT, ENGINE COMPARTMENT (-660100) | 40 - 77 | 7G3 | CASE, VERTICAL AUGER LOWER GEAR | 130 - 32 |
| 2F15 | BREAKERS, CIRCUIT, ENGINE COMPARTMENT (660101-) | 40 - 78 | 2C17 | CDC (COMBINE DATA CENTER) | 40 - 6 |
| 112 | BRUSHES, STARTING MOTOR | 24 - 145 | 5C23 | CDC (COMBINE DATA CENTER) | 90 - 34 |
| 115 | BYPASS START KIT (ESN 709446-) | 24 - 148 | 7D13 | CHAFF SPREADER (DUAL MOTOR) HOSES AND LINES (650101-) | 125 - 50 |
| 1E11 | BYPASS VALVE, ENGINE OIL | 24 - 48 | 7D1 | CHAFF SPREADER (DUAL MOTOR) PAN, WINGS AND SEALS (650101-) | 125 - 38 |
| C | | | 7C21 | CHAFF SPREADER (DUAL MOTOR) SHIELDS AND HANDLES (650101-) | 125 - 34 |
| 5C21 | CAB AIR FILTER AND HOUSING | 90 - 32 | 7D5 | CHAFF SPREADER CONTROL, CHECK VALVE, ROD AND KNOB | 125 - 42 |
| 2C12 | CAB DOME LIGHT | 40 - 1 | 7C17 | CHAFF SPREADER DISC (DUAL MOTOR) (650101-) | 125 - 30 |
| 5C1 | CAB DOOR AND GLASS | 90 - 12 | 7C15 | CHAFF SPREADER DISC AND DRIVE BELT (-650100) | 125 - 28 |
| 5B23 | CAB DOOR LATCH | 90 - 10 | 7C19 | CHAFF SPREADER FRAME, SHIELDS AND HANDLES (-650100) | 125 - 32 |
| 5B15 | CAB FLOOR MAT | 90 - 2 | 7D7 | CHAFF SPREADER LINES AND FITTINGS | 125 - 44 |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE |
|------|--|----------|------|---|----------|
| 4B21 | CHAFF SPREADER MOTOR (EATON) (655929-) | 70 - 8 | 7F3 | CLEAN GRAIN ELEVATOR, UPPER | 130 - 8 |
| 7D3 | CHAFF SPREADER MOUNTING SUPPORT | 125 - 40 | 7F11 | CLEAN GRAIN LOADING AUGER | 130 - 16 |
| 7C23 | CHAFF SPREADER PAN AND SEALS (-650100) | 125 - 36 | 7F7 | CLEAN GRAIN LOADING AUGER HOUSING, UPPER | 130 - 12 |
| 7D11 | CHAFF SPREADER, HOSES, LINES AND MOTOR (-650100) | 125 - 48 | 7F9 | CLEAN GRAIN LOADING AUGER HOUSING, UPPER (660101-) | 130 - 14 |
| 7D9 | CHAFF SPREADER, LINES, HOSES, VALVE AND PUMP | 125 - 46 | 7F10 | CLEAN GRAIN LOADING AUGER, FOLD (660101-) | 130 - 15 |
| 7D15 | CHAFF SPREADER, PUMP | 125 - 52 | 7E22 | CLEAN GRAIN LOWER AUGER | 130 - 2 |
| 6D21 | CHAFFER ELEMENT | 120 - 60 | 7E24 | CLEAN GRAIN LOWER AUGER AND HINGED DOOR | 130 - 2 |
| 6D23 | CHAFFER ELEMENT | 120 - 62 | 7E24 | CLEAN GRAIN LOWER ELEVATOR | 130 - 4 |
| 6E1 | CHAFFER EXTENSION ELEMENT | 120 - 64 | 7F1 | CLEAN GRAIN LOWER ELEVATOR | 130 - 6 |
| 6E3 | CHAFFER FRAME | 120 - 66 | 7E24 | CLEAN GRAIN LOWER ELEVATOR AND CONVEYOR CHAIN | 130 - 4 |
| 6D19 | CHAFFER FRAME ARMS, PRECLEANER | 120 - 58 | 7F1 | CLEAN GRAIN LOWER ELEVATOR AND CONVEYOR CHAIN | 130 - 6 |
| 6D15 | CHAFFER FRAME, PRE-CLEANER | 120 - 54 | 7G3 | CLEAN OUT CHUTE, GRAIN TANK | 130 - 32 |
| 6D13 | CHAFFER, PRE-CLEANING | 120 - 52 | 2B22 | CLEANER, AIR AND INTAKE TUBES - GRAIN | 30 - 12 |
| 7E6 | CHAIN TIGHTENER, UPPER TAILINGS DRIVE | 125 - 67 | 2B24 | CLEANER, AIR AND INTAKE TUBES - GRAIN | 30 - 14 |
| 7E24 | CHAIN, CONVEYOR, CLEAN GRAIN LOWER ELEVATOR | 130 - 4 | 6H7 | CLEANING FAN DRIVE, SEPARATOR | 121 - 54 |
| 7F1 | CHAIN, CONVEYOR, CLEAN GRAIN LOWER ELEVATOR | 130 - 6 | 6D5 | CLEANING FAN INTAKE SHIELDS | 120 - 44 |
| 5G24 | CHAIN, FEEDER CONVEYOR DRIVE | 110 - 38 | 6D7 | CLEANING FAN INTAKE SHIELDS | 120 - 46 |
| 7E3 | CHAIN, TAILINGS ELEVATOR CONVEYOR | 125 - 64 | 6D9 | CLEANING FAN INTAKE SHIELDS (-645100) | 120 - 48 |
| 7G14 | CHANNEL, CROSS AUGER | 130 - 43 | 6D11 | CLEANING FAN INTAKE SHIELDS (645101-) | 120 - 50 |
| 7G5 | CHARGE HOUSING, VERTICAL UNLOADING AUGER | 130 - 34 | 6D3 | CLEANING FAN LEAF SCREENS (CORN) (660193-) | 120 - 42 |
| 4F10 | CHARGE PRESSURE HOSE (640101-) | 70 - 98 | 6D5 | CLEANING FANS AND SHROUDS | 120 - 44 |
| 7D5 | CHECK VALVE, ROD AND KNOB, CHAFF SPREADER CONTROL | 125 - 42 | 6D7 | CLEANING FANS AND SHROUDS | 120 - 46 |
| 7C1 | CHOPPER, STRAW, HOUSING (-655100) | 125 - 14 | 6C23 | CLEANOUT DOOR, CONVEYOR AUGER, HANDLE AND LATCHES | 120 - 37 |
| 7C1 | CHOPPER, STRAW, KNIFEBACK (-655100) | 125 - 14 | 5G7 | CLEANOUT DOORS, FEEDER HOUSE | 110 - 20 |
| 7G3 | CHUTE, GRAIN TANK CLEAN OUT | 130 - 32 | 5G11 | CLOSURE PLATES, FEEDER HOUSE - CONTOUR MASTER (660101-) | 110 - 24 |
| 2D1 | CIGARETTE LIGHTER | 40 - 14 | 6G1 | CLUTCH, HEADER ELECTROMAGNETIC | 121 - 24 |
| 2C17 | CIRCUIT BOARD, COMBINE DATA CENTER | 40 - 6 | 5G18 | CLUTCH, SLIP, FEEDER HOUSE | 110 - 32 |
| 5C23 | CIRCUIT BOARD, COMBINE DATA CENTER | 90 - 34 | 1I5 | CLUTCH, STARING MOTOR (ESN 709446-) | 24 - 148 |
| 2F19 | CIRCUIT BREAKER AND RELAY, THROTTLE CONTROL PANEL | 40 - 82 | 1I9 | CLUTCH, STARTING MOTOR | 24 - 152 |
| 2F17 | CIRCUIT BREAKER RELAYS | 40 - 80 | 1I1 | COIL, STARTING MOTOR | 24 - 144 |
| 2F14 | CIRCUIT BREAKER RELAYS (-660100) | 40 - 77 | 3G5 | COLD WEATHER START BUTTON | 60 - 24 |
| 2F15 | CIRCUIT BREAKER RELAYS (660101-) | 40 - 78 | 5E10 | COLD WEATHER START BUTTON | 90 - 72 |
| 2F17 | CIRCUIT BREAKERS, ENGINE COMPARTMENT | 40 - 80 | 2B18 | COLD WEATHER STARTING AID (-655415) | 30 - 8 |
| 2F14 | CIRCUIT BREAKERS, ENGINE COMPARTMENT (-660100) | 40 - 77 | 2B20 | COLD WEATHER STARTING AID (655416-) | 30 - 10 |
| 2F15 | CIRCUIT BREAKERS, ENGINE COMPARTMENT (660101-) | 40 - 78 | 2C17 | COMBINE DATA CENTER | 40 - 6 |
| 2E23 | CLAMPS, UNLOADING AUGER LIGHT | 40 - 62 | 5C23 | COMBINE DATA CENTER | 90 - 34 |
| 7E24 | CLEAN GRAIN CONVEYOR CHAIN | 130 - 4 | 4F24 | COMPARTMENT, ENGINE (-640100) | 80 - 10 |
| 7F1 | CLEAN GRAIN CONVEYOR CHAIN | 130 - 6 | 4G3 | COMPARTMENT, ENGINE (-640100) | 80 - 14 |
| 7F15 | CLEAN GRAIN ELEVATOR DRIVE IDLER | 130 - 20 | 4G1 | COMPARTMENT, ENGINE (640100-) | 80 - 12 |
| 7F15 | CLEAN GRAIN ELEVATOR DRIVE TIGHTENER | 130 - 20 | 4G5 | COMPARTMENT, ENGINE (640101-) | 80 - 16 |
| 7F15 | CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER | 130 - 20 | 5E20 | COMPRESSOR AIR CONDITIONER (-650100) R-12 REFRIGERANT | 90 - 82 |
| 7F13 | CLEAN GRAIN ELEVATOR GEARCASE | 130 - 18 | 5E22 | COMPRESSOR AIR CONDITIONER (650101-) R134A REFRIGERANT | 90 - 84 |
| 7F17 | CLEAN GRAIN ELEVATOR SHIELDS, UPPER (-640100) | 130 - 22 | 5E25 | COMPRESSOR CLUTCH (-650100) R-12 REFRIGERANT | 90 - 87 |
| 7F19 | CLEAN GRAIN ELEVATOR SHIELDS, UPPER (640101-) | 130 - 24 | 5E24 | COMPRESSOR CLUTCH AND SERVICE VALVES (-650100) R-12 REFRIGERANT | 90 - 86 |
| 7F5 | CLEAN GRAIN ELEVATOR UPPER SHAFT | 130 - 10 | 5F1 | COMPRESSOR HARDWARE KIT (-650100) R-12 | 90 - 88 |
| 7F5 | CLEAN GRAIN ELEVATOR UPPER SHAFT, SPROCKET AND SHEAVE | 130 - 10 | 5F6 | COMPRESSOR HARDWARE KIT (650101-) R134A | 90 - 94 |
| 7F5 | CLEAN GRAIN ELEVATOR UPPER SHEAVE | 130 - 10 | | | |
| 7F5 | CLEAN GRAIN ELEVATOR UPPER SPROCKET | 130 - 10 | | | |

ALPHABETICAL INDEX - CONTINUED

| <i>GRID</i> | | <i>PAGE</i> | <i>GRID</i> | | <i>PAGE</i> |
|-------------|--|-------------|-------------|---|-------------|
| 5F2 | COMPRESSOR PARTS (-650100) R-12 | 90 - 90 | 3D18 | CONTROL VALVE (655101-) | 50 - 57 |
| 5E25 | COMPRESSOR SERVICE VALVES (-650100) R-12 REFRIGERANT | 90 - 87 | 4E1 | CONTROL VALVE MODULE, SIX STACK SOLENOID ASSEMBLY & MOUNTINGS (660101-) | 70 - 62 |
| 7H17 | COMPRESSOR, AIR CONDITIONING BELTS..... | 170 - 3 | 3D19 | CONTROL VALVE SOLENOID (FOUR-WHEEL DR.) | 50 - 58 |
| 2F9 | CONCAVE ADJUSTING MOTOR | 40 - 72 | 5F8 | CONTROL VALVE, HEATER | 90 - 96 |
| 6C8 | CONCAVE ASSEMBLY AND BEATER GRATE,13-BAR NARROW | 120 - 22 | 3C24 | CONTROL VALVE, HYDRO. DR. DISPLACEMENT | 50 - 38 |
| 6C18 | CONCAVE INDICATOR, CABLE AND BRACKETS..... | 120 - 32 | 4D22 | CONTROL VALVE, SOLENOID - CONTOUR MASTER (660101-) | 70 - 58 |
| 6C4 | CONCAVE, RASP BAR AND GRATE | 120 - 18 | 4D20 | CONTROL VALVE, SOLENOID, REEL FORE/AFT (650201-) | 70 - 56 |
| 6C6 | CONCAVE, RASP BAR AND GRATE | 120 - 20 | 5E3 | CONTROL, ARMREST ADJUSTING MECHANISM, R.H. (-640100)..... | 90 - 64 |
| 6C14 | CONCAVE, SPIKE TOOTH | 120 - 28 | 2G15 | CONVENIENCE OUTLET (660101-) | 40 - 102 |
| 6C12 | CONCAVE, SPIKE-TOOTH | 120 - 26 | 4B24 | CONVERSION PARTS, HUDRAULIC, 200 SERIES CUTTING PLATFORM..... | 70 - 11 |
| 5E20 | CONDENSER, AIR CONDITIONER (-650100) R-12 REFRIGERANT | 90 - 82 | 7H16 | CONVEYOR AUGER BELTS, | 170 - 2 |
| 5E22 | CONDENSER, AIR CONDITIONER (650101-) R134A REFRIGERANT | 90 - 84 | 6C23 | CONVEYOR AUGER CLEANOUT DOOR, HANDLE AND LATCHES..... | 120 - 37 |
| 4F3 | CONDENSER, AIR CONDITIONING AND OIL COOLER | 70 - 90 | 6H3 | CONVEYOR AUGERS, STRAW WALKER, SIEVE AND CHAFFER DRIVE | 121 - 50 |
| 1C15 | CONDITIONER, COOLANT..... | 24 - 2 | 7E24 | CONVEYOR CHAIN, CLEAN GRAIN | 130 - 4 |
| 1D8 | CONNECTING ROD | 24 - 20 | 7F1 | CONVEYOR CHAIN, CLEAN GRAIN | 130 - 6 |
| 1D11 | CONNECTING ROD | 24 - 23 | 1C15 | COOLANT CONDITIONER | 24 - 2 |
| 1D9 | CONNECTING ROD (6068)..... | 24 - 21 | 1J10 | COOLANT HEATER, ENGINE | 24 - 180 |
| 1D8 | CONNECTING ROD BEARINGS | 24 - 20 | 1C3 | COOLANT HEATER, ENGINE BLOCK..... | 20 - 16 |
| 1D11 | CONNECTING ROD BEARINGS | 24 - 23 | 2C5 | COOLANT RECOVERY TANK | 30 - 20 |
| 1D9 | CONNECTING ROD BEARINGS (6068)..... | 24 - 21 | 1H3 | COOLER, ENGINE OIL | 24 - 120 |
| 2F23 | CONNECTORS, ELECTRICAL, WEATHERPACK | 40 - 86 | 1H5 | COOLER, ENGINE OIL (6068) | 24 - 122 |
| 2G9 | CONNECTORS, HARNESS, LOWER, FOR 6359 ENGINE | 40 - 96 | 7H17 | COOLING FAN BELTS | 170 - 3 |
| 2G11 | CONNECTORS, HARNESS, UPPER FOR 6359 ENGINE | 40 - 98 | 7C7 | CORN CURTAIN AND DEFLECTORS | 125 - 20 |
| 1J4 | CONNECTORS, STARTING AID | 24 - 174 | 6B22 | CORN CYLINDER DOOR (ARGENTINA ONLY)..... | 120 - 10 |
| 1J5 | CONNECTORS, STARTING AID | 24 - 175 | 4H3 | CORNER SHEET, R H FRONT | 80 - 38 |
| 1J6 | CONNECTORS, STARTING AID | 24 - 176 | 4H5 | CORNER SHEET, REAR, L H | 80 - 40 |
| 2G7 | CONNECTORS, SUPPLEMENTARY TERMINALS | 40 - 94 | 6G21 | COUNTERSHAFT DRIVE, SECONDARY..... | 121 - 44 |
| 5E1 | CONSOLE GLOVE BOX AND ARM REST, R.H..... | 90 - 62 | 7H1 | COUNTERSHAFT DRIVE, UNLOADING AUGER | 130 - 54 |
| 2C15 | CONSOLE PANEL, OVERHEAD..... | 40 - 4 | 6F24 | COUNTERSHAFT GEARCASE, PRIMARY (640101-) | 121 - 22 |
| 5G11 | CONTOUR MASTER - FEEDER HOUSE FRAME, TILT BEAM & CLOSURE PLATES (660101-)..... | 110 - 24 | 6F20 | COUNTERSHAFT GEARCASE, PRIMARY (640101-)..... | 121 - 18 |
| 5H17 | CONTOUR MASTER DRIVESHAFT | 110 - 56 | 6F22 | COUNTERSHAFT, PRIMARY, GEARCASE (-640100) | 121 - 20 |
| 5H15 | CONTOUR MASTER DRIVESHAFT (660101-) | 110 - 54 | 6F18 | COUNTERSHAFT, PRIMARY, GEARCASE (-640100)..... | 121 - 16 |
| 4C13 | CONTOUR MASTER HYDRAULIC HOSES, L.H SIDE (OPTIONAL) (660101-) | 70 - 24 | 1B24 | COUPLING WITH HUB, ENGINE-TRANSMISSION..... | 20 - 13 |
| 5G15 | CONTOUR MASTER LOCKOUT ADAPTER KIT (BELT PU & 4R CORN HEADS) (660101-) | 110 - 28 | 1D6 | COVER, ACCESS, INJECTION PUMP GEAR | 24 - 18 |
| 4D10 | CONTOUR MASTER SOLENOID CONTROL RELIF VALVE | 70 - 45 | 6C22 | COVER, BEATER | 120 - 36 |
| 4D22 | CONTOUR MASTER SOLENOID CONTROL VALVE (660101-) | 70 - 58 | 5F5 | COVER, COMPRESSOR A/C (650101-) R134A | 90 - 93 |
| 4E20 | CONTOUR MASTER TILT CYLINDER..... | 70 - 82 | 4F24 | COVER, ENGINE (-640100) | 80 - 10 |
| 4E21 | CONTOUR MASTER TILT CYLINDER HOSES AND FITTINGS..... | 70 - 83 | 4G3 | COVER, ENGINE (-640100) | 80 - 14 |
| 2E3 | CONTOUR MASTER WIRING HARNESS ADAPTER | 40 - 42 | 4G1 | COVER, ENGINE (640100-) | 80 - 12 |
| 5G9 | CONTOUR MASTER, FEEDER HOUSE SHELL, WEAR PLATES AND SEALS (660101-) | 110 - 22 | 4G5 | COVER, ENGINE (640101-) | 80 - 16 |
| 5G13 | CONTOUR MASTER, LOCKOUT ASSEMBLY (OPTIONAL) (660101-) | 110 - 26 | 1E9 | COVER, ENGINE OIL FILLER OPENING | 24 - 46 |
| 3B17 | CONTROL CABLES, HYDROSTATIC DRIVE (-645100) | 50 - 4 | 3C18 | COVER, HYDROSTATIC DRIVE PUMP..... | 50 - 31 |
| 3B19 | CONTROL CABLES, HYDROSTATIC DRIVE (645101-) | 50 - 6 | 3C15 | COVER, HYDROSTATIC PUMP (RING AND PINION) | 50 - 28 |
| 2D1 | CONTROL PANEL, OPERATOR'S ARMREST | 40 - 14 | 3D7 | COVER, INNER | 50 - 46 |
| 2F19 | CONTROL PANEL, THROTTLE, RELAY AND CIRCUIT BREAKER | 40 - 82 | 1E10 | COVER, OIL FILLER OPENING | 24 - 47 |
| 3D17 | CONTROL VALVE (-655100) | 50 - 56 | 3D10 | COVER, QUILL AND BEARING (STEERABLE MOTOR)..... | 50 - 49 |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE |
|------|---|----------|------|--|----------|
| 1D2 | COVER, ROCKER ARM | 24 - 14 | 6G17 | CYLINDER DRIVE INTERMEDIATE SHEAVE, DUAL-RANGE | 121 - 40 |
| 1D3 | COVER, ROCKER ARM | 24 - 15 | 6G13 | CYLINDER DRIVE TIGHTENER, DUAL-RANGE | 121 - 36 |
| 1D4 | COVER, ROCKER ARM | 24 - 16 | 6G5 | CYLINDER DRIVE, SINGLE RANGE | 121 - 28 |
| 1I2 | COVER, STARTING MOTOR END..... | 24 - 145 | 6G7 | CYLINDER DRIVE, SLOW SPEED..... | 121 - 30 |
| 1H1 | COVER, THERMOSTAT | 24 - 118 | 1F3 | CYLINDER HEAD | 24 - 68 |
| 6B13 | COVER, THRESHING CYLINDER | 120 - 1 | 1F5 | CYLINDER HEAD | 24 - 70 |
| 1D5 | COVER, TIMING GEAR..... | 24 - 17 | 1F7 | CYLINDER HEAD | 24 - 72 |
| 1D6 | COVER, TIMING GEAR..... | 24 - 18 | 1F9 | CYLINDER HEAD | 24 - 74 |
| 7G14 | COVERS AND CHANNEL, CROSS AUGER | 130 - 43 | 1F3 | CYLINDER HEAD GASKET | 24 - 68 |
| 1C5 | CRANKCASE, ENGINE, OIL DRAIN..... | 20 - 18 | 1F5 | CYLINDER HEAD GASKET | 24 - 70 |
| 6E19 | CRANKS, STRAW WALKER, STRAW SPREADER DRIVE AND SHIELD | 120 - 82 | 1F7 | CYLINDER HEAD GASKET | 24 - 72 |
| 1C16 | CRANKSHAFT | 24 - 3 | 1F9 | CYLINDER HEAD GASKET | 24 - 74 |
| 1C17 | CRANKSHAFT | 24 - 4 | 1I20 | CYLINDER HEAD REMOVAL GASKET SET | 24 - 165 |
| 1C19 | CRANKSHAFT | 24 - 6 | 1J3 | CYLINDER HEAD REMOVAL GASKET SET | 24 - 172 |
| 1C20 | CRANKSHAFT - BEARINGS | 24 - 7 | 1D8 | CYLINDER LINER | 24 - 20 |
| 1I16 | CRANKSHAFT DAMPER | 24 - 161 | 1D11 | CYLINDER LINER | 24 - 23 |
| 1I17 | CRANKSHAFT DAMPER..... | 24 - 162 | 1D10 | CYLINDER LINER KIT..... | 24 - 22 |
| 1C19 | CRANKSHAFT GEAR | 24 - 6 | 1D8 | CYLINDER LINER O-RING KIT | 24 - 20 |
| 1C17 | CRANKSHAFT IDLER GEARS | 24 - 4 | 1D11 | CYLINDER LINER O-RING KIT | 24 - 23 |
| 1C21 | CRANKSHAFT KIT, UNDERSIZE | 24 - 8 | 1C15 | CYLINDER LINER PACKING LUBRICANT | 24 - 2 |
| 1I16 | CRANKSHAFT PULLEY | 24 - 161 | 6B24 | CYLINDER SHEAR BAR | 120 - 12 |
| 1I17 | CRANKSHAFT PULLEY | 24 - 162 | 4D13 | CYLINDER SPEED AND REEL LIFT, SOLENOID CONTROL VALVE..... | 70 - 48 |
| 1C19 | CRANKSHAFT THRUST BEARING | 24 - 6 | 4D7 | CYLINDER SPEED HYDRAULIC LINES AND HOSES .. | 70 - 42 |
| 1C22 | CRANKSHAFT, REPLACEMENT (6359) | 24 - 9 | 3F24 | CYLINDER, BRAKE SLAVE | 60 - 18 |
| 7G21 | CROSS AUGER BEARING PLATE, L.H. | 130 - 50 | 3F20 | CYLINDER, BRAKE, MASTER | 60 - 14 |
| 7G14 | CROSS AUGER COVERS AND CHANNEL..... | 130 - 43 | 4E10 | CYLINDER, DRIVE, GRAIN TANK UNLOADING..... | 70 - 72 |
| 7G23 | CROSS AUGERS, GRAIN TANK | 130 - 52 | 4C15 | CYLINDER, HEADER LIFT, HYDRAULIC | 70 - 26 |
| 4F16 | CROSS BRACES, SEPARATOR | 80 - 2 | 4E8 | CYLINDER, HYDRAULIC, UNLOADING AUGER SWING, LINES AND HOSES | 70 - 70 |
| 5E9 | CUP HOLDER (660101-) | 90 - 70 | 3G17 | CYLINDER, STEERING (4-WHEEL DRIVE)..... | 60 - 36 |
| 6C3 | CURTAIN, BEATER GRATE (650437-) | 120 - 16 | 6C1 | CYLINDER, THRESHING, RASP BAR | 120 - 14 |
| 6E21 | CURTAIN, SEPARATOR | 120 - 84 | 6C10 | CYLINDER, THRESHING, SPIKE TOOTH (OPTIONAL)..... | 120 - 24 |
| 7D17 | CURTAIN, SEPARATOR (-640194) | 125 - 54 | 4E20 | CYLINDER, TILT - CONTOUR MASTER | 70 - 82 |
| 6E23 | CURTAIN, SEPARATOR (SPIKE-TOOTH CYLINDER)..... | 120 - 86 | 4E21 | CYLINDER, TILT, HOSES AND FITTINGS - CONTOUR MASTER..... | 70 - 83 |
| 7D19 | CURTAIN, SPREADER (640195-) | 125 - 56 | 4E12 | CYLINDER, UNLOADING AUGER SWING HYDRAULIC (-650100)..... | 70 - 74 |
| 7G1 | CURTAINS, GRAIN TANK..... | 130 - 30 | 4E14 | CYLINDER, UNLOADING AUGER SWING HYDRAULIC (650101-655355) | 70 - 76 |
| 4B24 | CUTTING PLATFORM , 200 SERIES CONVERSION PARTS | 70 - 11 | 4E16 | CYLINDER, UNLOADING AUGER SWING HYDRAULIC (655356-) | 70 - 78 |
| 1D16 | CYLINDER BLOCK | 24 - 28 | 3F16 | CYLINDERS, MASTER BRAKE AND BRAKE PEDALS | 60 - 10 |
| 1D17 | CYLINDER BLOCK | 24 - 30 | | | |
| 1D18 | CYLINDER BLOCK | 24 - 31 | D | | |
| 1D19 | CYLINDER BLOCK | 24 - 32 | 1C22 | DAMPENER, REPLACEMENT CRANKSHAFT (6359).... | 24 - 9 |
| 1D20 | CYLINDER BLOCK | 24 - 33 | 1I16 | DAMPER, CRANKSHAFT | 24 - 161 |
| 1D21 | CYLINDER BLOCK | 24 - 34 | 1I17 | DAMPER, CRANKSHAFT | 24 - 162 |
| 1E3 | CYLINDER BLOCK | 24 - 40 | 2C17 | DATA CENTER, COMBINE | 40 - 6 |
| 6B13 | CYLINDER COVER, THRESHING | 120 - 1 | 5C23 | DATA CENTER, COMBINE | 90 - 34 |
| 6B18 | CYLINDER DOOR (CORN & GRAIN) (650101-655208)..... | 120 - 6 | 7I22 | DECALS, FRONT..... | 170 - 34 |
| 6B16 | CYLINDER DOOR (FOR CORN) (-650100) | 120 - 4 | 7I19 | DECALS, LEFT-HAND | 170 - 30 |
| 6B20 | CYLINDER DOOR (CORN AND GRAIN) (655208-) | 120 - 8 | 7I22 | DECALS, REAR | 170 - 34 |
| 6B22 | CYLINDER DOOR, CORN (ARGENTINA ONLY)..... | 120 - 10 | 7H20 | DECALS, SAFETY AND LOCATIONS | 170 - 6 |
| 6G19 | CYLINDER DRIVE ADJUSTING BRACKET, INTERMEDIATE..... | 121 - 42 | 7H22 | DECALS, SAFETY AND LOCATIONS | 170 - 8 |
| 6G17 | CYLINDER DRIVE BELT | 121 - 40 | 7H24 | DECALS, SAFETY AND LOCATIONS | 170 - 10 |
| 6G9 | CYLINDER DRIVE BELT, EXTENDED RANGE..... | 121 - 32 | 7I1 | DECALS, SAFETY AND LOCATIONS | 170 - 12 |
| 6G9 | CYLINDER DRIVE GEAR CASE, DUAL-RANGE..... | 121 - 32 | 7I3 | DECALS, SAFETY AND LOCATIONS | 170 - 14 |
| 6G15 | CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING, DUAL-RANGE | 121 - 38 | 7I5 | DECALS, SAFETY AND LOCATIONS - FRENCH | 170 - 16 |
| | | | 7I7 | DECALS, SAFETY AND LOCATIONS - FRENCH | 170 - 18 |
| | | | 7I9 | DECALS, SAFETY AND LOCATIONS - FRENCH | 170 - 20 |
| | | | 7I11 | DECALS, SAFETY AND LOCATIONS - FRENCH | 170 - 22 |
| | | | 7I13 | DECALS, SAFETY AND LOCATIONS - FRENCH | 170 - 24 |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE |
|------|--|----------|------|--|----------|
| 7I24 | DECALS, TOP | 170 - 36 | 6F16 | DRIVE SHAFT, GEARCASE AND PRIMARY COUNTERSHAFT | 121 - 14 |
| 7B14 | DECK, SUPPORTS AND FINS, STRAW CHOPPER..... | 125 - 2 | 3B23 | DRIVE SHAFTS | 50 - 10 |
| 7C7 | DEFLECTORS AND CORN CURTAIN | 125 - 20 | 4G21 | DRIVE SHIELD, R.H. REAR | 80 - 32 |
| 7H11 | DIAL-A-MATIC ELECTRICAL HARNESS | 160 - 2 | 5G3 | DRIVE SHIELDS, CONTOUR MASTER FEEDER HOUSE (660101-660245) | 110 - 16 |
| 7H10 | DIAL-A-MATIC HEADER HEIGHT CONTROL HYDRAULIC LINE AND VALVE BLOCK | 160 - 1 | 5G5 | DRIVE SHIELDS, CONTOUR MASTER FEEDER HOUSE (660246-) | 110 - 18 |
| 7H13 | DIAL-A-MATIC HEADER HEIGHT CONTROL VALVE BLOCK SOLENOID | 160 - 4 | 5G1 | DRIVE SHIELDS, SAFETY STOP, FEEDER HOUSE | 110 - 14 |
| 4C18 | DIAL-A-MATIC HEADER HEIGHT CONTROL VALVE.... | 70 - 29 | 6I7 | DRIVE SHIELDS, STRAW CHOPPER (640101-) | 121 - 78 |
| 3C8 | DIFFERENTIAL GEARS | 50 - 20 | 7C5 | DRIVE SPROCKETS, STRAW CHOPPER (655101-) | 125 - 18 |
| 3C8 | DIFFERENTIAL SHAFTS | 50 - 20 | 7F15 | DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR | 130 - 20 |
| 2C13 | DIGITAL TACH CONN. (WIRING HARNESS) | 40 - 2 | 6H17 | DRIVE TIGHTENER, FEEDER HOUSE | 121 - 64 |
| 5F4 | DIODE, A/C COMPRESSOR (650101-) R134A | 90 - 92 | 5F24 | DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE | 110 - 12 |
| 1E11 | DIPSTICK, ENGINE OIL | 24 - 48 | 5F22 | DRIVE TIGHTENER, VARIABLE SPEED | 110 - 10 |
| 1E12 | DIPSTICK, ENGINE OIL | 24 - 49 | 3B21 | DRIVE WHEELS | 50 - 8 |
| 7C15 | DISC AND DRIVE BELT, CHAFF SPREADER (-650100) | 125 - 28 | 6H19 | DRIVE, BELT PICKUP / REEL PUMP MOUNTING SHEAVE | 121 - 66 |
| 7C17 | DISC, CHAFF SPREADER (DUAL MOTOR) (650101-) | 125 - 30 | 6H7 | DRIVE, CLEANING FAN, SEPARATOR | 121 - 54 |
| 3C24 | DISPLACEMENT CONTROL VALVE, HYDRO. DR. | 50 - 38 | 7H1 | DRIVE, COUNTERSHAFT, UNLOADING AUGER | 130 - 54 |
| 2C13 | DOMELIGHT (WIRING HARNESS) | 40 - 2 | 7H17 | DRIVE, CYLINDER INTERMEDIATE, BELTS | 170 - 3 |
| 5B23 | DOOR LATCH, CAB | 90 - 10 | 7H17 | DRIVE, CYLINDER, BELTS | 170 - 3 |
| 5C1 | DOOR, CAB AND GLASS | 90 - 12 | 1B23 | DRIVE, ENGINE, 6359 | 20 - 12 |
| 7C9 | DOOR, CHOPPER, STRAW | 125 - 22 | 1I14 | DRIVE, FAN | 24 - 158 |
| 7E22 | DOOR, CLEAN GRAIN LOWER AUGER | 130 - 2 | 6H15 | DRIVE, FAN, SPEED CONTROL SHEAVE LINKAGE.... | 121 - 62 |
| 4H7 | DOOR, CORNER SHEET, LEFT - HAND FRONT..... | 80 - 42 | 6G23 | DRIVE, GEARCASE, STRAW WALKER..... | 121 - 46 |
| 6B18 | DOOR, CYLINDER (CORN & GRAIN) (650101-655208) | 120 - 6 | 3D1 | DRIVE, HYDROSTATIC MOTOR, FIXED (RING AND PINION) | 50 - 40 |
| 6B16 | DOOR, CYLINDER (FOR CORN) (-650100) | 120 - 4 | 3E5 | DRIVE, HYDROSTATIC OIL HOSES, UPPER (FOUR WHEEL DRIVE) (-655100) | 50 - 70 |
| 6B20 | DOOR, CYLINDER (CORN AND GRAIN) (655208-) | 120 - 8 | 3E1 | DRIVE, HYDROSTATIC, LOWER OIL LINES (FOUR WHEEL DRIVE) (655101-) | 50 - 66 |
| 6B22 | DOOR, CYLINDER DOOR (ARGENTINA ONLY) | 120 - 10 | 3D24 | DRIVE, HYDROSTATIC, LOWER OIL LINES (FOUR WHEEL DRIVE)(-655100) | 50 - 64 |
| 4F20 | DOOR, ENGINE ACCESS | 80 - 6 | 3E3 | DRIVE, HYDROSTATIC, LOWER OIL LINES (TWO WHEEL DRIVE) (655101-) | 50 - 68 |
| 4F20 | DOOR, RADIATOR | 80 - 6 | 3D20 | DRIVE, HYDROSTATIC, LOWER OIL LINES (2&4 WHEEL DRIVE)(-655100) | 50 - 60 |
| 1B17 | DOOR, ROTARY SCREEN | 20 - 6 | 4C1 | DRIVE, REEL, HYD., FRONT LINES AND HOSES..... | 70 - 12 |
| 1B15 | DOOR, ROTARY SCREEN (-640100) | 20 - 4 | 4B17 | DRIVE, REEL, HYDRAULIC LINES AND HOSES, L.H. SIDE | 70 - 4 |
| 7C9 | DOOR, STRAW CHOPPER..... | 125 - 22 | 1B12 | DRIVE, ROTARY SCREEN (-645100) | 20 - 1 |
| 4D15 | DOUBLE PILOTED, AUGER SWING, SOLENOID CONTROL VALVE (-650100) | 70 - 50 | 6G21 | DRIVE, SECONDARY COUNTERSHAFT | 121 - 44 |
| 4D19 | DOUBLE PILOTED, REEL FORE/AFT, SOLENOID CONTROL VALVE | 70 - 55 | 6I5 | DRIVE, STRAW CHOPPER, SHIELDS..... | 121 - 76 |
| 4D18 | DOUBLE PILOTED, REEL FORE/AFT, SOLENOID CONTROL VALVE (-650100) | 70 - 54 | 6H21 | DRIVES, STRAW CHOPPER (FRONT) | 121 - 68 |
| 1E22 | DRAIN HOSE, ENGINE OIL | 24 - 61 | 6I1 | DRIVES, STRAW CHOPPER (REAR) (-640100) | 121 - 72 |
| 1E23 | DRAIN HOSE, ENGINE OIL | 24 - 62 | 6H23 | DRIVES, STRAW CHOPPER, FINE CUT (FRONT) | 121 - 70 |
| 1E21 | DRAIN HOSE, ENGINE OIL (6359T) | 24 - 60 | 6I3 | DRIVES, STRAW CHOPPER, FINE CUT (REAR)..... | 121 - 74 |
| 1H16 | DRAIN HOSE, FUEL FILTER | 24 - 134 | 5H17 | DRIVESHAFT, CONTOUR MASTER | 110 - 56 |
| 7C15 | DRIVE BELT AND DISC, CHAFF SPREADER (-650100) | 125 - 28 | 5H15 | DRIVESHAFT, CONTOUR MASTER (660101-) | 110 - 54 |
| 6G9 | DRIVE BELT, EXTENDED RANGE CYLINDER..... | 121 - 32 | 3F22 | DRUM, BRAKE..... | 60 - 16 |
| 6G17 | DRIVE BELT, EXTENDED RANGE CYLINDER..... | 121 - 40 | 4C21 | DUAL ACCUMULATOR AND MOUNTING (-655100) (ONE-HALF GALLON) | 70 - 32 |
| 7E4 | DRIVE BRACKET, TAILINGS | 125 - 65 | 2E23 | DUAL LEVEL MONITOR | 40 - 62 |
| 7E6 | DRIVE CHAIN TIGHTENER, UPPER TAILINGS | 125 - 67 | 2E23 | DUAL LEVEL MONITOR WIRING HARNESS | 40 - 62 |
| 3B17 | DRIVE CONTROL CABLES, HYDROSTATIC (-645100) | 50 - 4 | 6G9 | DUAL-RANGE CYLINDER DRIVE GEAR CASE | 121 - 32 |
| 3B19 | DRIVE CONTROL CABLES, HYDROSTATIC (645101-) | 50 - 6 | 6G15 | DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING..... | 121 - 38 |
| 7F15 | DRIVE IDLER, CLEAN GRAIN ELEVATOR | 130 - 20 | 6G17 | DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHEAVE | 121 - 40 |
| 3E23 | DRIVE MOTOR, HYDROSTATIC | 50 - 90 | 6G13 | DUAL-RANGE CYLINDER DRIVE TIGHTENER | 121 - 36 |
| 1E19 | DRIVE SHAFT, ENGINE OIL PUMP (6068)..... | 24 - 58 | | | |

ALPHABETICAL INDEX - CONTINUED

| <i>GRID</i> | | <i>PAGE</i> | <i>GRID</i> | | <i>PAGE</i> |
|-------------|--|-------------|-------------|---|-------------|
| 6G11 | DUAL-RANGE LOCKOUT ARM | 121 - 34 | 1B19 | ENGINE FAN DRIVES, 6359 | 20 - 8 |
| 5C22 | DUCTS, HEATER AND AIR CONDITIONING | 90 - 33 | 1B19 | ENGINE FAN, 6359 | 20 - 8 |
| 5H21 | DUST FAN BELT, LH SIDE FEEDER | | 1D12 | ENGINE FRONT PLATE | 24 - 24 |
| | HOUSE-RETROFIT INSTALLATION..... | 110 - 60 | 1D13 | ENGINE FRONT PLATE | 24 - 25 |
| 5H23 | DUST FAN, LH SIDE FEEDER | | 1D14 | ENGINE FRONT PLATE | 24 - 26 |
| | HOUSE-RETROFIT INSTALLATION..... | 110 - 62 | 1D15 | ENGINE FRONT PLATE | 24 - 27 |
| E | | | | | |
| 2E19 | EITHER START SOLENIOD, 6068 | | 6F12 | ENGINE GEARCASE | |
| | LOWER PARTS..... | 40 - 58 | | (SEPARATOR AND PUMP DRIVE) | 121 - 10 |
| 2E19 | EITHER START SOLENOID, 6359 | | 4F5 | ENGINE GEARCASE OIL FILTER ASSEMBLY..... | 70 - 92 |
| | LOWER PARTS..... | 40 - 58 | 4F7 | ENGINE GEARCASE PRESSURE REGULATOR | 70 - 94 |
| 1F1 | ELBOW, ENGINE VENTILATING | 24 - 66 | 6F8 | ENGINE GEARCASE- SEPARATOR DRIVE WET- | |
| 1F11 | ELBOW, EXHAUST | 24 - 76 | | CLUTCH AND PUMP DRIVE SHAFT | 121 - 6 |
| 2G1 | ELECTRICAL CONNECTOR SERVICE KIT | 40 - 88 | 6F4 | ENGINE GEARCASE- STRAW CHOPPER,UNLOADING | |
| 2G3 | ELECTRICAL CONNECTOR SERVICE KIT | 40 - 90 | | DRIVE AND SEPARATOR DRIVE GEAR | 121 - 2 |
| 7H11 | ELECTRICAL HARNESS, DIAL-A-MATIC..... | 160 - 2 | 6F14 | ENGINE GEARCASE, SEPARATOR AND PUMP | |
| 2G8 | ELECTRICAL SERVICE OUTLET..... | 40 - 95 | | DRIVE | 121 - 12 |
| 2F23 | ELECTRICAL TERMINALS AND CONNECTORS, | | 6F10 | ENGINE GEARCASE, SEPARATOR DRIVE WET- | |
| | WEATHERPACK | 40 - 86 | | CLUTCH AND PUMP DRIVE SHAFT | 121 - 8 |
| 6G1 | ELECTROMAGNETIC HEADER CLUTCH | 121 - 24 | 6F6 | ENGINE GEARCASE, STRAW CHOPPER, UNLOAD- | |
| 2F21 | ELECTRONIC BOARDS | 40 - 84 | | ING DRIVE AND SEPARATOR DRIVE GEAR | 121 - 4 |
| 2F21 | ELECTRONIC HOUSING ASSEMBLY AND | | 1G9 | ENGINE INTERCOOLER..... | 24 - 101 |
| | ELECTRONIC BOARDS | 40 - 84 | 1G10 | ENGINE INTERCOOLER HOSE | 24 - 102 |
| 6D21 | ELEMENT, CHAFFER | 120 - 60 | 1J1 | ENGINE MAJOR OVERHAUL GASKET SET..... | 24 - 170 |
| 6D23 | ELEMENT, CHAFFER | 120 - 62 | 1C14 | ENGINE OIL..... | 24 - 1 |
| 6E1 | ELEMENT, CHAFFER EXTENSION | 120 - 64 | 1E3 | ENGINE OIL BY-PASS VALVE | 24 - 40 |
| 1H13 | ELEMENT, FUEL FILTER | 24 - 131 | 1H3 | ENGINE OIL COOLER | 24 - 120 |
| 6E5 | ELEMENT, SIEVE | 120 - 68 | 1H7 | ENGINE OIL COOLER | 24 - 124 |
| 1H16 | ELEMENT,FUEL FILTER | 24 - 134 | 1H9 | ENGINE OIL COOLER | 24 - 126 |
| 7F15 | ELEVATOR DRIVE IDLER, CLEAN GRAIN..... | 130 - 20 | 1H5 | ENGINE OIL COOLER (6068)..... | 24 - 122 |
| 7F15 | ELEVATOR DRIVE TIGHTENER, CLEAN GRAIN..... | 130 - 20 | 1H7 | ENGINE OIL COOLER HOSE..... | 24 - 124 |
| 7F17 | ELEVATOR SHIELDS, UPPER CLEAN GRAIN | | 1E11 | ENGINE OIL DIPSTICK..... | 24 - 48 |
| | (-640100) | 130 - 22 | 1E12 | ENGINE OIL DIPSTICK..... | 24 - 49 |
| 7F19 | ELEVATOR SHIELDS, UPPER CLEAN GRAIN | | 1E12 | ENGINE OIL DIPSTICK TUBE | 24 - 49 |
| | (640101-) | 130 - 24 | 1E22 | ENGINE OIL DRAIN HOSE..... | 24 - 61 |
| 7H17 | ELEVATOR, CLEAN GRAIN BELTS..... | 170 - 3 | 1E23 | ENGINE OIL DRAIN HOSE..... | 24 - 62 |
| 7E24 | ELEVATOR, LOWER, CLEAN GRAIN | 130 - 4 | 1E21 | ENGINE OIL DRAIN HOSE (6359T)..... | 24 - 60 |
| 7F1 | ELEVATOR, LOWER, CLEAN GRAIN | 130 - 6 | 1E10 | ENGINE OIL FILL CAP | 24 - 47 |
| 7F3 | ELEVATOR, UPPER CLEAN GRAIN | 130 - 8 | 1D4 | ENGINE OIL FILL PLUG | 24 - 16 |
| 1I2 | END FRAME, STARTING MOTOR COMMUTATOR | 24 - 145 | 1E11 | ENGINE OIL FILTER | 24 - 48 |
| 1C1 | ENGINE MOUNTS, 6359 AND REAR SUPPORT | 20 - 14 | 1E13 | ENGINE OIL FILTER | 24 - 50 |
| 4F20 | ENGINE ACCESS DOOR, HANDRAILS, AND | | 1E14 | ENGINE OIL FILTER | 24 - 51 |
| | RADIATOR DOOR..... | 80 - 6 | 1E15 | ENGINE OIL FILTER | 24 - 52 |
| 4G7 | ENGINE ACCESS PLATFORM AND STEP | 80 - 18 | 1E16 | ENGINE OIL FILTER | 24 - 54 |
| 2E14 | ENGINE AIR FILTER WARNING SWITCH..... | 40 - 53 | 1H11 | ENGINE OIL FILTER | 24 - 129 |
| 1E7 | ENGINE BASIC OVERHAUL KIT | 24 - 44 | 1H12 | ENGINE OIL FILTER | 24 - 130 |
| 2F14 | ENGINE CIRCUIT BREAKER | | 1E15 | ENGINE OIL FILTER ADAPTER..... | 24 - 52 |
| | (-660100) | 40 - 77 | 1E22 | ENGINE OIL PAN | 24 - 61 |
| 2F17 | ENGINE CIRCUIT BREAKERS | 40 - 80 | 1E23 | ENGINE OIL PAN | 24 - 62 |
| 2F15 | ENGINE CIRCUIT BREAKERS | | 1E18 | ENGINE OIL PUMP | 24 - 56 |
| | (660101-) | 40 - 78 | 1E20 | ENGINE OIL PUMP | 24 - 59 |
| 4F24 | ENGINE COMPARTMENT | | 1E19 | ENGINE OIL PUMP (6068) | 24 - 58 |
| | (-640100) | 80 - 10 | 1E19 | ENGINE OIL PUMP DRIVE SHAFT (6068) | 24 - 58 |
| 4G3 | ENGINE COMPARTMENT | | 1E20 | ENGINE OIL PUMP GEAR | 24 - 59 |
| | (-640100) | 80 - 14 | 1E20 | ENGINE OIL PUMP HOUSING | 24 - 59 |
| 4G1 | ENGINE COMPARTMENT | | 1E20 | ENGINE OIL PUMP INTAKE..... | 24 - 59 |
| | (640100-) | 80 - 12 | 1I21 | ENGINE OVERHAUL GASKET SET..... | 24 - 166 |
| 4G5 | ENGINE COMPARTMENT | | 1I23 | ENGINE OVERHAUL GASKET SET (624E) | 24 - 168 |
| | (640101-) | 80 - 16 | 1D8 | ENGINE PISTON | 24 - 20 |
| 1H9 | ENGINE COOLANT ADAPTER..... | 24 - 126 | 1D11 | ENGINE PISTON | 24 - 23 |
| 1J10 | ENGINE COOLANT HEATER | 24 - 180 | 2E14 | ENGINE PLUGGED AIR FILTER WARNING SWITCH .. | 40 - 53 |
| 7H16 | ENGINE DRIVE BELTS..... | 170 - 2 | 4F24 | ENGINE RAILS | |
| 7H16 | ENGINE DRIVE SHEAVES | 170 - 2 | | (-640100) | 80 - 10 |
| 1B23 | ENGINE DRIVE, 6359 | 20 - 12 | 4G3 | ENGINE RAILS | |
| | | | | (-640100) | 80 - 14 |
| | | | 4G1 | ENGINE RAILS | |
| | | | | (640100-) | 80 - 12 |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE |
|------|---|----------|------|--|----------|
| 4G5 | ENGINE RAILS (640101-) | 80 - 16 | | F | |
| 1D23 | ENGINE SHORT BLOCK | 24 - 36 | 1114 | FAN DRIVE | 24 - 158 |
| 1E1 | ENGINE SHORT BLOCK | 24 - 38 | 1114 | FAN DRIVE HOUSING | 24 - 158 |
| 1E5 | ENGINE SHORT BLOCK | 24 - 42 | 1114 | FAN DRIVE HUB | 24 - 158 |
| 2E17 | ENGINE TACH SENSOR, 6068 UPPER PARTS | 40 - 56 | 1114 | FAN DRIVE PULLEY | 24 - 158 |
| 2E17 | ENGINE TACH SENSOR, 6359 UPPER PARTS | 40 - 56 | 4G19 | FAN DRIVE SHIELD (L-H SIDE) | 80 - 30 |
| 2C17 | ENGINE TEMPERATURE GAUGE | 40 - 6 | 6H9 | FAN DRIVE SPEED CONTROL LINKAGE (-640100) | 121 - 56 |
| 5C23 | ENGINE TEMPERATURE GAUGE | 90 - 34 | 6H11 | FAN DRIVE SPEED CONTROL LINKAGE (640101-655100) | 121 - 58 |
| 2E17 | ENGINE TEMPERATURE SENDER, 6068 UPPER PARTS | 40 - 56 | 6H13 | FAN DRIVE SPEED CONTROL LINKAGE (655101-) | 121 - 60 |
| 2E17 | ENGINE TEMPERATURE SENDER, 6359 UPPER PARTS | 40 - 56 | 6H15 | FAN DRIVE SPEED CONTROL SHEAVE LINKAGE | 121 - 62 |
| 2E19 | ENGINE TEMPERATURE SENDING SWITCH LOWER PARTS | 40 - 58 | 1B19 | FAN DRIVES, 6359 ENGINE | 20 - 8 |
| 2E19 | ENGINE TEMPERATURE SENDING SWITCH 6068, LOWER PARTS | 40 - 58 | 2D15 | FAN, AIR CONDITIONER PRESSURIZER KIT (640101-650100) | 40 - 28 |
| 1G23 | ENGINE THERMOSTAT | 24 - 115 | 5E16 | FAN, AIR CONDITIONING/HEATER AND PRESSURIZING | 90 - 78 |
| 1G24 | ENGINE THERMOSTAT | 24 - 117 | 7H18 | FAN, CLEANING, BELTS | 170 - 4 |
| 1G23 | ENGINE THERMOSTAT HOUSING | 24 - 115 | 6H7 | FAN, DRIVE, CLEANING, SEPARATOR | 121 - 54 |
| 1G24 | ENGINE THERMOSTAT HOUSING | 24 - 117 | 5H23 | FAN, DUST, LH SIDE FEEDER HOUSE-RETROFIT INSTALLATION | 110 - 62 |
| 2E17 | ENGINE UPPER HARNESS, 6068 UPPER PARTS | 40 - 56 | 1B19 | FAN, 6359 ENGINE | 20 - 8 |
| 2E17 | ENGINE UPPER HARNESS, 6359 UPPER PARTS | 40 - 56 | 6D5 | FANS, CLEANING | 120 - 44 |
| 1C15 | ENGINE VALVE STEM LUBRICANT | 24 - 2 | 6D7 | FANS, CLEANING | 120 - 46 |
| 1F1 | ENGINE VENTILATING SYSTEM | 24 - 66 | 5H3 | FEED PLATE LATCH HANDLE | 110 - 42 |
| 1E25 | ENGINE VENTILATOR TUBE | 24 - 64 | 7H16 | FEEDER CONVEYOR BELTS | 170 - 2 |
| 1B24 | ENGINE-TRANSMISSION COUPLING WITH HUB | 20 - 13 | 5G24 | FEEDER CONVEYOR BRACKET | 110 - 38 |
| 2E19 | ENGINE, LOWER, HARNESS, 6068 LOWER PARTS | 40 - 58 | 5G24 | FEEDER CONVEYOR DRIVE CHAIN | 110 - 38 |
| 2E19 | ENGINE, LOWER, HARNESS, 6359 LOWER PARTS | 40 - 58 | 5H1 | FEEDER CONVEYOR DRIVE CHAIN, TIGHTENER AND GUIDES | 110 - 40 |
| 1E21 | ENIGNE OIL PAN (6359T) | 24 - 60 | 5H19 | FEEDER CONVEYOR DRIVE CHAIN, TIGHTENER AND GUIDES-RETROFIT INSTALLATION | 110 - 58 |
| 3G5 | ETHER START BUTTON | 60 - 24 | 5G24 | FEEDER CONVEYOR IDLER | 110 - 38 |
| 5E10 | ETHER START BUTTON | 90 - 72 | 4B22 | FEEDER HOUSE , HYD. HOSE, VARIABLE DRIVE | 70 - 9 |
| 2B18 | ETHER STARTING AID (-655415) | 30 - 8 | 2G22 | FEEDER HOUSE BACKSHAFT SPEED SENSOR (645123-) | 40 - 110 |
| 2B20 | ETHER STARTING AID (655416-) | 30 - 10 | 7H18 | FEEDER HOUSE BELTS | 170 - 4 |
| 5F8 | EVAPORATOR/HEATER UNIT | 90 - 96 | 5G3 | FEEDER HOUSE DRIVE SHIELDS - CONTOUR MASTER (660101-660245) | 110 - 16 |
| 5E20 | EVAPORATOR, AIR CONDITIONER (-650100)R-12 REFRIGERANT | 90 - 82 | 5G5 | FEEDER HOUSE DRIVE SHIELDS - CONTOUR MASTER (660246-) | 110 - 18 |
| 5E22 | EVAPORATOR, AIR CONDITIONER (650101-) R134A REFRIGERANT | 90 - 84 | 5G1 | FEEDER HOUSE DRIVE SHIELDS AND SAFETY STOP | 110 - 14 |
| 1F11 | EXHAUST ADAPTER | 24 - 76 | 6H17 | FEEDER HOUSE DRIVE TIGHTENER | 121 - 64 |
| 1F11 | EXHAUST ELBOW | 24 - 76 | 5F24 | FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED) | 110 - 12 |
| 1F11 | EXHAUST MANIFOLD | 24 - 76 | 5H21 | FEEDER HOUSE DUST FAN BELT, LH SIDE - RETROFIT INSTALLATION | 110 - 60 |
| 1F12 | EXHAUST MANIFOLD | 24 - 77 | 5H23 | FEEDER HOUSE DUST FAN, LH SIDE - RETROFIT INSTALLATION | 110 - 62 |
| 1F12 | EXHAUST MANIFOLD GASKET | 24 - 77 | 5G22 | FEEDER HOUSE FLOOR | 110 - 36 |
| 2C1 | EXHAUST PIPE AND MUFFLER | 30 - 16 | 5G7 | FEEDER HOUSE FRAME AND FRONT SHAFT | 110 - 20 |
| 1F9 | EXHAUST VALVE | 24 - 74 | 5G11 | FEEDER HOUSE FRAME, TILT BEAM & CLOSURE PLATES, CONTOUR MASTER (660101-) | 110 - 24 |
| 1F3 | EXHAUST VALVE INSERT | 24 - 68 | 5H13 | FEEDER HOUSE FRONT DRIVE SHAFT, SHEAVE AND MOUNTINGS (FIXED SPEED WITH | 110 - 52 |
| 1F5 | EXHAUST VALVE INSERT | 24 - 70 | 5D3 | FEEDER HOUSE REVERSER FOOT CONTROL | 90 - 38 |
| 1F7 | EXHAUST VALVE INSERT | 24 - 72 | 5F18 | FEEDER HOUSE REVERSER FOOT CONTROL | 110 - 6 |
| 1F3 | EXHAUST VALVE ROTATOR | 24 - 68 | 5G9 | FEEDER HOUSE SHELL - CONTOUR MASTER (660101-) | 110 - 22 |
| 1F3 | EXHAUST VALVES | 24 - 68 | 5G18 | FEEDER HOUSE SLIP CLUTCH | 110 - 32 |
| 1F5 | EXHAUST VALVES | 24 - 70 | 5H11 | FEEDER HOUSE UPPER DRIVE SHAFT, SHEAVE AND MOUNTING (FIXED SPEED WITH | 110 - 50 |
| 1F7 | EXHAUST VALVES | 24 - 72 | 5G16 | FEEDER HOUSE UPPER SHAFT (-641500) | 110 - 30 |
| 3B25 | EXPORT, TRANSMISSION (-655399) | 50 - 12 | | | |
| 6G9 | EXTENDED RANGE CYLINDER DRIVE BELT | 121 - 32 | | | |
| 6G17 | EXTENDED RANGE CYLINDER DRIVE BELT | 121 - 40 | | | |
| 6E1 | EXTENSION ELEMENT, CHAFFER | 120 - 64 | | | |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE |
|------|--|----------|------|---|----------|
| 5G20 | FEEDER HOUSE UPPER SHAFT (641501-)..... | 110 - 34 | 5C3 | FRAME, CAB AND SUPPORT | 90 - 14 |
| 5G9 | FEEDER HOUSE WEAR PLATES - CONTOUR MASTER (660101-)..... | 110 - 22 | 6E3 | FRAME, CHAFFER | 120 - 66 |
| 6B14 | FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR..... | 120 - 2 | 5G7 | FRAME, FEEDER HOUSE AND FRONT SHAFT | 110 - 20 |
| 5H5 | FEEDER HOUSE, UPPER COUNTERSHAFT VARIABLE DRIVE | 110 - 44 | 5G11 | FRAME, FEEDER HOUSE, CONTOUR MASTER (660101-)..... | 110 - 24 |
| 2C21 | FIELD LIGHTING, AUXILIARY | 40 - 10 | 4F16 | FRAME, SEPARATOR..... | 80 - 2 |
| 2G19 | FIELD LIGHTS (660101-)..... | 40 - 106 | 7C19 | FRAME, SHIELDS AND HANDLES, CHAFF SPREADER (-650100)..... | 125 - 32 |
| 2C15 | FIELD LIGHTS SWITCH, AUX, OPTIONAL | 40 - 4 | 6E7 | FRAME, SIEVE | 120 - 70 |
| 2B22 | FILTER, AIR AND INTAKE TUBES - GRAIN..... | 30 - 12 | 2C20 | FRONT AND REAR TURN AND TAIL LIGHTS | 40 - 9 |
| 2B24 | FILTER, AIR AND INTAKE TUBES - GRAIN..... | 30 - 14 | 3B22 | FRONT AXLE..... | 50 - 9 |
| 5C21 | FILTER, CAB AIR | 90 - 32 | 4H3 | FRONT CORNER SHEET, R H | 80 - 38 |
| 1E11 | FILTER, ENGINE OIL | 24 - 48 | 1D12 | FRONT PLATE, ENGINE..... | 24 - 24 |
| 1E13 | FILTER, ENGINE OIL | 24 - 50 | 1D13 | FRONT PLATE, ENGINE..... | 24 - 25 |
| 1H11 | FILTER, ENGINE OIL | 24 - 129 | 1D14 | FRONT PLATE, ENGINE..... | 24 - 26 |
| 1H13 | FILTER, FUEL | 24 - 131 | 1D15 | FRONT PLATE, ENGINE..... | 24 - 27 |
| 1H14 | FILTER, FUEL | 24 - 132 | 5F20 | FRONT SHAFT WITH REVERSER (VARIABLE)..... | 110 - 8 |
| 1H16 | FILTER, FUEL | 24 - 134 | 4H11 | FRONT SHIELD ASSEMBLY, LEFT SIDE | 80 - 46 |
| 1H20 | FILTER, FUEL | 24 - 138 | 4H17 | FRONT SHIELD ASSEMBLY, RIGHT SIDE..... | 80 - 52 |
| 4B23 | FILTER, MAIN HYDRAULIC | 70 - 10 | 3G9 | FRONT STEERING HOSES AND LINES..... | 60 - 28 |
| 5E14 | FILTERS, AIR CONDITIONER AND HEATER AND HOUSING..... | 90 - 76 | 5F14 | FRONT VARIABLE DRIVE SHEAVE AND MOUNTINGS | 110 - 2 |
| 5E14 | FILTERS, HEATER AND AIR CONDITIONING AND HOUSING..... | 90 - 76 | 1H13 | FUEL FILTER..... | 24 - 131 |
| 3C10 | FINAL DRIVE (RING AND PINION) | 50 - 22 | 1H14 | FUEL FILTER..... | 24 - 132 |
| 3C12 | FINAL DRIVE AXLE, GEAR AND BEARINGS (RING AND PINION) | 50 - 25 | 1H16 | FUEL FILTER..... | 24 - 134 |
| 3C11 | FINAL DRIVE BEARINGS (RING AND PINION) | 50 - 23 | 1H20 | FUEL FILTER..... | 24 - 138 |
| 3C11 | FINAL DRIVE HOUSING AND BRG. CAP (RING AND PINION) | 50 - 23 | 1H13 | FUEL FILTER ELEMENT..... | 24 - 131 |
| 3C13 | FINAL DRIVE PINION, SHAFTS AND BEARINGS (RING AND PINION) | 50 - 26 | 1H16 | FUEL FILTER ELEMENT..... | 24 - 134 |
| 6H23 | FINE CUT STRAW CHOPPER DRIVES (FRONT) | 121 - 70 | 1H13 | FUEL FILTER FUEL LINES..... | 24 - 131 |
| 6I3 | FINE CUT STRAW CHOPPER DRIVES (REAR)..... | 121 - 74 | 1H16 | FUEL FILTER FUEL LINES..... | 24 - 134 |
| 6C16 | FINGER GRATE, SPIKE-TOOTH | 120 - 30 | 1H14 | FUEL FILTER LINES | 24 - 132 |
| 7B14 | FINS, SUPPORTS AND DECK, STRAW CHOPPER..... | 125 - 2 | 1H20 | FUEL FILTER LINES | 24 - 138 |
| 2B12 | FITTINGS, FUEL TANK..... | 30 - 2 | 2C17 | FUEL GAUGE | 40 - 6 |
| 7H5 | FITTINGS, LOWER LUBE HOSE, UNLOADING AUGER..... | 130 - 58 | 5C23 | FUEL GAUGE | 90 - 34 |
| 2B16 | FITTINGS, TANK FUEL LINES..... | 30 - 6 | 1F15 | FUEL INJECTION LINES..... | 24 - 80 |
| 4E21 | FITTINGS, TILT CYLINDER - CONTOUR MASTER | 70 - 83 | 1F17 | FUEL INJECTION LINES..... | 24 - 82 |
| 7H7 | FITTINGS, UPPER LUBE HOSE, UNLOADING AUGER..... | 130 - 60 | 1F19 | FUEL INJECTION LINES..... | 24 - 84 |
| 3G18 | FIXED REAR AXLE | 60 - 37 | 1F22 | FUEL INJECTION LINES..... | 24 - 88 |
| 3G21 | FIXED REAR AXLE STEERING TIE RODS..... | 60 - 40 | 1F24 | FUEL INJECTION LINES..... | 24 - 90 |
| 3G22 | FIXED REAR AXLE, 4-WHEEL DRIVE, STEERING TIE RODS | 60 - 41 | 1F13 | FUEL INJECTION NOZZLE..... | 24 - 78 |
| 5F24 | FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER.. | 110 - 12 | 1F14 | FUEL INJECTION NOZZLE..... | 24 - 79 |
| 5B15 | FLOOR MAT, CAB..... | 90 - 2 | 1F21 | FUEL INJECTION NOZZLE..... | 24 - 87 |
| 5G22 | FLOOR, FEEDER HOUSE | 110 - 36 | 1F15 | FUEL INJECTION PUMP..... | 24 - 80 |
| 4B19 | FLOW CONTROL VALVE, REEL DRIVE | 70 - 6 | 1F17 | FUEL INJECTION PUMP..... | 24 - 82 |
| 1118 | FLYWHEEL..... | 24 - 163 | 1F19 | FUEL INJECTION PUMP..... | 24 - 84 |
| 1118 | FLYWHEEL HOUSING | 24 - 163 | 1F22 | FUEL INJECTION PUMP..... | 24 - 88 |
| 1119 | FLYWHEEL HOUSING | 24 - 164 | 1F24 | FUEL INJECTION PUMP..... | 24 - 90 |
| 5B17 | FOAM, SEALS AND SOUND DEADENING, CAB | 90 - 4 | 1F22 | FUEL INJECTION PUMP DRIVE GEAR..... | 24 - 88 |
| 5D3 | FOOT PEDAL, FEEDER HOUSE REVERSER | 90 - 38 | 1F24 | FUEL INJECTION PUMP DRIVE GEAR..... | 24 - 90 |
| 5F18 | FOOT PEDAL, FEEDER HOUSE REVERSER | 110 - 6 | 1G3 | FUEL INJECTION PUMP ELECTRIC SHUT-OFF KIT | 24 - 94 |
| 3E17 | FOUR WHEEL DRIVE HYDRAULIC LINES AND HOS ES, L.H. (655101-)..... | 50 - 82 | 1F15 | FUEL INJECTION SYSTEM | 24 - 80 |
| 3G17 | FOUR-WHEEL DRIVE | 60 - 36 | 1F17 | FUEL INJECTION SYSTEM | 24 - 82 |
| 3D17 | FOUR-WHEEL DRIVE (-655100)..... | 50 - 56 | 1F19 | FUEL INJECTION SYSTEM | 24 - 84 |
| 6D19 | FRAME ARMS, PRECLEANER CHAFFER | 120 - 58 | 1F22 | FUEL INJECTION SYSTEM | 24 - 88 |
| | | | 1F24 | FUEL INJECTION SYSTEM | 24 - 90 |
| | | | 1H18 | FUEL LINE, FUEL TRANSFER PUMP | 24 - 136 |
| | | | 1H13 | FUEL LINES, FUEL FILTER | 24 - 131 |
| | | | 1H16 | FUEL LINES,FUEL FILTER..... | 24 - 134 |
| | | | 2B14 | FUEL PUMP, WATER SEPARATOR, AND FUEL SENDER | 30 - 4 |
| | | | 2B14 | FUEL SENDER | 30 - 4 |
| | | | 2B12 | FUEL TANK, SUPPORTS, AND FITTINGS | 30 - 2 |
| | | | 1H18 | FUEL TRANSFER PUMP | 24 - 136 |
| | | | 1H19 | FUEL TRANSFER PUMP | 24 - 137 |
| | | | 1H22 | FUEL TRANSFER PUMP | 24 - 140 |
| | | | 1H18 | FUEL TRANSFER PUMP FUEL LINE | 24 - 136 |

ALPHABETICAL INDEX - CONTINUED

| GRID | | PAGE | GRID | | PAGE | | | |
|----------|---|----------|----------|--|----------|--|--|--|
| 1H22 | FUEL TRANSFER PUMP PUSH ROD | 24 - 140 | 7G23 | GRAIN TANK CROSS AUGERS..... | 130 - 52 | | | |
| G | | | | | | | | |
| 1I20 | GASKET SET, CYLINDER HEAD REMOVAL | 24 - 165 | 2E23 | GRAIN TANK DUAL LEVEL MONITOR HARNESS..... | 40 - 62 | | | |
| 1J3 | GASKET SET, CYLINDER HEAD REMOVAL | 24 - 172 | 2E21 | GRAIN TANK LEVEL MONITOR..... | 40 - 60 | | | |
| 1I21 | GASKET SET, ENGINE OVERHAUL | 24 - 166 | 2E21 | GRAIN TANK LIGHT | 40 - 60 | | | |
| 1I23 | GASKET SET, ENGINE OVERHAUL (624E) | 24 - 168 | 2F12 | GRAIN TANK LIGHTS | 40 - 75 | | | |
| 1J1 | GASKET SET,ENGINE MAJOR OVERHAUL..... | 24 - 170 | 7F21 | GRAIN TANK TOP..... | 130 - 26 | | | |
| 1J3 | GASKET SET,IN CHASSIS OVERHAUL | 24 - 172 | 2E21 | GRAIN TANK UNLOADING AUGER LIMIT SWITCH | 40 - 60 | | | |
| 1F3 | GASKET, CYLINDER HEAD | 24 - 68 | 4E10 | GRAIN TANK UNLOADING DRIVE CYLINDER..... | 70 - 72 | | | |
| 1F5 | GASKET, CYLINDER HEAD | 24 - 70 | 4E10 | GRAIN TANK UNLOADING DRIVE CYLINDER MOUNTING | 70 - 72 | | | |
| 1F7 | GASKET, CYLINDER HEAD | 24 - 72 | 7G5 | GRAIN TANK VERTICAL UNLOADING AUGER | 130 - 34 | | | |
| 1F9 | GASKET, CYLINDER HEAD | 24 - 74 | 7G5 | GRAIN TANK VERTICAL UNLOADING AUGER HOUSING..... | 130 - 34 | | | |
| 1D6 | GASKET, TIMING GEAR COVER..... | 24 - 18 | 2E21 | GRAIN TANK WIRING HARNESS, LIGHT, LIMIT SWITCH AND LEVEL MONITOR | 40 - 60 | | | |
| 1F12 | GASKET,EXHAUST MANIFOLD | 24 - 77 | 6C4 | GRATE AND RASP BAR CONCAVE | 120 - 18 | | | |
| 1E3 | GASKET,PLASTIC | 24 - 40 | 6C6 | GRATE AND RASP BAR CONCAVE | 120 - 20 | | | |
| 1D4 | GASKET,ROCKER ARM COVER | 24 - 16 | 6C3 | GRATE, BEATER CURTAIN (650437-) | 120 - 16 | | | |
| 2C13 | GAUGE BOARD CONN. (WIRING HARNESS)..... | 40 - 2 | 6C16 | GRATE, FINGER, SPIKE-TOOTH..... | 120 - 30 | | | |
| 2C17 | GAUGE, ENGINE TEMPERATURE | 40 - 6 | 7C11 | GUARD AND STRAW SPREADER MOUNTING | 125 - 24 | | | |
| 5C23 | GAUGE, ENGINE TEMPERATURE | 90 - 34 | 7H3 | GUIDE, DRIVE BELT, UNLOADING AUGER..... | 130 - 56 | | | |
| 5F16 | GEAR BOX, REVERSER..... | 110 - 4 | 5H1 | GUIDES, TIGHTENER AND FEEDER CONVEYOR DRIVE CHAIN | 110 - 40 | | | |
| 6G9 | GEAR CASE, DUAL-RANGE CYLINDER DRIVE..... | 121 - 32 | 5H19 | GUIDES, TIGHTENER AND FEEDER CONVEYOR DRIVE CHAIN-RETROFIT INSTALLATION | 110 - 58 | | | |
| 7G3 | GEAR CASE, VERTICAL AUGER LOWER | 130 - 32 | H | | | | | |
| 1C23 | GEAR, CAMSHAFT | 24 - 10 | 5C19 | HAND RAIL, R.H..... | 90 - 30 | | | |
| 1C24 | GEAR, CAMSHAFT | 24 - 11 | 5B23 | HANDLE, CAB DOOR | 90 - 10 | | | |
| 1C19 | GEAR, CRANKSHAFT..... | 24 - 6 | 6C23 | HANDLE, LATCHES AND CONVEYOR AUGER CLEANOUT DOOR | 120 - 37 | | | |
| 1C22 | GEAR, CRANKSHAFT REPLACEMENT (6359)..... | 24 - 9 | 7C21 | HANDLES AND SHIELDS, CHAFF SPREADER (DUAL MOTOR) (650101-) | 125 - 34 | | | |
| 1E20 | GEAR, ENGINE OIL PUMP..... | 24 - 59 | 5C7 | HANDRAIL, OPERATOR'S PIVOTING PLATFORM | 90 - 18 | | | |
| 3C12 | GEAR, FINAL DRIVE (RING AND PINION) | 50 - 25 | 4F20 | HANDRAILS, REAR LADDER LANDING | 80 - 6 | | | |
| 1F22 | GEAR, FUEL INJECTION PUMP DRIVE | 24 - 88 | 5F10 | HARDWARE KIT, CAB | 90 - 98 | | | |
| 1F24 | GEAR, FUEL INJECTION PUMP DRIVE | 24 - 90 | 5F1 | HARDWARE KIT, COMPRESSOR (-650100) R-12 | 90 - 88 | | | |
| 6G23 | GEARCASE DRIVE, STRAW WALKER | 121 - 46 | 5F6 | HARDWARE KIT, COMPRESSOR (650101-) R134A..... | 90 - 94 | | | |
| 7F13 | GEARCASE, CLEAN GRAIN ELEVATOR | 130 - 18 | 2G9 | HARNESS CONNECTORS, LOWER, FOR 6359 ENGINE | 40 - 96 | | | |
| 6F16 | GEARCASE, DRIVE SHAFT AND PRIMARY COUNTERSHAFT | 121 - 14 | 2G11 | HARNESS CONNECTORS, UPPER, FOR 6359 ENGINE | 40 - 98 | | | |
| 6F8 | GEARCASE, ENGINE | 121 - 6 | 2E5 | HARNESS FOR REAR LIGHTS AND SHIELDS | 40 - 44 | | | |
| 6F10 | GEARCASE, ENGINE | 121 - 8 | 2E3 | HARNESS WIRING, MAIN, L.H. CENTER | 40 - 42 | | | |
| 6F14 | GEARCASE, ENGINE | 121 - 12 | 2E19 | HARNESS, LOWER, ENGINE, 6068 LOWER PARTS..... | 40 - 58 | | | |
| 6F12 | GEARCASE, ENGINE (SEPARATOR AND PUMP DRIVE) | 121 - 10 | 2E19 | HARNESS, LOWER, ENGINE, 6359 LOWER PARTS..... | 40 - 58 | | | |
| 4F5 | GEARCASE, ENGINE, OIL FILTER ASSEMBLY..... | 70 - 92 | 2E17 | HARNESS, UPPER ENGINE, 6068 UPPER PARTS | 40 - 56 | | | |
| 7G13 | GEARCASE, HORIZONTAL UNLOADING AUGER DRIVE | 130 - 42 | 2E17 | HARNESS, UPPER, ENGINE, 6359 UPPER PARTS | 40 - 56 | | | |
| 6F22 | GEARCASE, PRIMARY COUNTERSHAFT (-640100) | 121 - 20 | 2D11 | HARNESS, WIRING, A/C, HEATER AND AIRSEAT (660101-) | 40 - 24 | | | |
| 6F18 | GEARCASE, PRIMARY COUNTERSHAFT (-640100)..... | 121 - 16 | 2D24 | HARNESS, WIRING, MAIN, L.H. FRONT..... | 40 - 38 | | | |
| 6F24 | GEARCASE, PRIMARY COUNTERSHAFT (640101-) | 121 - 22 | 2E7 | HARNESS, WIRING, R.H. MAIN..... | 40 - 46 | | | |
| 6F20 | GEARCASE, PRIMARY COUNTERSHAFT (640101-)..... | 121 - 18 | 2D5 | HARNESS, WIRING, STEERING COLUMN (-645340)..... | 40 - 18 | | | |
| 6H1 | GEARCASE, STRAW WALKER DRIVE | 121 - 48 | 2D7 | HARNESS, WIRING, STEERING COLUMN (646237-) | 40 - 20 | | | |
| 3C8 | GEARS, DIFFERENTIAL | 50 - 20 | 2C17 | HARVESTRAK | 40 - 6 | | | |
| 1C16 | GEARS, IDLER | 24 - 3 | 5C23 | HARVESTRAK | 90 - 34 | | | |
| 3C4 | GEARS, TRANSMISSION | 50 - 16 | | | | | | |
| 3C6 | GEARS, TRANSMISSION PINION | 50 - 18 | | | | | | |
| 3C2 | GEARSHIFT LEVER AND LINKAGE | 50 - 14 | | | | | | |
| 5D1 | GEARSHIFT LEVER AND LINKAGE | 90 - 36 | | | | | | |
| 5C1 | GLASS, CAB AND DOOR..... | 90 - 12 | | | | | | |
| 5E1 | GLOVE BOX AND ARM REST, R.H. | 90 - 62 | | | | | | |
| 6D17 | GRAIN LEAK KIT..... | 120 - 56 | | | | | | |
| 7G1 | GRAIN TANK AND CURTAINS..... | 130 - 30 | | | | | | |
| 7F23 | GRAIN TANK BASE..... | 130 - 28 | | | | | | |