

H51903

-UN-04FEB99



JOHN DEERE 9650 SELF-PROPELLED COMBINE™ WITH 90 SERIES CORN HEAD

MANUFACTURED (1999-)

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS, USA. ALL RIGHTS RESERVED.

NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2404.

FOR 900R & F SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2771.

FOR 914P BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2772.

IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9650 SELF-PROPELLED COMBINE. VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION NUMBER (PIN) PLATE IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX. AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9650X685000
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9650 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

900000 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE

RGP5229

-UN-21JUN99



RGP5229

FIRST LINE

RG - WATERLOO ENGINE WORKS

6

081 (8.1 LITERS)

H - AIR-TO-AIR

H

XXXXXX

SECOND LINE

6081HH010

DEFINES

DESIGNATES ENGINE MANUFACTURER.

DESIGNATES NUMBER OF CYLINDERS.

DESIGNATES LITER DISPLACEMENT.

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

DESIGNATES HARVESTER VEHICLE.


DESIGNATES ENGINE SERIAL NUMBER.

APPLICATION

9650

SHORT BLOCK SERIAL NUMBER IDENTIFICATION

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490995

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED | 09 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES THE PART MAY BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™
DIAL-A-MATIC™
HARVESTRAK™
CONTOUR MASTER™

POSI-TORQ™
TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE ACCESSORIES

SECTION 25 - ENGINE

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - BODY AND SHIELDS

SECTION 90 - OPERATOR'S STATION

SECTION 95 - AIR CONDITIONING AND HEATING

SECTION 100 - FEEDER HOUSE

SECTION 110 - THRESHING AND SEPARATION

SECTION 120 - CLEANING SHOE

SECTION 125 - ELEVATORS

SECTION 130 - RESIDUE DISPOSAL

SECTION 140 - DRIVES

SECTION 150 - GRAIN TANK AND UNLOADING AUGER

SECTION 155 - GREENSTAR YIELD MAPPING AND MONITOR SYSTEMS

SECTION 160 - RUBBER TRACK SYSTEM

SECTION 170 - DECALS

SECTION 180 - NUMERICAL INDEX

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
	A				
1H5	ACCESS COVER FUEL INJECTION PUMP	40 - 58	3B23	ARMREST ROCKER SWITCHES	90 - 24
1B10	ACCESS DOOR, RADIATOR	20 - 8	3C1	ARMREST ROCKER SWITCHES	90 - 26
2G11	ACCUMULATOR AND MOUNTING, ONE GALLON	70 - 34	1G5	ARMREST WIRING HARNESS	40 - 32
2G13	ACCUMULATOR PRESSURE GAUGE	70 - 36	3B12	ASHTRAY	90 - 12
2G9	ACCUMULATOR, SINGLE MOUNTING BRACKET ONE HALF GALLON	70 - 32	3B23	ASHTRAY	90 - 24
2G9	ACCUMULATOR, SINGLE, ONE HALF GALLON	70 - 32	1H7	ASSEMBLY, CLUTCH (STARTER)	40 - 60
2F24	ACTIVE HEADER HEIGHT CONTROL HYDRAULIC LINE AND VALVE BLOCK	70 - 22	2E9	ATTENUATOR, HYDRAULIC STEERING	60 - 16
1H19	ACTUATOR, STRAW WALKER SENSOR SWITCH	40 - 73	4E17	AUGER COVERS AND CHANNEL, CROSS	150 - 34
1D8	ADAPTER, OIL COOLER	25 - 28	4D3	AUGER DRIVE SHIELD, UPPER TAILINGS	140 - 54
1D7	ADAPTER, OIL COOLER BYPASS	25 - 27	4D3	AUGER DRIVE, UPPER TAILINGS	140 - 54
4F22	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM ..	160 - 6	3I9	AUGER HOUSING, LOADING, UPPER CLEAN GRAIN	125 - 8
2B6	ADJUSTABLE REAR AXLE	50 - 3	4D22	AUGER SWING, HOSES AND LINES	150 - 14
2E24	ADJUSTABLE REAR AXLE STEERING TIE RODS	60 - 32	4E3	AUGER SWIVEL SUPPORT AND BRACES	150 - 20
4C5	ADJUSTING BRACKET, CYLINDER DRIVE, DUAL-RANGE	140 - 32	3I9	AUGER TROUGH, LOWER TAILINGS	125 - 18
1H13	ADJUSTING MOTOR, CONCAVE	40 - 66	4E15	AUGER, GRAIN TANK CROSS	150 - 32
1H18	ADJUSTING MOTOR, SEPARATOR FAN DRIVE	40 - 72	4D20	AUGER, GRAIN TANK, VERTICAL UNLOADING	150 - 12
1E19	AIR CLEANER AND INTAKE TUBES	30 - 18	4E1	AUGER, HORIZONTAL UNLOADING	150 - 18
3D11	AIR CONDITIONER COMPRESSOR	95 - 11	4E11	AUGER, HORIZONTAL UNLOADING (17- AND 20-FT.)	150 - 28
1B20	AIR CONDITIONER COMPRESSOR FAN PULLEY	20 - 18	3I11	AUGER, LOADING, CLEAN GRAIN	125 - 10
3D14	AIR CONDITIONER COMPRESSOR HARDWARE	95 - 14	3J1	AUGER, LOWER TAILINGS	125 - 24
3D12	AIR CONDITIONER COMPRESSOR HOSE	95 - 12	3J3	AUGER, LOWER TAILINGS DRIVE TIGHTENER	125 - 26
3D11	AIR CONDITIONER COMPRESSOR MANIFOLD	95 - 11	3I5	AUGER, LOWER, CLEAN GRAIN	125 - 4
1B20	AIR CONDITIONER COMPRESSOR SUPPORT	20 - 18	3G23	AUGER, SHOE GRAIN SUPPLY	120 - 2
3D7	AIR CONDITIONING AND HEATER DUCTS	95 - 7	4D3	AUGER, UPPER TAILINGS	140 - 54
3D4	AIR CONDITIONING AND HEATER HOUSING, LOWER	95 - 4	2B7	AXLE EXTENSIONS	50 - 4
3D2	AIR CONDITIONING AND HEATER HOUSING, UPPER	95 - 2	2B7	AXLE SHAFTS	50 - 4
2F11	AIR CONDITIONING CONDENSER AND OIL COOLER	70 - 8	2B7	AXLE SPACERS	50 - 4
3D10	AIR CONDITIONING SYSTEM, EVAPORATOR HEATER	95 - 10	2B8	AXLE SPACERS	50 - 5
3D9	AIR CONDITIONING SYSTEM, RECEIVER-DRYER	95 - 9	4H13	AXLE STOP AND TIRE CLEARANCE LABEL	170 - 20
3D8	AIR CONDITIONING SYSTEM, WATER VALVE	95 - 8	4G4	AXLE, BOGEY WHEEL	160 - 14
1G9	AIR CONDITIONING WIRING HARNESS	40 - 36	4G1	AXLE, IDLER	160 - 10
1C1	AIR COOLER	20 - 24	2B6	AXLE, REAR, ADJUSTABLE	50 - 3
3D7	AIR DUCT, AIR CONDITIONER AND HEATER	95 - 7	2E22	AXLE, REAR, SPINDLES (HEAVY DUTY)	60 - 30
3H1	AIR DUCT, CLEANING FANS	120 - 4	2E20	AXLE, REAR, SPINDLES (REGULAR DUTY)	60 - 28
3D2	AIR DUCT, INTAKE	95 - 2			
1B8	AIR DUCT, RADIATOR	20 - 6		B	
1B6	AIR DUCT, ROTARY SCREEN	20 - 4	1H9	BACKSHAFT SPEED SENSOR, FEEDER HOUSE	40 - 62
1E19	AIR FILTER	30 - 18	3G5	BAR, SPIKE TOOTH THRESHING CYLINDER	110 - 12
3D6	AIR FILTER, CAB	95 - 6	4D12	BASE, GRAIN TANK	150 - 4
3B18	AIR SEAT SUSPENSION	90 - 18	1H22	BATTERY AND CABLES	40 - 76
3B20	AIR SEAT SWITCH	90 - 20	3G17	BEARING KIT, STRAW WALKERS	110 - 24
4F24	AIR SUSPENSION	160 - 8	1C18	BEARING KIT, UNDERSIZED MAIN BEARING CRANKSHAFT	25 - 11
3B18	AIR SUSPENSION, SEAT	90 - 18	4G6	BEARING, BOGEY WHEEL	160 - 16
1H5	ALTERNATOR ADJUSTING STRAP	40 - 58	4G4	BEARING, BOGEY WHEEL AXLE	160 - 14
1H5	ALTERNATOR BRACKET	40 - 58	2C15	BEARING, CAM LOBE MOTOR	50 - 40
1H3	ALTERNATOR, SHEAVE AND BELT (185 AMP)	40 - 56	1C15	BEARING, CONNECTING ROD	25 - 8
1H1	ALTERNATOR, SHEAVE AND BELT (95 AMP)	40 - 54	2C1	BEARING, FINAL DRIVE	50 - 24
1I1	AMBER LAMP ASSEMBLY, REAR	40 - 80	1B4	BEARING, IDLER ARM, ROTARY SCREEN	20 - 2
3C15	ANTENNA, SPEAKERS AND RADIO	90 - 40	4G3	BEARING, IDLER WHEEL	160 - 12
3B20	ARM REST, OPERATOR'S SEAT	90 - 20	1C19	BEARING, MAIN	25 - 12
4B23	ARM, DUAL RANGE LOCKOUT	140 - 25	3I24	BEARING, TAILINGS ELEVATOR CONVEYOR	125 - 23
3H7	ARM, FRAME, PRECLEANER CHAFFER	120 - 10	1C19	BEARING, THRUST	25 - 12
4F22	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY ..	160 - 6	2B18	BEARING, TRANSMISSION	50 - 16
4G1	ARM, REAR	160 - 10	2B20	BEARING, TRANSMISSION PINION SHAFT	50 - 18
1D1	ARM, ROCKER	25 - 20	4C13	BEATER DRIVE SHEAVES AND TIGHTENER	140 - 40
3J23	ARM, TAILBOARD, CHOP-TO-BALE	130 - 16	3G7	BEATER GRATE (WIDE)	110 - 14
3B23	ARMREST PANEL, OPERATOR'S	90 - 24	3G12	BEATER GRATE CURTAIN	110 - 19
3C1	ARMREST PANEL, OPERATOR'S	90 - 26	3G13	BEATER, SHAFT AND DRIVE BELT	110 - 20
			4G13	BELT AND DRIVE WHEEL	160 - 24
			4E22	BELT GUIDE, UNLOADING AUGER DRIVE	150 - 40
			2G19	BELT PICKUP / REEL DRIVE, PUMP MOUNTING SHEAVE	70 - 42

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3G13	BELT SET, BEATER SHAFT.....	110-20	3F6	BELT, UPPER VARIABLE DRIVE COUNTERSHAFT	100-40
1H5	BELT TENSIONER, ALTERNATOR	40-58	3D18	BELT, VARIABLE SPEED FEEDERHOUSE.....	100-2
4H23	BELT, AIR CONDITIONING COMPRESSOR.....	170-30	4I1	BELT, VARIABLE SPEED FEEDERHOUSE.....	170-32
4I1	BELT, AIR FLOW DRIVE	170-32	4I1	BELT, VARIABLE SPEED FEEDERHOUSE (HI-CAPACITY)	170-32
1H3	BELT, ALTERNATOR (185 AMP)	40-56	3E5	BELT, VARIABLE SPEED TIGHTENER DRIVE.....	100-14
4H21	BELT, ALTERNATOR (185 AMP)	170-28	2G3	BI-DIRECTIONAL MODULE, SOLENOID CONTROL VALVE, REEL LIFT AND CYLINDER SPEED	70-26
1H1	BELT, ALTERNATOR (95 AMP)	40-54	3G13	BLADE, BEATER	110-20
4H21	BELT, ALTERNATOR (95 AMP)	170-28	3J16	BLADE, FINE CUT CHOPPER - PADDLED.....	130-8
4I3	BELT, BEATER	170-34	3J14	BLADE, FINE CUT ROTOR CHOPPER	130-6
4C13	BELT, BEATER DRIVE AND TIGHTENER.....	140-40	3J12	BLADE, TRI-ROD CHOPPER	130-4
4C21	BELT, CHOPPER DRIVES (FRONT)	140-48	1G13	BLADE, WIPER	40-40
4H23	BELT, CLEAN GRAIN ELEVATOR	170-30	1B22	BLOCK, ENGINE COOLANT HEATER.....	20-20
4D6	BELT, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER.....	140-58	1C11	BLOCK, SHORT.....	25-4
4C15	BELT, CLEANING FAN (490 - 980 RPM)	140-42	4G6	BOGEY WHEEL ASSEMBLY	160-16
4I1	BELT, CLEANING FAN (490 - 980 RPM)	170-32	4G4	BOGEY WHEEL AXLES	160-14
4C15	BELT, CLEANING FAN (750 - 1350 RPM)	140-42	4G7	BOX, GEAR, TRANSFER	160-18
4I1	BELT, CLEANING FAN (750 - 1350 RPM)	170-32	2J16	BOX, TOOL	80-40
1B16	BELT, COOLING FAN	20-14	1H5	BRACKET, ALTERNATOR	40-58
4H23	BELT, COOLING FAN	170-30	2E4	BRACKET, BRAKE CABLE SUPPORT	60-11
4B21	BELT, CYLINDER DRIVE (150 - 500 RPM)	140-22	3J23	BRACKET, CHOP-TO-BALE	130-16
4H23	BELT, CYLINDER DRIVE (150 - 500 RPM)	170-30	4F4	BRACKET, DISPLAY, YIELD MAPPING.....	155-4
4B21	BELT, CYLINDER DRIVE (240 - 960 RPM).....	140-22	1H21	BRACKET, LOW SHAFT SPEED SENSORS.....	40-75
4H23	BELT, CYLINDER DRIVE (240 - 960 RPM).....	170-30	4F6	BRACKET, MASS FLOW SENSOR YIELD MAPPING	155-6
4H23	BELT, CYLINDER INTERMEDIATE DRIVE	170-30	4F8	BRACKET, MOISTURE SENSOR, YIELD MAPPING	155-8
4C3	BELT, DUAL RANGE CYLINDER DRIVE, INTERMEDIATE SHEAVE.....	140-30	4F2	BRACKET, POSITION RECEIVER YIELD MAPPING	155-2
4B17	BELT, ELECTROMAGNETIC CLUTCH.....	140-17	1B10	BRACKET, RADITOR MOUNTING	20-8
1B14	BELT, ENGINE FAN DRIVE	20-12	2G9	BRACKET, SINGLE ACCUMULATOR MOUNTING ONE HALF GALLON	70-32
4H21	BELT, FEEDER CONVEYOR	170-28	2F15	BRACKET, SOLENOID CONTROL VALVE	70-12
3E7	BELT, FEEDER HOUSE DRIVE TIGHTENER	100-16	4F6	BRACKET, TRANSDUCER MOUNTING YIELD MAPPING	155-6
3E3	BELT, FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED).....	100-12	2E4	BRAKE CABLE SUPPORT BRACKET	60-11
4I1	BELT, FIXED SPEED FEEDERHOUSE W/REVERSER	170-32	2E1	BRAKE CYLINDER, MASTER.....	60-8
3D18	BELT, HEADER AND REEL PUMP	100-2	2D23	BRAKE LINES, MASTER CYLINDER AND RESERVOIR	60-6
4I1	BELT, HEADER AND REEL PUMP	170-32	2D19	BRAKE PEDAL AND SEAL, PARKING	60-2
3J1	BELT, LOWER TAILINGS AUGER	125-24	2D21	BRAKE PEDALS AND MASTER CYLINDER	60-4
4H23	BELT, LOWER TAILINGS AUGER AND ELEVATOR	170-30	2E5	BRAKE SHOES AND DRUM.....	60-12
3B22	BELT, OPERATOR'S SEAT	90-23	4G11	BRAKE SHOES AND DRUM.....	160-22
4H23	BELT, ROTARY SCREEN.....	170-30	2E3	BRAKE SLAVE CYLINDER.....	60-10
1B4	BELT, ROTARY SCREEN DRIVE.....	20-2	2G13	BULB, ACCUMULATOR PRESSURE GAUGE.....	70-36
4H23	BELT, ROTARY SCREEN DRIVE.....	170-30	1H23	BULB, CAB ROOF LIGHT.....	40-77
4B18	BELT, SECONDARY COUNTERSHAFT.....	140-18	2J10	BULB, ENGINE COMPARTMENT.....	80-34
4H21	BELT, SECONDARY COUNTERSHAFT.....	170-28	3C13	BULB, OVERHEAD CONSOLE	90-38
4C7	BELT, SECONDARY COUNTERSHAFT DRIVE	140-34	3C5	BULB, STEERING COLUMN CONTROLS	90-30
4C15	BELT, SEPARATOR FAN DRIVE	140-42	1C9	BUSHING, CAMSHAFT	25-2
4H21	BELT, SHOE, WALKER AND CONVEYOR AUGERS	170-28	1C23	BUSHING, CAMSHAFT	25-16
4B20	BELT, SINGLE RANGE CYLINDER DRIVE	140-21	4F20	BUSHING, MAIN FRAME PIVOT	160-4
4C23	BELT, STRAW CHOPPER (FINE CUT BALING).....	140-50	1D7	BYPASS TUBES, OIL COOLER	25-27
4I1	BELT, STRAW CHOPPER (FINE CUT BALING).....	170-32	1D9	BYPASS VALVE, OIL FILTER.....	25-30
4C23	BELT, STRAW CHOPPER (FINE CUT)	140-50			
4I1	BELT, STRAW CHOPPER (FINE CUT)	170-32		C	
4C23	BELT, STRAW CHOPPER (STANDARD BALING)	140-50	3D6	CAB AIR FILTER AND HOUSING	95-6
4I1	BELT, STRAW CHOPPER (STANDARD BALING)	170-32	3B12	CAB DOOR AND GLASS	90-12
4C23	BELT, STRAW CHOPPER (STANDARD).....	140-50	3B14	CAB DOOR LATCH	90-14
4I1	BELT, STRAW CHOPPER (STANDARD).....	170-32	3B8	CAB INTERIOR TRIM PANELS	90-8
3K4	BELT, STRAW SPREADER	130-22	3C20	CAB LANDING AND MIRROR (L.H.)	90-46
4I1	BELT, STRAW SPREADER	170-32	3C22	CAB LANDING AND MIRROR (R.H.)	90-48
3G19	BELT, STRAW WALKER.....	110-26	1G3	CAB MAIN WIRING HARNESS.....	40-30
4C11	BELT, STRAW WALKER, CONVEYOR AUGERS, SIEVE AND CHAFFER DRIVE	140-38	3B20	CAB OPERATOR'S SEAT AND BACKREST	90-20
4E20	BELT, UNLOADING AUGER COUNTERSHAFT	150-38	3B6	CAB REAR AND SIDE SEALS	90-6
4I1	BELT, UNLOADING AUGERS.....	170-32			
4I3	BELT, UNLOADING SYSTEM.....	170-34			
3F14	BELT, UPPER DRIVE SHAFT (FIXED SPEED WITH REVERSER).....	100-48			
3I23	BELT, UPPER TAILINGS AUGER	125-22			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3B6	CAB REAR, SIDE AND FLOOR PANELS	90 - 6	3K1	CHOPPER COVER AND BRACKETS, CHOP-TO-BALE	130 - 19
3B10	CAB ROOF	90 - 10	3J9	CHOPPER DOOR	130 - 1
1H23	CAB ROOF LIGHTS	40 - 77	4C21	CHOPPER DRIVES (FRONT)	140 - 48
3B3	CAB SUPPORT	90 - 2	3J18	CHOPPER HOUSING AND KNIFEBANK	130 - 10
1H22	CABLE, BATTERY	40 - 76	3J16	CHOPPER ROTOR, FINE CUT PADDLED BLADE	130 - 8
2E5	CABLE, BRAKE	60 - 12	3J20	CHOPPER TRANSPORT SPROCKETS	130 - 12
4F14	CABLE, DATASTORE/COMPUTER	155 - 14	3J14	CHOPPER, FINE CUT STRAIGHT BLADE	130 - 6
2C3	CABLE, HYDROSTATIC DRIVE CONTROL	50 - 26	3J12	CHOPPER, TRI-ROD	130 - 4
2C15	CAM LOBE MOTOR	50 - 40	3B23	CIGARETTE LIGHTER	90 - 24
2C19	CAM, CARRIER AND PISTON	50 - 44	3B23	CIRCUIT BOARD, ARMREST CONTROL PANEL	90 - 24
3G9	CAM, SPIKE TOOTH CONCAVE	110 - 16	1G20	CIRCUIT BOARD, CENTRAL ELECTRONICS	40 - 48
2B17	CAM, TRANSMISSION SHIFTER	50 - 14	3C13	CIRCUIT BOARD, OVERHEAD CONSOLE	90 - 38
1C23	CAMSHAFT	25 - 16	1G22	CIRCUIT BREAKER AND RELAY PANEL	40 - 50
1C9	CAMSHAFT BUSHING	25 - 2	3I7	CLEAN GRAIN CONVEYOR CHAIN	125 - 6
1D1	CAMSHAFT FOLLOWERS	25 - 20	4D6	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER	140 - 58
1C23	CAMSHAFT GEAR AND FOLLOWER	25 - 16	3I13	CLEAN GRAIN ELEVATOR GEARCASE	125 - 12
1E21	CAP, EXHAUST PIPE	30 - 20	3I3	CLEAN GRAIN ELEVATOR UPPER SHAFT	125 - 2
4D18	CAP, GRAIN TANK CLEAN OUT CHUTE	150 - 10	3I11	CLEAN GRAIN LOADING AUGER	125 - 10
1C9	CAP, MAIN BEARING	25 - 2	3I9	CLEAN GRAIN LOADING AUGER HOUSING, UPPER	125 - 8
1B12	CAP, RADIATOR	20 - 10	3I5	CLEAN GRAIN LOWER AUGER AND HINGED DOOR	125 - 4
1G11	CAP, WINDSHIELD SIPER RESERVOIR	40 - 38	3I7	CLEAN GRAIN LOWER ELEVATOR	125 - 6
2C20	CAP, YOKE AND PIVOTS (STEERABLE MOTOR)	50 - 46	4D18	CLEAN OUT CHUTE, GRAIN TANK	150 - 10
2C19	CARRIER, PISTON AND CAM	50 - 44	1E19	CLEANER, AIR AND INTAKE TUBES	30 - 18
2D13	CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES	50 - 64	4C15	CLEANING FAN DRIVE, SEPARATOR	140 - 42
4G7	CASE, GEAR, TRANSFER	160 - 18	3H1	CLEANING FAN INTAKE SHIELDS	120 - 4
4D18	CASE, VERTICAL AUGER LOWER GEAR	150 - 10	3H1	CLEANING FANS AND SHROUDS	120 - 4
2J4	CATCH, REAR LANDING LADDER	80 - 28	1I5	CLEANING SHOE INSPECTION LIGHT	40 - 84
1G20	CENTRAL ELECTRONICS MODULE AND CIRCUIT BOARDS	40 - 48	3G22	CLEANOUT DOOR, SUPPLY AUGER	120 - 1
2H16	CHAFF SPREADER CONTROL, CHECK VALVE, ROD AND KNOB	70 - 64	1H7	CLUTCH ASSEMBLY (STARTER)	40 - 60
3K8	CHAFF SPREADER DISC	130 - 26	3D13	CLUTCH, COMPRESSOR	95 - 13
2H18	CHAFF SPREADER LINES AND FITTINGS	70 - 66	3E19	CLUTCH, FEEDER HOUSE SHAFT	100 - 28
3K14	CHAFF SPREADER MOUNTING SUPPORT	130 - 32	4B17	CLUTCH, HEADER ELECTROMAGNETIC	140 - 17
2G17	CHAFF SPREADER PUMP	70 - 40	3C5	COLD WEATHER START BUTTON	90 - 30
3K10	CHAFF SPREADER SHIELDS AND HANDLES	130 - 28	1E13	COLD WEATHER STARTING AID	30 - 12
2H22	CHAFF SPREADER, HOSES, LINES (DUAL MOTOR)	70 - 70	3B12	COMPLETE CAB	90 - 12
2H20	CHAFF SPREADER, LINES, HOSES, VALVE AND PUMP	70 - 68	3D15	COMPRESSOR PARTS (650301-)	95 - 15
3K12	CHAFF SPREADER, PAN AND SEALS	130 - 30	3D11	COMPRESSOR, AIR CONDITIONING	95 - 11
3H9	CHAFFER ELEMENT	120 - 12	3D13	COMPRESSOR, CLUTCH	95 - 13
3H11	CHAFFER EXTENSION ELEMENT	120 - 14	1H13	CONCAVE ADJUSTING MOTOR	40 - 66
3H13	CHAFFER FRAME	120 - 16	1H14	CONCAVE INDICATOR	40 - 68
3H7	CHAFFER FRAME ARMS, PRECLEANER	120 - 10	3G7	CONCAVE, SPIKE-TOOTH	110 - 14
3H5	CHAFFER FRAME, PRE-CLEANER	120 - 8	3G9	CONCAVE, SPIKE-TOOTH	110 - 16
3H3	CHAFFER, PRECLEANING	120 - 6	2F11	CONDENSER, AIR CONDITIONING	70 - 8
1E15	CHAIN LINK, FUEL TANK	30 - 14	1C15	CONNECTING ROD	25 - 8
4D5	CHAIN TIGHTENER, UPPER TAILINGS DRIVE	140 - 57	1C15	CONNECTING ROD BEARINGS	25 - 8
3C1	CHAIN, ARMREST CONTROL PANEL	90 - 26	1F4	CONNECTOR, ELECTRICAL, WEATHERPACK	40 - 2
3C17	CHAIN, CAB PLATFORM SAFETY	90 - 42	1C4	CONNECTOR, ENGINE HEATER HOSE	20 - 27
3I7	CHAIN, CONVEYOR, CLEAN GRAIN LOWER ELEVATOR	125 - 6	1E7	CONNECTOR, FUEL INJECTION PUMP HOUSING	30 - 6
3F3	CHAIN, FEEDER CONVEYOR	100 - 36	1F12	CONNECTOR, SUPPLEMENTARY TERMINALS	40 - 10
3E23	CHAIN, FEEDER CONVEYOR IDLER	100 - 32	3C13	CONSOLE, OVERHEAD	90 - 38
3J1	CHAIN, LOWER TAILINGS AUGER	125 - 24	3B8	CONTAINER, TRASH	90 - 8
4I3	CHAIN, LOWER TAILINGS AUGER	170 - 34	2H11	CONTOUR MASTER HYDRAULIC HOSES, L.H.	70 - 58
3E23	CHAIN, ROLLER, FEEDER CONVEYOR	100 - 32	2F22	CONTOUR MASTER SOLENOID RELIEF VALVE	70 - 20
3C17	CHAIN, SAFETY, CAB PLATFORM	90 - 42	2H14	CONTOUR MASTER TILT CYLINDER	70 - 61
3I24	CHAIN, TAILINGS ELEVATOR CONVEYOR	125 - 23	2H15	CONTOUR MASTER TILT CYLINDER HOSES	70 - 63
4I3	CHAIN, UPPER TAILINGS AUGER	170 - 34	3E17	CONTOUR MASTER, FEEDER HOUSE SHELL, WEAR PLATES AND SEALS	100 - 26
4E17	CHANNEL, CROSS AUGER	150 - 34	2C3	CONTROL CABLES, HYDROSTATIC DRIVE	50 - 26
4D20	CHARGE HOUSING, VERTICAL UNLOADING AUGER	150 - 12	3B23	CONTROL PANEL, OPERATOR'S ARMREST	90 - 24
2C9	CHARGE PUMP, HYDROSTATIC	50 - 32	3C1	CONTROL PANEL, OPERATOR'S ARMREST	90 - 26
2H16	CHECK VALVE, CHAFF SPREADER CONTROL	70 - 64	1E5	CONTROL UNIT, ELECTRONIC	30 - 4
3J25	CHOP-TO-BALE DECLUTCHING LEVER	130 - 18	1G24	CONTROL UNIT, ELECTRONIC (ECU)	40 - 52
			2C23	CONTROL VALVE	50 - 50
			2F16	CONTROL VALVE MODULE, 6-STACK SOLENOID	70 - 14
			2C24	CONTROL VALVE SOLENOID	50 - 51
			2C10	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT	50 - 34

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G5	CONTROL VALVE, SOLENOID, AUGER SWING	70 - 28	4C3	CYLINDER DRIVE INTERMEDIATE SHEAVE, DUAL-RANGE	140 - 30
2G5	CONTROL VALVE, SOLENOID, REEL FORE/AFT	70 - 28	4B24	CYLINDER DRIVE TIGHTENER, DUAL-RANGE	140 - 26
1E5	CONTROLLER, ENGINE	30 - 4	1C24	CYLINDER HEAD	25 - 18
1F13	CONVENIENCE OUTLET,KIT	40 - 12	1C24	CYLINDER HEAD GASKET	25 - 18
4C11	CONVEYOR AUGERS, STRAW WALKER, SIEVE AND CHAFFER DRIVE	140 - 38	1D22	CYLINDER HEAD GASKET KIT	25 - 46
3I7	CONVEYOR CHAIN, CLEAN GRAIN	125 - 6	1C15	CYLINDER LINER O-RING KIT	25 - 8
3E23	CONVEYOR, LEVEL LAND IDLER	100 - 32	3G1	CYLINDER SHEAR BAR, SEPARATOR.....	110 - 8
1B22	COOLANT HEATER, ENGINE BLOCK.....	20 - 20	2G15	CYLINDER SPEED HYDRAULIC HOSES	70 - 38
1B12	COOLANT RECOVERY TANK	20 - 10	2G3	CYLINDER SPEED, SOLENOID CONTROL VALVE	70 - 26
1D8	COOLER, ENGINE OIL	25 - 28	3G5	CYLINDER THRESHING, SPIKE TOOTH	110 - 12
3D20	COOLER, OIL, FEEDER HOUSE GEARCASE	100 - 4	2D21	CYLINDER, BRAKE PEDAL	60 - 4
3J22	CORN DEFLECTOR	130 - 15	2E3	CYLINDER, BRAKE SLAVE	60 - 10
2I19	CORNER PANEL, REAR, L.H.	80 - 18	2D23	CYLINDER, BRAKE, MASTER	60 - 6
3C11	CORNERPOST DISPLAY PANEL, R.H.	90 - 36	2E1	CYLINDER, BRAKE, MASTER	60 - 8
4C7	COUNTERSHAFT DRIVE, SECONDARY.....	140 - 34	4E18	CYLINDER, GRAIN TANK UNLOADING DRIVE	150 - 36
4E20	COUNTERSHAFT DRIVE, UNLOADING AUGER	150 - 38	2G6	CYLINDER, HEADER LIFT, HYDRAULIC	70 - 29
4B15	COUNTERSHAFT, PRIMARY GEARCASE	140 - 14	2C7	CYLINDER, HYDROSTATIC PUMP	50 - 30
4B13	COUNTERSHAFT, PRIMARY, SEPARATOR.....	140 - 12	2D21	CYLINDER, MASTER BRAKE.....	60 - 4
1B19	COUPLING WITH HUB, ENGINE-TRANSMISSION.....	20 - 17	2E19	CYLINDER, STEERING.....	60 - 26
2B8	COUPLINGS, AXLE	50 - 5	4G17	CYLINDER, TENSION INDIVIDUAL REPAIR PARTS.....	160 - 28
4E17	COVER AND CHANNEL, CROSS AUGER	150 - 34	4G1	CYLINDER, TENSION AND ATTACHING HARDWARE	160 - 10
3K1	COVER, CHOPPER, CHOP-TO-BALE	130 - 19	3G3	CYLINDER, THRESHING, RASP BAR	110 - 10
1E17	COVER, ENGINE.....	30 - 16	2H14	CYLINDER, TILT - CONTOUR MASTER	70 - 61
1H5	COVER, FUEL INJECTION PUMP ACCESS	40 - 58	2H15	CYLINDER, TILT, HOSES, CONTOUR MASTER	70 - 63
2C5	COVER, HYDROSTATIC PUMP	50 - 28	4D24	CYLINDER, UNLOADING AUGER SWING	150 - 16
2C17	COVER, INNER, CAM LOBE MOTOR	50 - 42			
4F8	COVER, MOISTURE SENSOR, YIELD MAPPING	155 - 8		D	
4F10	COVER, MOISTURE SENSOR, YIELD MAPPING	155 - 10	1C16	DAMPER KEY	25 - 9
4F2	COVER, POSITION RECEIVER YIELD MAPPING.....	155 - 2	1D24	DAMPER, CRANKSHAFT	25 - 48
1D2	COVER, ROCKER ARM	25 - 21	4F14	DATASTORE	155 - 14
1B21	COVER, STARTER RELAY.....	20 - 19	4F12	DATASTORE MODULE	155 - 12
1D16	COVER, THERMOSTAT	25 - 38	4F14	DATASTORE MODULE	155 - 14
3F19	COVER, THRESHING CYLINDER	110 - 1	4F12	DATASTORE W/DISPLAY.....	155 - 12
1C22	COVER, TIMING GEAR.....	25 - 15	4F16	DECALS, DISPLA, YIELD MAPPING	155 - 17
4F10	COVER, WHEN MOISTURE SENSOR IS NOT USED YIELD MAPPING.....	155 - 10	4F15	DECALS, DISPLAY, YIELD MAPPING	155 - 15
3G19	CRANK, STRAW WALKER	110 - 26	4H15	DECALS, FRENCH CANADIAN	170 - 22
1B24	CRANKCASE, ENGINE OIL DRAIN	20 - 22	4H9	DECALS, FRONT AND REAR	170 - 16
1C16	CRANKSHAFT	25 - 9	4H13	DECALS, FRONT AND REAR TIRE.....	170 - 20
1C22	CRANKSHAFT FRONT OIL SEAL	25 - 15	4H7	DECALS, L.H.....	170 - 14
1C17	CRANKSHAFT KIT, UNDERSIZE	25 - 10	4F15	DECALS, MOISTURE SENSOR, YIELD MAPPING.....	155 - 15
1C18	CRANKSHAFT KIT, UNDERSIZED MAIN BEARING.....	25 - 11	4F16	DECALS, MOISTURE SENSOR, YIELD MAPPING.....	155 - 17
1C20	CRANKSHAFT OIL SEAL	25 - 13	4H16	DECALS, PORTUGESE.....	170 - 23
1D24	CRANKSHAFT PULLEY AND DAMPER.....	25 - 48	4H5	DECALS, R.H.	170 - 12
3G19	CRANKSHAFT, STRAW WALKER	110 - 26	4H17	DECALS, ROMANIAN	170 - 24
4E13	CROSS AUGER BEARING PLATE, L.H.	150 - 30	4H18	DECALS, RUSSIAN	170 - 25
4E17	CROSS AUGER COVERS AND CHANNEL.....	150 - 34	4H11	DECALS, SAFETY (RUBBER TRACK).....	170 - 18
4E15	CROSS AUGER, GRAIN TANK	150 - 32	4G20	DECALS, SAFETY AND LOCATIONS	170 - 2
3G12	CURTAIN, BEATER GRATE	110 - 19	4G22	DECALS, SAFETY AND LOCATIONS	170 - 4
4D14	CURTAIN, GRAIN TANK	150 - 6	4G24	DECALS, SAFETY AND LOCATIONS	170 - 6
3G2	CURTAIN, SEPARATOR, RASP BAR CYLINDER.....	110 - 9	4H1	DECALS, SAFETY AND LOCATIONS	170 - 8
3K6	CURTAIN, SPREADER	130 - 24	4H3	DECALS, SAFETY AND LOCATIONS	170 - 10
3C11	CURUIT BOARD, CORNERPOST DISPLAY, R.H.	90 - 36	4H19	DECALS, SPANISH	170 - 26
3B16	CUSHION, SEAT, PASSENGER.....	90 - 16	4H20	DECALS, UKRAINIAN	170 - 27
1C9	CYLINDER BLOCK FITTINGS	25 - 2	4F15	DECALS, YIELD MAPPING.....	155 - 15
3F19	CYLINDER COVER, THRESHING	110 - 1	4F16	DECALS, YIELD MAPPING.....	155 - 17
3F24	CYLINDER DOOR (CORN).....	110 - 6	3J25	DECLUTCHING LEVER, CHOP-TO-BALE	130 - 18
3F22	CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4	4F6	DEFLECTOR DOOR, MASS FLOW SENSOR YIELD MAPPING	155 - 6
4C5	CYLINDER DRIVE ADJUSTING BRACKET, DUAL-RANGE	140 - 32	3K12	DEFLECTOR, CHAFF SPREADER.....	130 - 30
4B21	CYLINDER DRIVE GEAR CASE, DUAL-RANGE.....	140 - 22	3J22	DEFLECTOR, CORN	130 - 15
4C1	CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING, DUAL-RANGE	140 - 28	3F22	DEFLECTOR, CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4
			2B22	DIFFERENTIAL GEARS	50 - 20

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2B22	DIFFERENTIAL SHAFTS	50 - 20	2G19	DRIVE, BELT PICKUP AND REEL PUMP MOUNTING SHEAVE	70 - 42
1C9	DIPSTICK TUBE, CYLINDER BLOCK	25 - 2	4E20	DRIVE, COUNTERSHAFT, UNLOADING AUGER	150 - 38
1D13	DIPSTICK, ENGINE OIL	25 - 34	1B14	DRIVE, ENGINE FAN	20 - 12
3K8	DISC, CHAFF SPREADER	130 - 26	1B16	DRIVE, ENGINE FAN	20 - 14
2C10	DISPLACEMENT CONTROL VALVE	50 - 34	4C19	DRIVE, FAN, SPEED CONTROL SHEAVE LINKAGE....	140 - 46
4F4	DISPLAY BRACKET, YIELD MAPPING	155 - 4	4C9	DRIVE, GEARCASE, STRAW WALKER.....	140 - 36
4F16	DISPLAY DECALS, YEILD MAPPING	155 - 17	2C12	DRIVE, HYDROSTATIC MOTOR	50 - 36
4F15	DISPLAY DECALS, YIELD MAPPING	155 - 15	2D3	DRIVE, HYDROSTATIC OIL HOSES, UPPER (FOUR WHEEL DRIVE)	50 - 54
3C11	DISPLAY PANEL, R.H. CORNERPOST	90 - 36	2D1	DRIVE, HYDROSTATIC, LOWER OIL LINES (TWO WHEEL DRIVE)	50 - 52
4F12	DISPLAY W/DATASTORE.....	155 - 12	2H1	DRIVE, REEL, HYDRAULIC LINES, L.H.....	70 - 48
4F4	DISPLAY, YIELD MAPPING	155 - 4	4C7	DRIVE, SECONDARY COUNTERSHAFT.....	140 - 34
3B14	DOOR LATCH, CAB	90 - 14	4B20	DRIVE, SINGLE RANGE CYLINDER.....	140 - 21
3B12	DOOR, CAB AND GLASS.....	90 - 12	4C23	DRIVE, STRAW CHOPPER (REAR).....	140 - 50
3J9	DOOR, CHOPPER.....	130 - 1	4C11	DRIVE, STRAW WALKER, CONVEYOR AUGERS, SIEVE AND CHAFFER DRIVE.....	140 - 38
3I7	DOOR, CLEAN GRAIN ELEVATOR	125 - 6	4G11	DRUM AND SHOES, BRAKE	160 - 22
3I5	DOOR, CLEAN GRAIN LOWER AUGER	125 - 4	2E5	DRUM, BRAKE.....	60 - 12
2I13	DOOR, CORNER SHEET, LEFT FRONT.....	80 - 12	3E23	DRUM, FEEDER CONVEYOR IDLER	100 - 32
3F24	DOOR, CYLINDER (CORN)	110 - 6	3D9	DRYER, AIR CONDITIONER	95 - 9
3F22	DOOR, CYLINDER, SEPARATOR (GRAIN AND RICE).....	110 - 4	4B23	DUAL RANGE LOCKOUT ARM	140 - 25
2J14	DOOR, ENGINE ACCESS PLATFORM	80 - 38	4C5	DUAL-RANGE CYLINDER DRIVE ADJUSTING BRACKET.....	140 - 32
1E17	DOOR, ENGINE COMPARTMENT	30 - 16	4B21	DUAL-RANGE CYLINDER DRIVE GEAR CASE	140 - 22
2J10	DOOR, ENGINE COMPARTMENT	80 - 34	4C1	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING.....	140 - 28
3E15	DOOR, FEEDER HOUSE FRAME	100 - 24	4C3	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHEAVE.....	140 - 30
4D10	DOOR, GRAIN TANK	150 - 2	4B24	DUAL-RANGE CYLINDER DRIVE TIGHTENER	140 - 26
2I15	DOOR, GULLWING, L.H.....	80 - 14	3F1	DUST FAN, FEEDER HOUSE - R.H.	100 - 34
2I23	DOOR, GULLWING, R.H.	80 - 22	3F12	DUST FAN, LH SIDE FEEDER HOUSE.....	100 - 46
2I17	DOOR, LEFT REAR GULLWING	80 - 16	E		
4F6	DOOR, MASS FLOW SENSOR DEFLECTOR YIELD MAPPING	155 - 6	1E5	E.C.U.	30 - 4
3I23	DOOR, MATERIAL SENSOR REPLACEMENT TAILING ELEVATOR.....	125 - 22	1G20	ECU MODULE	40 - 48
2J1	DOOR, RADIATOR	80 - 24	1G24	ECU, ELECTRONIC CONTROL UNIT	40 - 52
1B10	DOOR, RADIATOR ACCESS	20 - 8	1F6	ELECTRICAL CONNECTOR SERVICE KIT.....	40 - 4
1B6	DOOR, ROTARY SCREEN	20 - 4	1F8	ELECTRICAL CONNECTOR SERVICE KIT.....	40 - 6
2I3	DOOR, SEPARATOR FRAME.....	80 - 2	1F4	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK	40 - 2
3G22	DOOR, SHOE GRAIN SUPPLY AUGER CLEANOUT....	120 - 1	4B17	ELECTROMAGNETIC HEADER CLUTCH	140 - 17
3F20	DOOR, STONE TRAP, FEEDER HOUSE	110 - 2	1E5	ELECTRONIC CONTROL UNIT	30 - 4
3I21	DOOR, TAILINGS ELEVATOR	125 - 20	1G24	ELECTRONIC CONTROL UNIT (ECU).....	40 - 52
1C9	DRAIN PLUG, CYLINDER BLOCK	25 - 2	1E5	ELECTRONIC FUEL INJECTION PUMP	30 - 4
2C12	DRAIN PLUG, DRIVE MOTOR	50 - 36	1G20	ELECTRONICS MODULE, CENTRAL	40 - 48
1B22	DRAIN PLUG, ENGINE COOLANT.....	20 - 20	3H9	ELEMENT, CHAFFER	120 - 12
2C14	DRAIN PLUG, HYDROSTATIC MOTOR VALVE	50 - 38	3H11	ELEMENT, CHAFFER EXTENSION	120 - 14
1C9	DRAIN VALVE, CYLINDER BLOCK	25 - 2	3H15	ELEMENT, SIEVE	120 - 18
1D16	DRAIN VALVE, CYLINDER HEAD	25 - 38	4D6	ELEVATOR DRIVE IDLER, CLEAN GRAIN.....	140 - 58
1E15	DRAIN VALVE, FUEL	30 - 14	4D6	ELEVATOR DRIVE TIGHTENER, CLEAN GRAIN.....	140 - 58
1E10	DRAIN VALVE, FUEL COOLER	30 - 9	3I7	ELEVATOR, LOWER, CLEAN GRAIN	125 - 6
1D11	DRAIN VALVE, OIL PAN.....	25 - 32	3I21	ELEVATOR, TAILINGS	125 - 20
1B12	DRAIN VALVE, RADIATOR.....	20 - 10	3I3	ELEVATOR, UPPER CLEAN GRAIN	125 - 2
4E22	DRIVE BELT GUIDE, UNLOADING AUGER	150 - 40	2J14	ENGINE ACCESS PLATFORM.....	80 - 38
4D5	DRIVE CHAIN TIGHTENER, UPPER TAILINGS	140 - 57	1E17	ENGINE COMPARTMENT.....	30 - 16
4C21	DRIVE CHOPPER (FRONT)	140 - 48	2J10	ENGINE COMPARTMENT.....	80 - 34
1C16	DRIVE GEAR, OIL PUMP	25 - 9	1E5	ENGINE CONTROLLER	30 - 4
4D6	DRIVE IDLER, CLEAN GRAIN ELEVATOR	140 - 58	1B14	ENGINE FAN DRIVE	20 - 12
2B24	DRIVE SHAFT, FINAL DRIVE.....	50 - 22	1B16	ENGINE FAN DRIVE	20 - 14
2B8	DRIVE SHAFTS	50 - 5	1C21	ENGINE FLYWHEEL	25 - 14
2J3	DRIVE SHIELD, R.H. REAR	80 - 27	1B19	ENGINE GEARCASE HUB	20 - 17
4D1	DRIVE SHIELDS, STRAW CHOPPER	140 - 52	4B3	ENGINE GEARCASE OIL FILTER ASSEMBLY.....	140 - 2
4D6	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR.....	140 - 58	4B5	ENGINE GEARCASE PRESSURE REGULATOR	140 - 4
3E7	DRIVE TIGHTENER, FEEDER HOUSE	100 - 16			
3E3	DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE.....	100 - 12			
3E5	DRIVE TIGHTENER, VARIABLE SPEED	100 - 14			
4G13	DRIVE WHEEL AND BELT	160 - 24			
2B9	DRIVE WHEELS	50 - 6			
2B10	DRIVE WHEELS, HIGH FLOATION.....	50 - 7			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4B11	ENGINE GEARCASE, SEPARATOR AND PUMP DRIVE	140 - 10	3F14	FEEDER HOUSE UPPER DRIVE SHAFT, (FIXED SPEED WITH REVERSER)	100 - 48
4B9	ENGINE GEARCASE, SEPARATOR DRIVE WET-CLUTCH AND PUMP DRIVE SHAFT	140 - 8	3E19	FEEDER HOUSE UPPER SHAFT	100 - 28
1C1	ENGINE INTERCOOLER	20 - 24	3F5	FEEDER HOUSE VARIABLE DRIVE HOSE	100 - 39
1C3	ENGINE MOUNTS AND REAR SUPPORT	20 - 26	3E17	FEEDER HOUSE WEAR PLATES - CONTOUR MASTER	100 - 26
1C8	ENGINE OIL (TORQ-GARD PLUS-50)	25 - 1	3F20	FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR	110 - 2
1D8	ENGINE OIL COOLER	25 - 28	3F6	FEEDER HOUSE, UPPER COUNTERSHAFT VARIABLE DRIVE	100 - 40
1D13	ENGINE OIL DIPSTICK	25 - 34	3B16	FIELD OFFICE	90 - 16
1D9	ENGINE OIL FILTER	25 - 30	1E19	FILTER, AIR CLEANER	30 - 18
1D4	ENGINE OIL PUMP	25 - 24	3D4	FILTER, AIR, RECIRCULATION	95 - 4
1D6	ENGINE OIL PUMP INTAKE	25 - 26	3D6	FILTER, CAB AIR	95 - 6
1C13	ENGINE OVERHAUL KIT	25 - 6	1D9	FILTER, ENGINE OIL	25 - 30
1C15	ENGINE PISTON	25 - 8	3D10	FILTER, EVAPORATOR HEATER	95 - 10
1D22	ENGINE REBUILD GASKET KIT	25 - 46	1E11	FILTER, FUEL	30 - 10
1C11	ENGINE SHORT BLOCK	25 - 4	1E15	FILTER, FUEL PUMP	30 - 14
1H20	ENGINE SPEED SENSOR	40 - 74	2C9	FILTER, HYDROSTATIC CHARGE PUMP	50 - 32
1F15	ENGINE WIRING HARNESS	40 - 14	2H13	FILTER, MAIN HYDRAULIC	70 - 60
1B19	ENGINE-TRANSMISSION COUPLING WITH HUB	20 - 17	4B3	FILTER, OIL, ENGINE GEARCASE	140 - 2
1E14	ETHER AID FITTINGS	30 - 13	1C22	FILTER, WATER PUMP	25 - 15
3C5	ETHER START BUTTON	90 - 30	1G11	FILTER, WINDSHIELD WASHER	40 - 38
3D10	EVAPORATOR HEATER, AIR CONDITIONER	95 - 10	2C1	FINAL DRIVE	50 - 24
1D21	EXHAUST MANIFOLD	25 - 44	2B24	FINAL DRIVE SHAFT	50 - 22
1D21	EXHAUST MANIFOLD HEAT SHIELD	25 - 44	2D15	FINAL DRIVE SHAFT SHIELDS	50 - 66
1E21	EXHAUST PIPE AND MUFFLER	30 - 20	2D14	FINAL DRIVE SHAFT SHIELDS - SINGLE REDUCTION	50 - 65
1C24	EXHAUST VALVES	25 - 18	3J14	FINE CUT ROTOR CHOPPER (STRAIGHT BLADE)	130 - 6
3H11	EXTENSION ELEMENT, CHAFFER	120 - 14	3G11	FINGER GRATE, SPIKE-TOOTH	110 - 18
2B7	EXTENSION, AXLE	50 - 4	3F1	FINGER, FEEDER HOUSE DUST FAN - R.H.	100 - 34
3J9	EXTENSION, CHOPPER DOOR	130 - 1	3F12	FINGER, FEEDER HOUSE DUST FAN, L.H.	100 - 46
4D16	EXTENSION, GRAIN TANK	150 - 8	3H5	FINGER, PRECLEANER CHAFFER	120 - 8
3C19	EXTENSION, LADDER ASSEMBLY	90 - 45	3H11	FINGERS, PLASTIC, CHAFFER	120 - 14
F					
4C17	FAN DRIVE SPEED CONTROL LINKAGE	140 - 44	1C9	FITTINGS, CYLINDER BLOCK	25 - 2
4C19	FAN DRIVE SPEED CONTROL SHEAVE LINKAGE	140 - 46	1E14	FITTINGS, ETHER STARTING	30 - 13
4C15	FAN DRIVE, CLEANING, SEPARATOR	140 - 42	1E15	FITTINGS, FUEL TANK	30 - 14
1B14	FAN DRIVE, ENGINE	20 - 12	1B18	FIXED FAN DRIVE	20 - 16
1B18	FAN DRIVE, FIXED	20 - 16	2B5	FIXED REAR AXLE	50 - 2
1B18	FAN PULLEY HUB	20 - 16	2E25	FIXED REAR AXLE STEERING TIE RODS	60 - 33
1B20	FAN PULLEY, AIR CONDITIONER COMPRESSOR	20 - 18	3E3	FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER	100 - 12
3D2	FAN, AIR CONDITIONER AND HEATER	95 - 2	1I5	FLOODLIGHT, CLEANING SHOE INSPECTION	40 - 84
1H3	FAN, ALTERNATOR (185 AMP)	40 - 56	2I19	FLOODLIGHT, LEFT REAR CORNER PANEL	80 - 18
1H1	FAN, ALTERNATOR (95 AMP)	40 - 54	1I3	FLOODLIGHT, SIDE FINDER	40 - 82
3D4	FAN, BLOWER, AIR CONDITIONER AND HEATER	95 - 4	3B8	FLOOR MAT	90 - 8
3H1	FAN, CLEANING	120 - 4	3B6	FLOOR PANELS	90 - 6
3F1	FAN, DUST, FEEDER HOUSE, R.H.	100 - 34	3E21	FLOOR, FEEDER HOUSE	100 - 30
3F12	FAN, DUST, LH SIDE FEEDER HOUSE	100 - 46	3F8	FLOOR, FEEDER HOUSE RETURN	100 - 42
1B16	FAN, ENGINE	20 - 14	2G21	FLOW CONTROL VALVE, REEL DRIVE	70 - 44
3F3	FEEDER CONVEYOR DRIVE CHAIN AND IDLER BRACKET	100 - 36	4F6	FLOW SENSOR, MASS, YIELD MAPPING	155 - 6
3E23	FEEDER CONVEYOR IDLER SHAFT AND DRUM	100 - 32	1C21	FLYWHEEL RING GEAR	25 - 14
1H9	FEEDER HOUSE BACKSHAFT SPEED SENSOR	40 - 62	1C21	FLYWHEEL, ENGINE	25 - 14
3E7	FEEDER HOUSE DRIVE TIGHTENER	100 - 16	1C23	FOLLOWER, CAMSHAFT	25 - 16
3E3	FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED)	100 - 12	1D1	FOLLOWER, CAMSHAFT	25 - 20
3F1	FEEDER HOUSE DUST FAN - R.H.	100 - 34	3C7	FOOT PEDAL, FEEDER HOUSE REVERSER	90 - 32
3F12	FEEDER HOUSE DUST FAN, LH SIDE	100 - 46	2D7	FOUR WHEEL DRIVE HYDRAULIC HOSES, L.H.	50 - 58
3E21	FEEDER HOUSE FLOOR	100 - 30	3H7	FRAME ARMS, PRECLEANER CHAFFER	120 - 10
3E15	FEEDER HOUSE FRAME	100 - 24	4F18	FRAME MOUNTING, TRACK	160 - 2
3F16	FEEDER HOUSE FRONT DRIVE SHAFT, SHEAVE AND MOUNTINGS (FIXED SPEED WITH	100 - 50	3H13	FRAME, CHAFFER	120 - 16
3D20	FEEDER HOUSE GEARCASE OIL COOLER	100 - 4	1E17	FRAME, ENGINE COMPARTMENT	30 - 16
3F10	FEEDER HOUSE POSITION SENSOR	100 - 44	3E15	FRAME, FEEDER HOUSE	100 - 24
3C7	FEEDER HOUSE REVERSER FOOT CONTROL	90 - 32	4F20	FRAME, MAIN, PIVOT BUSHINGS	160 - 4
3E17	FEEDER HOUSE SHELL - CONTOUR MASTER	100 - 26	2I3	FRAME, SEPARATOR	80 - 2
			4F18	FRAME, SHIPPING	160 - 2
			3H17	FRAME, SIEVE	120 - 20
			4H15	FRENCH CANADIAN DECALS AND LABELS	170 - 22
			4F22	FRONT ARM AND ADJUSTABLE IDLER ASSEMBLY ..	160 - 6

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2I21	FRONT PANEL, RIGHT.....	80 - 20	4B15	GEARCASE, PRIMARY COUNTERSHAFT	140 - 14
2I9	FRONT SHIELD ASSEMBLY, RIGHT SIDE.....	80 - 8	3E1	GEARCASE, STANDARD	100 - 10
2E11	FRONT STEERING HOSES AND LINES.....	60 - 18	3C9	GEARSHIFT LEVER AND LINKAGE	90 - 34
3D18	FRONT VARIABLE DRIVE SHEAVE	100 - 2	3B12	GLASS, CAB AND DOOR	90 - 12
1E11	FUEL CHECK VALVE	30 - 10	1G16	GRAIN LOSS MONITOR	40 - 43
1E10	FUEL COOLER	30 - 9	3H19	GRAIN PAN, SHAKER.....	120 - 22
1E11	FUEL FILTER.....	30 - 10	4D14	GRAIN TANK AND CURTAINS.....	150 - 6
1E11	FUEL FILTER LINES.....	30 - 10	4D12	GRAIN TANK BASE.....	150 - 4
1E3	FUEL INJECTION LINES.....	30 - 2	4E15	GRAIN TANK CROSS AUGERS.....	150 - 32
1E3	FUEL INJECTION NOZZLE.....	30 - 2	4D16	GRAIN TANK EXTENSIONS.....	150 - 8
1E9	FUEL INJECTION NOZZLE.....	30 - 8	1G19	GRAIN TANK FULL BIN SENSOR	40 - 46
1H5	FUEL INJECTION PUMP ACCESS COVER	40 - 58	4D10	GRAIN TANK TOP.....	150 - 2
1E7	FUEL INJECTION PUMP HOUSING CONNECTORS	30 - 6	4E18	GRAIN TANK UNLOADING DRIVE CYLINDER.....	150 - 36
1E3	FUEL LEAK-OFF LINES	30 - 2	4D20	GRAIN TANK VERTICAL UNLOADING AUGER	150 - 12
1E5	FUEL LEAK-OFF LINES	30 - 4	1G18	GRAIN TANK WIRING HARNESS	40 - 45
1E5	FUEL PUMP.....	30 - 4	3G12	GRATE CURTAIN, BEATER	110 - 19
1E15	FUEL PUMP.....	30 - 14	3G11	GRATE, FINGER, SPIKE-TOOTH.....	110 - 18
1E15	FUEL SENDER	30 - 14	3G9	GRATE, SPIKE TOOTH CONCAVE	110 - 16
1E15	FUEL TANK AND FITTINGS.....	30 - 14	3B10	GRILLE, SPEAKER	90 - 10
2J12	FUEL TANK STEPS AND MOUNTING BRACKETS	80 - 36	3J25	GRIP, DECLUTCHING LEVER	130 - 18
1E8	FUEL TRANSFER PUMP	30 - 7	2J4	GRIP, REAR LANDING LADDER	80 - 28
			3K2	GUARD AND STRAW SPREADER MOUNTING	130 - 20
			3F3	GUIDE, CHAIN SUPPORT, FEEDER CONVEYOR	100 - 36
	G		2I15	GULLWING DOOR, L.H.	80 - 14
1D22	GASKET KIT, CYLINDER HEAD	25 - 46	2I17	GULLWING DOOR, LEFT REAR	80 - 16
1D22	GASKET KIT, ENGINE REBUILD	25 - 46	2I23	GULLWING DOOR, R.H.....	80 - 22
1D22	GASKET KIT, SHORT BLOCK	25 - 46			
1C24	GASKET, CYLINDER HEAD	25 - 18		H	
1D21	GASKET, EXHAUST MANIFOLD	25 - 44	3K10	HANDLE AND SHIELDS, CHAFF SPREADER	130 - 28
1D18	GASKET, INTAKE MANIFOLD	25 - 40	3B23	HANDLE, ARMREST CONTROL PANEL	90 - 24
1D9	GASKET, OIL FILTER HOUSING	25 - 30	3B6	HANDLE, CAB	90 - 6
1D11	GASKET, OIL PAN	25 - 32	3B14	HANDLE, CAB DOOR	90 - 14
1D4	GASKET, OIL PUMP.....	25 - 24	3H9	HANDLE, CHAFFER ELEMENT	120 - 12
1D6	GASKET, OIL PUMP INTAKE	25 - 26	3H11	HANDLE, CHAFFER EXTENSION ELEMENT	120 - 14
1C20	GASKET, REAR OIL SEAL.....	25 - 13	3F24	HANDLE, CYLINDER DOOR (CORN)	110 - 6
1D2	GASKET, ROCKER ARM COVER	25 - 21	3F22	HANDLE, CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4
1D16	GASKET, THERMOSTAT	25 - 38	3E21	HANDLE, FEEDER HOUSE LATCH.....	100 - 30
1C22	GASKET, TIMING GEAR COVER.....	25 - 15	2I15	HANDLE, GULLWING DOOR, L.H.....	80 - 14
1D19	GASKET, TURBOCHARGER	25 - 42	2I23	HANDLE, GULLWING DOOR, R.H.	80 - 22
1D16	GASKET, WATER MANIFOLD	25 - 38	2I5	HANDLE, LEFT SIDE FRONT SHIELD	80 - 4
1D14	GASKET, WATER PUMP	25 - 36	2I11	HANDLE, RIGHT SIDE SHIELD	80 - 10
2G13	GAUGE, ACCUMULATOR PRESSURE	70 - 36	3G22	HANDLE, SHOE GRAIN SUPPLY AUGER DOOR	120 - 1
3D22	GEAR BOX, REVERSER - (HIGH CAPACITY)	100 - 6	3H15	HANDLE, SIEVE ELEMENT	120 - 18
3E1	GEAR BOX, REVERSER, STANDARD	100 - 10	2J14	HANDRAIL, ENGINE ACCESS PLATFORM	80 - 38
4B21	GEAR CASE, DUAL-RANGE CYLINDER DRIVE.....	140 - 22	2J10	HANDRAIL, ENGINE COMPARTMENT	80 - 34
4G7	GEAR CASE, TRANSFER.....	160 - 18	3C20	HANDRAIL, L.H.....	90 - 46
4D18	GEAR CASE, VERTICAL AUGER LOWER	150 - 10	3C17	HANDRAIL, PLATFORM EXTENSIONS	90 - 42
1C23	GEAR, CAMSHAFT	25 - 16	3C22	HANDRAIL, R.H.	90 - 48
2B22	GEAR, DIFFERENTIAL	50 - 20	2J1	HANDRAIL, RADIATOR DOOR.....	80 - 24
2C1	GEAR, FINAL DRIVE.....	50 - 24	3C24	HARDWARE KIT, CAB	90 - 50
1E5	GEAR, INJECTION PUMP.....	30 - 4	1G9	HARNESS, AIR CONDITIONING WIRING	40 - 36
1C16	GEAR, OIL PUMP DRIVE	25 - 9	1G5	HARNESS, ARMREST WIRING	40 - 32
1D4	GEAR, OIL PUMP DRIVE	25 - 24	1G3	HARNESS, CAB WIRING	40 - 30
3E1	GEAR, REVERSER, STANDARD	100 - 10	4F12	HARNESS, DATASTORE	155 - 12
3G23	GEAR, SHOE GRAIN SUPPLY AUGER.....	120 - 2	1G19	HARNESS, FULL BIN SENSOR	40 - 46
2B18	GEAR, TRANSMISSION	50 - 16	1F17	HARNESS, MAIN WIRING, L.H.	40 - 17
2B20	GEAR, TRANSMISSION PINION	50 - 18	1F20	HARNESS, MAIN WIRING, L.H.	40 - 20
1C17	GEAR, UNDERSIZE CRANKSHAFT.....	25 - 10	4F8	HARNESS, MOISTURE SENSOR MOTOR YIELD MAPPING	155 - 8
4C9	GEARCASE DRIVE, STRAW WALKER	140 - 36	1F25	HARNESS, R.H. MAIN W/GREENSTAR.....	40 - 27
4B13	GEARCASE MOUNTING.....	140 - 12	1F22	HARNESS, R.H. MAIN WIRING W/O GREENSTAR	40 - 23
3I13	GEARCASE, CLEAN GRAIN ELEVATOR	125 - 12	1H7	HARNESS, STARTER, WIRING	40 - 60
4B9	GEARCASE, ENGINE	140 - 8			
4B11	GEARCASE, ENGINE	140 - 10			
4E6	GEARCASE, HORIZONTAL UNLOADING AUGER DRIVE	150 - 23			
4B7	GEARCASE, MAIN.....	140 - 6			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1G7	HARNES, STEERING COLUMN WIRING	40 - 34	2D1	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE)	50 - 52
1G17	HARNES, UNLOADING AUGER.....	40 - 44	2D9	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE).....	50 - 60
1G15	HARVESTRAK WIRING HARNES	40 - 42	2D3	HOSES, OIL, HYDROSTATIC DRIVE, UPPER (FOUR WHEEL DRIVE)	50 - 54
1C24	HEAD, CYLINDER	25 - 18	2F5	HOSES, PRESSURE, HYDRAULIC	70 - 2
4B17	HEADER ELECTROMAGNETIC CLUTCH	140 - 17	2H3	HOSES, REEL DRIVE, HYDRAULIC, FRONT	70 - 50
2F23	HEADER HEIGHT CONTROL VALVE	70 - 21	2F7	HOSES, RETURN, HYDRAULIC.....	70 - 4
2F24	HEADER HEIGHT CONTROL, HYDRAULIC LINE AND VALVE BLOCK	70 - 22	2E9	HOSES, STEERING, UPPER	60 - 16
2G6	HEADER LIFT CYLINDER, HYDRAULIC	70 - 29	2H15	HOSES, TILT CYLINDER - CONTOUR MASTER	70 - 63
2G7	HEADER LIFT LINES AND HOSES	70 - 30	4D22	HOSES, UNLOADING AUGER SWING	150 - 14
2G1	HEADER LIFT MODULE, SOLENOID VALVE	70 - 24	3F5	HOSES, VARIABLE DRIVE, FEEDER HOUSE	100 - 39
3B10	HEADLINER, CAB	90 - 10	2F13	HOSES, WET CLUTCH OIL COOLER, HYDRAULIC	70 - 10
1D21	HEAT SHIELD, EXHAUST MANIFOLD.....	25 - 44	1G11	HOSES, WINDSHIELD WIPER	40 - 38
3D7	HEATER AND AIR CONDITIONING DUCTS	95 - 7	3G23	HOUSING AND SHOE GRAIN SUPPLY AUGERS	120 - 2
3D2	HEATER AND AIR CONDITIONING HOUSING.....	95 - 2	1E7	HOUSING CONNECTORS, FUEL INJECTION PUMP ..	30 - 6
3D4	HEATER AND AIR CONDITIONING HOUSING, LOWER	95 - 4	2B17	HOUSING COVER, TRANSMISSION AND DIFFERENTIAL	50 - 14
1C4	HEATER HOSE CONNECTORS.....	20 - 27	3D4	HOUSING, AIR CONDITIONER/HEATER, LOWER	95 - 4
1B22	HEATER, COOLANT, ENGINE BLOCK	20 - 20	3D2	HOUSING, AIR CONDITIONER/HEATER, UPPER	95 - 2
3D10	HEATER, EVAPORATOR, AIR CONDITIONER	95 - 10	3D6	HOUSING, CAB AIR FILTER	95 - 6
3D22	HIGH CAPACITY REVERSE GEAR BOX	100 - 6	4D20	HOUSING, CHARGE, VERTICAL UNLOADING AUGER.....	150 - 12
2B10	HIGH FLOATATION DRIVE WHEELS	50 - 7	2C1	HOUSING, FINAL DRIVE	50 - 24
3F22	HINGE, CYLINDER DOOR (GRAIN AND RICE).....	110 - 4	4E9	HOUSING, HORIZONTAL UNLOADING AUGER (EXPORT)	150 - 26
3I5	HINGE, DOOR, LOWER AUGER, CLEAN GRAIN	125 - 4	4E7	HOUSING, HORIZONTAL UNLOADING AUGER (17 AND 20 FT.)	150 - 24
3F20	HINGE, DOOR, STONE TRAP	110 - 2	2C7	HOUSING, HYDROSTATIC PUMP	50 - 30
2J10	HINGE, ENGINE COMPARTMENT.....	80 - 34	1C20	HOUSING, REAR OIL SEAL.....	25 - 13
1E17	HINGE, ENGINE PLATFORM DOOR.....	30 - 16	2B5	HOUSING, SPINDLE, REAR AXLE	50 - 2
3E15	HINGE, FEEDER HOUSE FRAME DOOR	100 - 24	3I21	HOUSING, TAILINGS ELEVATOR	125 - 20
2I23	HINGE, GULLWING DOOR, R.H.....	80 - 22	1D16	HOUSING, THERMOSTAT, FRONT	25 - 38
2I15	HINGE, L.H. GULLWING.....	80 - 14	2B16	HOUSING, TRANSMISSION AND DIFFERENTIAL	50 - 13
1B10	HINGE, RADIATOR ACCESS DOOR	20 - 8	3J5	HOUSING, UPPER TAILINGS AUGER	125 - 28
2J1	HINGE, RADIATOR DOOR	80 - 24	4E5	HUB SUPPORT, HORIZONTAL UNLOADING AUGER ..	150 - 22
2J8	HOOD, REAR.....	80 - 32	4G6	HUB, BOGEY WHEEL.....	160 - 16
4E11	HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....	150 - 28	1B16	HUB, FAN.....	20 - 14
4E6	HORIZONTAL UNLOADING AUGER DRIVE GEARCASE	150 - 23	1B18	HUB, FAN PULLEY	20 - 16
4E9	HORIZONTAL UNLOADING AUGER HOUSING (EXPORT)	150 - 26	4G3	HUB, IDLER WHEEL	160 - 12
4E7	HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.)	150 - 24	2H13	HYDRAULIC FILTER, MAIN	70 - 60
4E1	HORIZONTAL UNLOADING AUGER SWIVEL.....	150 - 18	2H11	HYDRAULIC HOSES, CONTOUR MASTER (L.H.)	70 - 58
3B5	HORN ASSEMBLY.....	90 - 5	2G15	HYDRAULIC HOSES, CYLINDER SPEED	70 - 38
3C5	HORN BUTTON	90 - 30	2D7	HYDRAULIC HOSES, L.H., 4-WHEEL DRIVE	50 - 58
2G7	HOSES AND LINES, HEADER LIFT	70 - 30	2G23	HYDRAULIC HOSES, REEL PUMP	70 - 46
2D5	HOSES AND LINES, HYDROSTATIC OIL COOLER.....	50 - 56	2F13	HYDRAULIC HOSES, WET CLUTCH OIL COOLER.....	70 - 10
2H9	HOSES AND LINES, REEL LIFT	70 - 56	2H7	HYDRAULIC LINES AND HOSES, REEL FORE-AND-AFT, FRONT	70 - 54
2E11	HOSES AND LINES, STEERING, FRONT.....	60 - 18	2D13	HYDRAULIC LINES, CASE DRAIN, 4-WHEEL DRIVE	50 - 64
2E17	HOSES AND LINES, STEERING, REAR	60 - 24	2H5	HYDRAULIC LINES, REEL FORE-AND-AFT, L.H.	70 - 52
1B12	HOSES RADIATOR	20 - 10	2C19	HYDRAULIC MOTOR PISTON CARRIER	50 - 44
3D12	HOSES, AIR CONDITIONER COMPRESSOR	95 - 12	2F5	HYDRAULIC PRESSURE HOSES	70 - 2
2H20	HOSES, CHAFF SPREADER	70 - 68	2G17	HYDRAULIC PUMP REEL / FEEDER HOUSE DRIVE ..	70 - 40
2D11	HOSES, CONTROL VALVE TO CAM LOBE MOTOR (4-WHEEL DRIVE).....	50 - 62	2F9	HYDRAULIC PUMP, MAIN	70 - 6
2D7	HOSES, FOUR WHEEL DRIVE HYDRAULIC, L.H.	50 - 58	2F7	HYDRAULIC RETURN LINES.....	70 - 4
4E18	HOSES, GRAIN TANK UNLOADING DRIVE CYLINDER	150 - 36	2F4	HYDRAULIC/HYDROSTATIC OIL RESERVOIR.....	70 - 1
2H11	HOSES, HYDRAULIC, CONTOUR MASTER (L.H.).....	70 - 58	4G15	HYDRAULICS, TENSION CYLINDER.....	160 - 26
2G15	HOSES, HYDRAULIC, CYLINDER SPEED	70 - 38	2C10	HYDROSTASTIC DRIVE DISPLACEMENT CONTROL VALVE.....	50 - 34
2G23	HOSES, HYDRAULIC, REEL PUMP.....	70 - 46	2C9	HYDROSTATIC DRIVE CHARGE PUMP	50 - 32
1C1	HOSES, INTERCOOLER	20 - 24	2C3	HYDROSTATIC DRIVE CONTROL CABLES	50 - 26
2H22	HOSES, LINES, CHAFF SPREADER (DUAL MOTOR).....	70 - 70	2C12	HYDROSTATIC DRIVE MOTOR.....	50 - 36
4E1	HOSES, LUBRICATION, HORIZONTAL UNLOADING AUGER.....	150 - 18	2D3	HYDROSTATIC DRIVE OIL HOSES, UPPER (FOUR WHEEL DRIVE)	50 - 54

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2D1	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE)	50 - 52	4D24	KIT, UNLOADING AUGER SWING CYLINDER REPAIR	150 - 16
2D9	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (4-WHEEL DRIVE)	50 - 60	1D14	KIT, WATER PUMP SEAL	25 - 36
2C5	HYDROSTATIC DRIVE PUMP COVER	50 - 28	1C18	KIT, UNDERSIZED MAIN BEARING CRANKSHAFT	25 - 11
2C5	HYDROSTATIC DRIVE PUMP SHAFT	50 - 28	3J18	KNIFEBANK AND HOUSING, CHOPPER	130 - 10
2D5	HYDROSTATIC OIL COOLER LINES	50 - 56	3C9	KNOB GEARSHIFT	90 - 34
2F4	HYDROSTATIC/HYDRAULIC RESERVOIR	70 - 1	3B23	KNOB, ARMREST CONTROL PANEL	90 - 24
I			3C1	KNOB, ARMREST CONTROL PANEL	90 - 26
1B4	IDLER ARMS, ROTARY SCREEN DRIVE	20 - 2	3D6	KNOB, CAB AIR FILTER	95 - 6
4F22	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM..	160 - 6	2H16	KNOB, CHAFF SPREADER ADJUSTER	70 - 64
4G1	IDLER AXLE	160 - 10	2I13	KNOB, DOOR, LEFT FRONT	80 - 12
1B20	IDLER PULLEY, AIR CONDITIONER COMPRESSOR ..	20 - 18	3B20	KNOB, LUMBAR	90 - 20
4G3	IDLER WHEEL ASSEMBLY	160 - 12	3C13	KNOB, OVERHEAD CONSOLE	90 - 38
4D6	IDLER, DRIVE, CLEAN GRAIN ELEVATOR	140 - 58	L		
3C5	IGNITION SWITCH	90 - 30	1F18	L.H. MAIN WIRING HARNESS	40 - 18
1H14	INDICATOR, SPIKE TOOTH	40 - 68	1F20	L.H. MAIN WIRING HARNESS	40 - 20
1E5	INJECTION PUMP GEAR	30 - 4	2E13	L.H. SIDE LINES, STEERING	60 - 20
1E5	INJECTION PUMP, ELECTRONIC FUEL	30 - 4	4H13	LABEL, AXLE STOP AND TIRE CLEARANCE	170 - 20
2C17	INNER COVER, CAM LOBE MOTOR	50 - 42	4H15	LABEL, FRENCH CANADIAN	170 - 22
2B18	INPUT SHAFT, TRANSMISSION	50 - 16	4H16	LABEL, PORTUGUESE	170 - 23
1I5	INSPECTION LIGHT, CLEANING SHOE	40 - 84	4H17	LABEL, ROMANIAN	170 - 24
1D18	INTAKE MANIFOLD	25 - 40	4H18	LABEL, RUSSIAN	170 - 25
3G23	INTAKE SHIELD, SHOE GRAIN SUPPLY AUGER	120 - 2	4H11	LABEL, SAFETY (RUBBER TRACK)	170 - 18
3H1	INTAKE SHIELDS, CLEANING FAN	120 - 4	4H19	LABEL, SPANISH	170 - 26
1E19	INTAKE TUBES AND AIR CLEANER	30 - 18	4H13	LABEL, TIRE CLEARANCE	170 - 20
1C24	INTAKE VALVES	25 - 18	4H13	LABEL, TIRE PRESSURE	170 - 20
1D6	INTAKE, ENGINE OIL PUMP	25 - 26	4H20	LABEL, UKRAINIAN	170 - 27
1C1	INTERCOOLER	20 - 24	4H13	LABEL, WHEEL BOLT TORQUE	170 - 20
4C1	INTERMEDIATE SHAFT MOUNTING, CYLINDER DRIVE, DUAL-RANGE	140 - 28	3C19	LADDER EXTENSION ASSEMBLY	90 - 45
4C3	INTERMEDIATE SHEAVE, CYLINDER DRIVE, DUAL-RANGE	140 - 30	3C17	LADDER, CAB PLATFORM	90 - 42
K			2J10	LADDER, ENGINE COMPARTMENT	80 - 34
1C16	KEY, DAMPER, CRANKSHAFT	25 - 9	4D10	LADDER, GRAIN TANK	150 - 2
1F13	KIT-CONVENIENCE, OUTLET	40 - 12	2J4	LADDER, REAR LANDING	80 - 28
1H11	KIT, ALIGNMENT BRACKET REEL SPEED	40 - 64	1H24	LAMP ASSEMBLY - L.H. FRONT (AMBER)	40 - 78
2H14	KIT, CONTOUR MASTER CYLINDER REPAIR	70 - 61	1H25	LAMP ASSEMBLY, R.H. FRONT (AMBER)	40 - 79
2G5	KIT, CONTROL VALVE, AUGER SWING	70 - 28	1I1	LAMP ASSEMBLY, REAR (AMBER)	40 - 80
2G5	KIT, CONTROL VALVE, REEL FORE/AFT	70 - 28	1H24	LAMP, TURN SIGNAL, L.H. FRONT (AMBER)	40 - 78
1D22	KIT, CYLINDER HEAD	25 - 46	3C20	LANDING, L.H.	90 - 46
1C15	KIT, CYLINDER LINER O-RING	25 - 8	3C22	LANDING, R.H.	90 - 48
1F6	KIT, ELECTRICAL CONNECTOR SERVICE	40 - 4	2J4	LANDING, REAR	80 - 28
1F8	KIT, ELECTRICAL CONNECTOR SERVICE	40 - 6	2J6	LATCH ARM, REAR LADDER LANDING	80 - 30
1C13	KIT, ENGINE OVERHAUL	25 - 6	3B14	LATCH, CAB DOOR	90 - 14
1D22	KIT, ENGINE REBUILD	25 - 46	3J23	LATCH, CHOP-TO-BALE	130 - 16
2G1	KIT, HEADER LIFT CONTROL VALVE REPAIR	70 - 24	3J25	LATCH, DECLUTCHING LEVER, CHOP-TO-BALE	130 - 18
2C12	KIT, HYDROSTATIC DRIVE MOTOR	50 - 36	2I13	LATCH, DOOR, LEFT FRONT	80 - 12
2F9	KIT, MAIN HYDRAULIC PUMP REPAIR	70 - 6	3G22	LATCH, DOOR, SHOE GRAIN SUPPLY CLEANOUT ...	120 - 1
2E1	KIT, MASTER BRAKE CYLINDER	60 - 8	1G20	LATCH, ELECTRONICS MODULE	40 - 48
3J16	KIT, PADDLE BLADE, FINE CUT CHOPPER	130 - 8	1E17	LATCH, ENGINE PLATFORM DOOR	30 - 16
2G21	KIT, REEL DRIVE FLOW CONTROL REPAIR	70 - 44	4D18	LATCH, GRAIN TANK CLEAN OUT CHUTE	150 - 10
2G3	KIT, REEL LIFT/VARIABLE	70 - 26	3E11	LATCH, L.H. DRIVE SHIELD - W/AIRFLOW	100 - 20
1H11	KIT, REEL SPEED BRACKET	40 - 64	3E9	LATCH, L.H. DRIVE SHIELD - W/O AIRFLOW	100 - 18
2E19	KIT, STEERING CYLINDER REPAIR	60 - 26	3C19	LATCH, LADDER EXTENSION	90 - 45
2E7	KIT, STEERING PUMP SEALS	60 - 14	3E13	LATCH, R.H. DRIVE SHIELD	100 - 22
3G17	KIT, STRAW WALKER BEARING	110 - 24	1B10	LATCH, RADIATOR FRAME	20 - 8
1F10	KIT, TERMINAL AND WIRING	40 - 8	3I21	LATCH, TAILINGS ELEVATOR	125 - 20
2H15	KIT, TILT CYLINDER REPAIR, CONTOUR MASTER	70 - 63	2I7	LEFT SIDE SHIELD ASSEMBLY	80 - 6
1C17	KIT, UNDERSIZE CRANKSHAFT	25 - 10	3J25	LEVER, DECLUTCHING, CHOP-TO-BALE	130 - 18
			3C9	LEVER, GEARSHIFT	90 - 34
			2G6	LIFT CYLINDER, HEADER, HYDRAULIC	70 - 29
			1D3	LIFT STRAPS, ENGINE	25 - 22
			1H25	LIGHT ASSEMBLY - R.H. FRONT (AMBER)	40 - 79
			3I21	LIGHT SWITCH, TAILINGS ELEVATOR	125 - 20
			3C1	LIGHT, ARMREST CONTROL PANEL	90 - 26
			1H23	LIGHT, CAB ROOF	40 - 77

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
115	LIGHT, CLEANING SHOE INSPECTION	40-84		M	
2J14	LIGHT, ENGINE ACCESS PLATFORM	80-38			
2119	LIGHT, FLOOD, LEFT REAR CORNER PANEL	80-18	2117	MAGNET, GULLWING, LEFT REAR	80-16
1H24	LIGHT, L.H. FRONT (AMBER)	40-78	1H20	MAGNETIC PICK-UP (ENGINE)	40-74
112	LIGHT, REAR TURN AND TAIL (RED)	40-81	1C9	MAIN BEARING CAPS	25-2
2J10	LIGHT, SERVICE, ENGINE COMPARTMENT	80-34	1C19	MAIN BEARINGS	25-12
2115	LIGHT, SERVICE, L.H. GULLWING	80-14	4F20	MAIN FRAME PIVOT BUSHINGS	160-4
2123	LIGHT, SERVICE, R.H. GULLWING	80-22	4B7	MAIN GEARCASE	140-6
2J1	LIGHT, SERVICE, RADIATOR DOOR	80-24	2F9	MAIN HYDRAULIC PUMP	70-6
113	LIGHT, SIDE FINDER	40-82	2F23	MAIN VALVE BLOCK SOLENOID ACTIVE HEADER HEIGHT CONTROL	70-21
3B3	LIGHT, STUBBLE	90-2	1F25	MAIN WIRING HARNESS, R.H. W/GREENSTAR	40-27
114	LIGHT, TRANSPORT WARNING	40-83	1F22	MAIN WIRING HARNESS, R.H. W/O GREENSTAR	40-23
1G17	LIGHT, UNLOADING AUGER	40-44	3D11	MANIFOLD, AIR CONDITIONER COMPRESSOR	95-11
3B23	LIGHTER, CIGARETTE	90-24	2C17	MANIFOLD, CAM LOBE MOTOR	50-42
3F12	LIMIT CURTAIN, FEEDER HOUSE DUST FAN	100-46	2D13	MANIFOLD, CASE DRAIN	50-64
1C15	LINER, CYLINDER	25-8	1D21	MANIFOLD, EXHAUST	25-44
2G7	LINES AND HOSES, HEADER LIFT	70-30	1D18	MANIFOLD, INTAKE	25-40
2D5	LINES AND HOSES, HYDROSTATIC OIL COOLER	50-56	1D16	MANIFOLD, WATER, FRONT	25-38
2H9	LINES AND HOSES, REEL LIFT	70-56	4F6	MASS FLOW SENSOR BRACKET YIELD MAPPING	155-6
2E11	LINES AND HOSES, STEERING, FRONT	60-18	4F6	MASS FLOW SENSOR DOOR, YIELD MAPPING	155-6
2E17	LINES AND HOSES, STEERING, REAR	60-24	4F6	MASS FLOW SENSOR, YIELD MAPPING	155-6
2D23	LINES, BRAKE	60-6	2E1	MASTER BRAKE CYLINDER	60-8
2H18	LINES, CHAFF SPREADER	70-66	2D23	MASTER CYLINDER, RESERVOIR, BRAKE LINES	60-6
2D11	LINES, CONTROL VALVE TO CAM LOBE MOTOR (4-WHEEL DRIVE)	50-62	2D21	MASTER CYLINDERS	60-4
2D7	LINES, FOUR WHEEL DRIVE HYDRAULIC, L.H.	50-58	3B8	MAT, CAB FLOOR	90-8
1E5	LINES, FUEL	30-4	1E17	MAT, ENGINE PLATFORM	30-16
1E11	LINES, FUEL FILTER	30-10	3E15	MAT, FEEDER HOUSE FRAME	100-24
1E3	LINES, FUEL INJECTION	30-2	1B10	MAT, RADIATOR FRAME	20-8
1E3	LINES, FUEL LEAK-OFF	30-2	3I23	MATERIAL SENSOR, TAILINGS ELEVATOR	125-22
2H20	LINES, HOSES, VALVE AND PUMP, CHAFF SPREADER	70-68	3C20	MIRROR, L.H.	90-46
2G23	LINES, HYDRAULIC, REEL PUMP	70-46	3C22	MIRROR, R.H.	90-48
1E5	LINES, INJECTION PUMP LUBE	30-4	4F4	MOBILE PROCESSOR, YIELD MAPPING	155-4
2D1	LINES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE)	50-52	3C11	MODULE, ACTIVE HEADER HEIGHT CONTROL DISPLAY, R.H. CORNERPOST	90-36
2D9	LINES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE)	50-60	1G20	MODULE, CENTRAL ELECTRONICS	40-48
2H3	LINES, REEL DRIVE, HYDRAULIC, FRONT	70-50	4F12	MODULE, DATASTORE	155-12
2H1	LINES, REEL DRIVE, HYDRAULIC, L.H.	70-48	4F14	MODULE, DATASTORE	155-14
2F7	LINES, RETURN, HYDRAULIC RESERVOIR	70-4	3C11	MODULE, GRAIN LOSS DISPLAY R.H. CORNERPOST	90-36
2E15	LINES, STEERING R.H. SIDE	60-22	3C11	MODULE, TACHOMETER DISPLAY R.H. CORNERPOST	90-36
2E13	LINES, STEERING, L.H. SIDE	60-20	3I23	MODULE, TAILINGS ELEVATOR SENSOR	125-22
1D19	LINES, TURBOCHARGER OIL	25-42	2F16	MODULE, 6-STACK SOLENOID CONTROL VALVE	70-14
4D22	LINES, UNLOADING AUGER SWING	150-14	1H16	MOISTURE SENSOR	40-70
1H14	LINKAGE, CONCAVE INDICATOR	40-68	4F8	MOISTURE SENSOR BRACKET, YIELD MAPPING	155-8
1H14	LINKAGE, CORN AND SMALL GRAIN CONCAVE	40-68	4F8	MOISTURE SENSOR COVER, YIELD MAPPING	155-8
4C19	LINKAGE, FAN DRIVE SPEED CONTROL	140-46	4F10	MOISTURE SENSOR COVERS - YIELD MAPPING W/O MOISTURE SENSOR	155-10
3F10	LINKAGE, FEEDER HOUSE POSITION SENSOR	100-44	4F10	MOISTURE SENSOR COVERS, YIELD MAPPING	155-10
3C9	LINKAGE, GEARSHIFT	90-34	4F15	MOISTURE SENSOR DECALS, YIELD MAPPING	155-15
4C17	LINKAGE, SPEED CONTROL, FAN DRIVE	140-44	4F16	MOISTURE SENSOR DECALS, YIELD MAPPING	155-17
3I11	LOADING AUGER, CLEAN GRAIN	125-10	4F8	MOISTURE SENSOR MOTOR HARNESS YIELD MAPPING	155-8
3H9	LOUVER, CHAFFER ELEMENT	120-12	4F8	MOISTURE SENSOR MOTOR, YIELD MAPPING	155-8
3H11	LOUVER, CHAFFER EXTENSION ELEMENT	120-14	4F8	MOISTURE SENSOR, YIELD MAPPING	155-8
3H3	LOUVER, PRECLEANING CHAFFER	120-6	3K8	MOTOR AND DISC, CHAFF SPREADER	130-26
3H15	LOUVER, SIEVE ELEMENT	120-18	2C19	MOTOR PISTON CARRIER	50-44
1H21	LOW SHAFT SPEED SENSORS AND BRACKETS	40-75	1H13	MOTOR, ADJUSTING, CONCAVE	40-66
3I5	LOWER AUGER, CLEAN GRAIN	125-4	1H18	MOTOR, ADJUSTING, SEPARATOR FAN DRIVE	40-72
317	LOWER ELEVATOR, CLEAN GRAIN	125-6	3D2	MOTOR, BLOWING	95-2
2D1	LOWER HYDROSTATIC DRIVE OIL LINES AND HOSES (TWO WHEEL DRIVE)	50-52	2C15	MOTOR, CAM LOBE	50-40
3J1	LOWER TAILINGS AUGER AND SHAFT	125-24	2C12	MOTOR, HYDROSTATIC DRIVE	50-36
3J3	LOWER TAILINGS AUGER DRIVE TIGHTENER	125-26	4F8	MOTOR, MOISTURE SENSOR, YIELD MAPPING	155-8
3J1	LOWER TAILINGS AUGER TIGHTENER	125-24			
3I19	LOWER TAILINGS AUGER TROUGH	125-18			
3B20	LUMBAR ASSEMBLY	90-20			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3D4	MOTOR, RECIRCULATION BLOWER	95 - 4	3B22	OPERATOR'S SEATBELT	90 - 23
1H11	MOTOR, REEL SPEED	40 - 64	1F13	OUTLET, CONVENIENCE, KIT	40 - 12
2C14	MOTOR, VALVE, HYDROSTATIC	50 - 38	1C13	OVERHAUL KIT, ENGINE	25 - 6
1G13	MOTOR, WINDSHIELD WIPER	40 - 40	3C13	OVERHEAD CONSOLE	90 - 38
2J12	MOUNTING BRACKETS, FUEL TANK	80 - 36			
3K14	MOUNTING SUPPORT, CHAFF SPREADER	130 - 32		P	
4E18	MOUNTING, GRAIN TANK UNLOADING DRIVE CYLINDER	150 - 36	4F8	PADDLE, MOISTURE SENSOR, YIELD MAPPING	155 - 8
2F4	MOUNTING, HYDRAULIC OIL RESERVOIR	70 - 1	3I24	PADDLE, TAILINGS ELEVATOR CONVEYOR	125 - 23
2G11	MOUNTING, ONE GALLON ACCUMULATOR	70 - 34	3J5	PADDLE, UPPER TAILINGS AUGER	125 - 28
2F20	MOUNTING, SOLENOID CONTROL VALVE MODULE, 4-STACK	70 - 18	3J16	PADDLED BLADE, FINE CUT CHOPPER	130 - 8
2F18	MOUNTING, SOLENOID CONTROL VALVE, 5-STACK	70 - 16	3K12	PAN, CHAFF SPREADER	130 - 30
3K2	MOUNTING, STRAW SPREADER AND GUARD	130 - 20	1D11	PAN, OIL	25 - 32
4F18	MOUNTING, TRACK FRAME	160 - 2	3H19	PAN, SHAKER	120 - 22
4D24	MOUNTING, UNLOADING AUGER SWING CYLINDER	150 - 16	3B23	PANEL, ARMREST	90 - 24
2D16	MUD SHIELDS, POWERED REAR WHEELS	50 - 67	3C1	PANEL, ARMREST	90 - 26
1E21	MUFFLER AND EXHAUST PIPE	30 - 20	3B8	PANEL, CAB INTERIOR	90 - 8
	N		3B6	PANEL, FLOOR	90 - 6
1E3	NOZZLE, FUEL INJECTION	30 - 2	2I17	PANEL, GULLWING, LEFT REAR	80 - 16
1E9	NOZZLE, FUEL INJECTION	30 - 8	2I13	PANEL, LEFT FRONT AND DOOR	80 - 12
	O		2I21	PANEL, RIGHT FRONT	80 - 20
1D14	O-RING KIT, WATER PUMP	25 - 36	2D19	PARKING BRAKE PEDAL AND SEAL	60 - 2
3D12	O-RING, AIR CONDITIONER HOSE	95 - 12	2D21	PEDAL, BRAKE	60 - 4
1D8	OIL COOLER ADAPTER AND COVER	25 - 28	3C7	PEDAL, REVERSER FOOT CONTROL, FEEDER HOUSE	90 - 32
2F11	OIL COOLER AND AIR CONDITIONING	70 - 8	1H20	PICK-UP, MAGNETIC (ENGINE)	40 - 74
1D7	OIL COOLER BYPASS ADAPTER	25 - 27	2G17	PICKUP DRIVE, REEL AND BELT	70 - 40
1D7	OIL COOLER BYPASS TUBES	25 - 27	1C15	PISTON RINGS	25 - 8
2D5	OIL COOLER LINES AND HOSES, HYDROSTATIC	50 - 56	2C19	PISTON, CAM AND CARRIER	50 - 44
1D8	OIL COOLER, ENGINE	25 - 28	1C15	PISTON, ENGINE	25 - 8
3D20	OIL COOLER, FEEDER HOUSE GEARCASE	100 - 4	4F20	PIVOT BUSHINGS, MAIN FRAME	160 - 4
1B24	OIL DRAIN, ENGINE CRANKCASE	20 - 22	2C20	PIVOT, CAPS AND YOKE (STEERABLE MOTOR)	50 - 46
4B3	OIL FILTER ASSEMBLY, ENGINE GEARCASE	140 - 2	4E13	PLATE, CROSS AUGER BEARING, L.H.	150 - 30
1D9	OIL FILTER, ENGINE	25 - 30	1E17	PLATFORM, ENGINE	30 - 16
2D1	OIL HOSES, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE)	50 - 52	2J14	PLATFORM, ENGINE ACCESS	80 - 38
2D9	OIL HOSES, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE)	50 - 60	4H16	PORTUGUESE DECALS AND LABELS	170 - 23
2D3	OIL HOSES, UPPER, HYDROSTATIC DRIVE (FOUR WHEEL DRIVE)	50 - 54	4F2	POSITION RECEIVER BRACKET YIELD MAPPING	155 - 2
2D1	OIL LINES HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE)	50 - 52	4F2	POSITION RECEIVER COVER YIELD MAPPING	155 - 2
2D9	OIL LINES HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE)	50 - 60	4F2	POSITION RECEIVER, YIELD MAPPING	155 - 2
1D11	OIL PAN DRAIN VALVE	25 - 32	3C13	POTENTIOMETER	90 - 38
1D11	OIL PAN DRAIN VALVE AND GASKET	25 - 32	1B22	POWER CORD, ENGINE BLOCK COOLANT HEATER	20 - 20
1D8	OIL PRESSURE REGULATING VALVE	25 - 28	3H5	PRE-CLEANER CHAFFER FRAME	120 - 8
1D9	OIL PRESSURE REGULATING VALVE	25 - 30	3H7	PRE-CLEANER CHAFFER FRAME ARMS	120 - 10
1B21	OIL PRESSURE SENSOR	20 - 19	3H3	PRE-CLEANING CHAFFER	120 - 6
1C16	OIL PUMP DRIVE GEAR	25 - 9	2G13	PRESSURE GAUGE, ACCUMULATOR	70 - 36
1D4	OIL PUMP DRIVE GEAR	25 - 24	4B5	PRESSURE REGULATOR, ENGINE GEARCASE	140 - 4
1D6	OIL PUMP INTAKE GASKET	25 - 26	4B3	PRESSURE SWITCH, ENGINE GEARCASE OIL FILTER ASSEMBLY	140 - 2
1D4	OIL PUMP, ENGINE	25 - 24	2F5	PRESSURE, HYDRAULIC HOSES	70 - 2
1C22	OIL SEAL, CRANKSHAFT FRONT	25 - 15	4B18	PRIMARY COUNTERSHAFT, SUPPORTS AND VARI- ABLE SHEAVE	140 - 18
1C20	OIL SEAL, REAR	25 - 13	1E8	PRIMER, FUEL TRANSFER	30 - 7
3D11	OIL, AIR CONDITIONER COMPRESSOR	95 - 11	4F4	PROCESSOR, MOBILE, YIELD MAPPING	155 - 4
1C8	OIL, ENGINE (TORQ-GARD, PLUS-50)	25 - 1	1B20	PULLEY, AIR CONDITIONER COMPRESSOR FAN	20 - 18
3B23	OPERATOR'S ARMREST PANEL	90 - 24	1D24	PULLEY, CRANKSHAFT	25 - 48
3C1	OPERATOR'S ARMREST PANEL	90 - 26	3J3	PULLEY, LOWER TAILINGS AUGER TIGHTENER	125 - 26
3B20	OPERATOR'S SEAT AND BACKREST	90 - 20	4C7	PULLEY, SECONDARY COUNTERSHAFT DRIVE	140 - 34
			3E5	PULLEY, VARIABLE SPEED DRIVE TIGHTENER	100 - 14
			4B11	PUMP DRIVE AND SEPARATOR, GEARCASE	140 - 10
			4B9	PUMP DRIVE SHAFT AND SEPARATOR DRIVE WET-CLUTCH, GEARCASE	140 - 8
			2G19	PUMP MOUNTING SHEAVE, REEL AND BELT PICKUP DRIVE	70 - 42
			2H20	PUMP, CHAFF SPREADER	70 - 68

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G17	PUMP, FEEDER HOUSE AND REEL DRIVE	70 - 40	2D23	RESERVOIR, BRAKE LINES, MASTER CYLINDER	60 - 6
1E5	PUMP, FUEL	30 - 4	2F4	RESERVOIR, HYDRAULIC/HYDROSTATIC	70 - 1
1E15	PUMP, FUEL	30 - 14	1G11	RESERVOIR, WINDSHIELD WASHER.....	40 - 38
1E8	PUMP, FUEL TRANSFER	30 - 7	3F8	RETURN FLOOR, FEEDER HOUSE	100 - 42
2C5	PUMP, HYDROSTATIC DRIVE.....	50 - 28	2F7	RETURN LINES, HYDRAULIC	70 - 4
2C9	PUMP, HYDROSTATIC DRIVE CHARGE	50 - 32	3C7	REVERSER FOOT CONTROL, FEEDER HOUSE.....	90 - 32
2F9	PUMP, MAIN HYDRAULIC	70 - 6	3D22	REVERSER GEAR BOX (HIGH CAPACITY)	100 - 6
1D4	PUMP, OIL ENGINE	25 - 24	3D24	REVERSER GEAR BOX, HI CAPACITY	100 - 8
2G17	PUMP, REEL/FEEDER HOUSE DRIVE	70 - 40	3E1	REVERSER GEAR BOX, STANDARD	100 - 10
2E7	PUMP, STEERING.....	60 - 14	2I11	RIGHT SIDE SHIELD ASSEMBLY	80 - 10
2B18	PUMP, TRANSMISSION	50 - 16	1C21	RING GEAR, FLYWHEEL	25 - 14
1D14	PUMP, WATER	25 - 36	1C15	RING, PISTON.....	25 - 8
1G11	PUMP, WINDSHIELD WASHER	40 - 38	1D1	ROCKER ARM AND SHAFT.....	25 - 20
1D1	PUSH RODS	25 - 20	1D2	ROCKER ARM COVER.....	25 - 21
			1C15	ROD, CONNECTING	25 - 8
			1D1	ROD, PUSH	25 - 20
	R		4H17	ROMANIAN DECALS AND LABELS.....	170 - 24
1F23	R.H. MAIN WIRING HARNESS		1H23	ROOF, CAB LIGHTS	40 - 77
	W/O GREENSTAR	40 - 24	3B10	ROOF, INTERIOR CAB.....	90 - 10
1G1	R.H. MAIN WIRING HARNESS W/GREENSTAR.....	40 - 28	1B6	ROTARY SCREEN DOOR AND SCREEN.....	20 - 4
2E15	R.H. SIDE STEERING LINES	60 - 22	1B4	ROTARY SCREEN DRIVE AND IDLER ARMS	20 - 2
1B12	RADIATOR AND CAP	20 - 10	3J16	ROTOR, FINE CUT PADDLED BLADE CHOPPER.....	130 - 8
2J1	RADIATOR DOOR AND HANDRAIL.....	80 - 24	3J14	ROTOR, FINE CUT STRAIGHT BLADE CHOPPER	130 - 6
1B8	RADIATOR SHELL AND SEALS.....	20 - 6	3J12	ROTOR, TRI-ROD CHOPPER	130 - 4
3C15	RADIO, SPEAKERS AND ANTENNA	90 - 40	4H18	RUSSIAN DECALS AND LABELS	170 - 25
1B6	RAKE, ROTARY SCREEN	20 - 4			
3G3	RASP BAR THRESHING CYLINDER.....	110 - 10		S	
4G1	REAR ARM, TENSION CYLINDER & IDLER AXLE	160 - 10	3C17	SAFETY CHAIN, CAB PLATFORM.....	90 - 42
2B5	REAR AXLE SPINDLE HOUSING	50 - 2	4G20	SAFETY DECALS AND LOCATIONS.....	170 - 2
2E22	REAR AXLE SPINDLES (HEAVY DUTY).....	60 - 30	4G22	SAFETY DECALS AND LOCATIONS.....	170 - 4
2E20	REAR AXLE SPINDLES (REGULAR DUTY)	60 - 28	4G24	SAFETY DECALS AND LOCATIONS.....	170 - 6
2B4	REAR AXLE SUPPORT.....	50 - 1	4H1	SAFETY DECALS AND LOCATIONS.....	170 - 8
2B6	REAR AXLE, ADJUSTABLE	50 - 3	4H3	SAFETY DECALS AND LOCATIONS.....	170 - 10
2B5	REAR AXLE, FIXED	50 - 2	4H11	SAFETY DECALS, RUBBER TRACK	170 - 18
2I19	REAR CORNER SHEET, L.H.....	80 - 18	4H11	SAFETY LABELS, RUBBER TRACK	170 - 18
2J8	REAR HOOD	80 - 32	4E23	SAMPLING TROUGH, GRAIN TANK	150 - 41
2J6	REAR LADDER LANDING LATCH ARM	80 - 30	3F8	SCOOP, FEEDER HOUSE RETURN	100 - 42
1I1	REAR LAMP ASSEMBLY (AMBER)	40 - 80	1B6	SCREEN DOOR, ROTARY	20 - 4
2J14	REAR LAMP, ENGINE ACCESS PLATFORM	80 - 38	1B4	SCREEN DRIVE, ROTARY	20 - 2
1C20	REAR OIL SEAL	25 - 13	2D19	SEAL AND BRAKE PEDAL, PARKING	60 - 2
1C20	REAR OIL SEAL GASKET	25 - 13	3K12	SEAL AND PAN, CHAFF SPREADER	130 - 30
1C20	REAR OIL SEAL HOUSING	25 - 13	1B8	SEAL AND RADIATOR SHELL.....	20 - 6
2E17	REAR STEERING LINES AND HOSES	60 - 24	2C12	SEAL KIT, HYDROSTATIC DRIVE MOTOR	50 - 36
1C3	REAR SUPPORT, ENGINE MOUNTS	20 - 26	3D11	SEAL, AIR CONDITIONER COMPRESSOR	95 - 11
3I15	REAR TAILINGS SHIELD, LEFT SIDE	125 - 14	3B6	SEAL, CAB SIDE AND REAR.....	90 - 6
1I2	REAR TURN AND TAIL LIGHTS (RED).....	40 - 81	2C15	SEAL, CAM LOBE MOTOR.....	50 - 40
2B14	REAR WHEELS (4-WHEEL DRIVE/CAM LODE MOTOR).....	50 - 11	3E17	SEAL, FEEDER HOUSE - CONTOUR MASTER.....	100 - 26
2B13	REAR WHEELS AND WHEEL WEIGHTS	50 - 10	1C22	SEAL, FRONT OIL.....	25 - 15
3D9	RECEIVER-DRYER, AIR CONDITIONER.....	95 - 9	1C20	SEAL, REAR OIL	25 - 13
4F2	RECEIVER, POSITION, YIELD MAPPING	155 - 2	1D14	SEAL, TUBE, WATER PUMP	25 - 36
2G21	REEL DRIVE FLOW CONTROL VALVE	70 - 44	1D14	SEAL, WATER PUMP OIL	25 - 36
2H1	REEL DRIVE HYD. LINES L.H.	70 - 48	3B20	SEAT AND BACKREST, OPERATOR'S.....	90 - 20
2H3	REEL DRIVE HYDRAULIC LINES AND HOSES	70 - 50	3B16	SEAT CONSOLE, PASSENGER.....	90 - 16
2H7	REEL FORE-AND-AFT HYDRAULIC LINES AND HOSES, FRONT	70 - 54	3B16	SEAT CUSHIONS, PASSENGER	90 - 16
2H5	REEL FORE-AND-AFT HYDRAULIC LINES, L.H.	70 - 52	3B22	SEATBELT, OPERATOR'S	90 - 23
2H9	REEL LIFT LINES AND HOSES.....	70 - 56	4C7	SECONDARY COUNTERSHAFT DRIVE	140 - 34
2G3	REEL LIFT, SOLENOID CONTROL VALVE.....	70 - 26	4C7	SECONDARY COUNTERSHAFT DRIVE PULLEY.....	140 - 34
2G23	REEL PUMP HOSES, HYDRAULIC	70 - 46	1H19	SENSING SWITCH, STRAW WALKER	40 - 73
2G23	REEL PUMP HYDRAULIC HOSES.....	70 - 46	1H21	SENSOR AND BRACKET, LOW SHAFT SPEED	40 - 75
1H11	REEL SPEED MOTOR	40 - 64	3D2	SENSOR, AIR CONDITIONER AND HEATER.....	95 - 2
1G22	RELAY PANEL AND CIRCUIT BREAKERS.....	40 - 50	3D4	SENSOR, AIR CONDITIONER AND HEATER.....	95 - 4
2F22	RELIEF VALVE, SOLENOID, CONTOUR MASTER	70 - 20	3C1	SENSOR, ARMREST CONTROL PANEL.....	90 - 26
2F22	RELIEF VALVE, SOLENOID, UNLOAD MODULE	70 - 20	1H14	SENSOR, CONCAVE INDICATOR	40 - 68
2F7	RESERVOIR LINES AND HOSES	70 - 4	1H20	SENSOR, ENGINE SPEED.....	40 - 74
			3F10	SENSOR, FEEDER HOUSE POSITION.....	100 - 44

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1G19	SENSOR, FULL BIN	40-46	2G19	SHEAVE, MOUNTING, PUMP, REEL AND BELT PICKUP DRIVE	70-42
1G16	SENSOR, GRAIN LOSS MONITOR	40-43	3D18	SHEAVE, MOUNTINGS, FRONT VARIABLE DRIVE	100-2
1G19	SENSOR, GRAIN TANK FULL BIN	40-46	1B4	SHEAVE, ROTARY SCREEN DRIVE	20-2
2B22	SENSOR, GROUND SPEED	50-20	3I3	SHEAVE, UPPER CLEAN GRAIN ELEVATOR	125-2
3J20	SENSOR, MAGNETIC PICKUP	130-12	3F14	SHEAVE, UPPER DRIVE SHAFT, FEEDER HOUSE (FIXED SPEED WITH REVERSER)	100-48
4F6	SENSOR, MASS FLOW, YIELD MAPPING	155-6	3E17	SHELL, FEEDER HOUSE-CONTOUR MASTER	100-26
1H16	SENSOR, MOISTURE	40-70	1B8	SHELL, RADIATOR AND SEALS	20-6
4F8	SENSOR, MOISTURE, YIELD MAPPING	155-8	3K10	SHIELD AND HANDLES, CHAFF SPREADER	130-28
3C13	SENSOR, OVERHEAD CONSOLE	90-38	2I9	SHIELD ASSEMBLY, FRONT, RIGHT SIDE	80-8
1H9	SENSOR, SPEED, BACKSHAFT	40-62	2I7	SHIELD ASSEMBLY, LEFT SIDE	80-6
3J20	SENSOR, STRAW CHOPPER	130-12	2I11	SHIELD ASSEMBLY, RIGHT SIDE	80-10
3I23	SENSOR, TAILINGS ELEVATOR	125-22	2J3	SHIELD, DRIVE, R.H. REAR	80-27
1E5	SENSOR, TEMPERATURE	30-4	2D15	SHIELD, FINAL DRIVE SHAFT	50-66
1C4	SENSOR, TEMPERATURE, ENGINE CYLINDER	20-27	1D21	SHIELD, HEAT, EXHAUST MANIFOLD	25-44
4B11	SEPARATOR AND PUMP DRIVE, GEARCASE	140-10	3E11	SHIELD, L.H. DRIVE - W/AIRFLOW	100-20
3G2	SEPARATOR CURTAIN (RASP BAR CYLINDER)	110-9	3E9	SHIELD, L.H. DRIVE - W/O AIRFLOW	100-18
3H21	SEPARATOR CURTAIN, SPIKE-TOOTH CYLINDER	120-24	2I5	SHIELD, LEFT SIDE FRONT	80-4
4B9	SEPARATOR DRIVE WET-CLUTCH AND PUMP DRIVE SHAFT, GEARCASE	140-8	2D16	SHIELD, MUD - POWERED REAR WHEELS	50-67
4C15	SEPARATOR FAN DRIVE	140-42	3E13	SHIELD, R.H. DRIVE	100-22
1H18	SEPARATOR FAN DRIVE ADJUSTING MOTOR	40-72	3I15	SHIELD, REAR TAILINGS LEFT SIDE	125-14
2I3	SEPARATOR FRAME	80-2	4D1	SHIELD, STRAW CHOPPER DRIVE	140-52
3F20	SEPARATOR, STONE TRAP AND DOOR	110-2	3I17	SHIELD, TAILINGS UPPER REAR	125-16
1F6	SERVICE KIT, ELECTRICAL CONNECTORS	40-4	4D3	SHIELD, UPPER TAILINGS AUGER DRIVE	140-54
1F8	SERVICE KIT, ELECTRICAL CONNECTORS	40-6	2J8	SHIELD, WIRING HARNESS	80-32
2J10	SERVICE LIGHT, ENGINE COMPARTMENT	80-34	2B17	SHIFTER CAM, TRANSMISSION AND DIFFERENTIAL	50-14
2I15	SERVICE LIGHT, L.H.	80-14	2B16	SHIFTER FORKS, TRANSMISSION	50-13
2I23	SERVICE LIGHT, R.H. GULLWING	80-22	4F18	SHIPPING FRAME	160-2
2J1	SERVICE LIGHT, RADIATOR DOOR	80-24	3G22	SHOE GRAIN SUPPLY AUGER CLEANOUT DOOR	120-1
2C7	SERVO, HYDROSTATIC PUMP	50-30	3G23	SHOE GRAIN SUPPLY AUGERS	120-2
2B7	SHAFT, AXLE	50-4	4G11	SHOES AND DRUM, BRAKE	160-22
3G13	SHAFT, BEATER AND DRIVE BELT	110-20	2E5	SHOES, BRAKE	60-12
2C15	SHAFT, CAM LOBE MOTOR	50-40	1C11	SHORT BLOCK	25-4
2B22	SHAFT, DIFFERENTIAL	50-20	1D22	SHORT BLOCK GASKET KIT	25-46
3F16	SHAFT, DRIVE, FRONT (FIXED SPEED WITH REVERSER)	100-50	1A5	SHORT BLOCK SERIAL NUMBER IDENTIFICATION	10-4
3F16	SHAFT, DRIVE, FRONT, SHEAVE AND MOUNTINGS (FIXED SPEED WITH REVERSER)	100-50	1E5	SHUT-OFF SOLENOID	30-4
3F14	SHAFT, DRIVE, UPPER, SHEAVE AND MOUNTING (FIXED SPEED WITH REVERSER)	100-48	3B6	SIDE AND REAR CAB SEALS	90-6
2B24	SHAFT, FINAL DRIVE	50-22	1I3	SIDE FINDER LIGHTS	40-82
2C1	SHAFT, FINAL DRIVE	50-24	2J8	SIDE PANEL, REAR HOOD	80-32
2C12	SHAFT, HYDROSTATIC DRIVE MOTOR	50-36	4C11	SIEVE AND CHAFFER DRIVE, CONVEYOR AUGERS AND STRAW WALKER	140-38
2C5	SHAFT, HYDROSTATIC PUMP	50-28	3H15	SIEVE ELEMENT	120-18
3J1	SHAFT, LOWER TAILINGS AUGER	125-24	3H17	SIEVE FRAME	120-20
1D1	SHAFT, ROCKER ARM	25-20	2G9	SINGLE ACCUMULATOR, ONE HALF GALLON	70-32
4B20	SHAFT, SINGLE RANGE CYLINDER DRIVE	140-21	2F16	SIX STACK SOLENOID CONTROL VALVE MODULE	70-14
2B20	SHAFT, TRANSMISSION PINION	50-18	2E3	SLAVE CYLINDER, BRAKE	60-10
3I3	SHAFT, UPPER CLEAN GRAIN ELEVATOR	125-2	3E19	SLIP CLUTCH, FEEDER HOUSE SHAFT	100-28
2B8	SHAFTS, DRIVE	50-5	2J8	SLOW MOVING VEHICLE SIGN	80-32
3H19	SHAKER PAN	120-22	2J8	SMV SIGN	80-32
3G1	SHEAR BAR, SEPARATOR CYLINDER	110-8	2F22	SOLENOID CONTROL UNLOAD RELIEF VALVE	70-20
4C19	SHEAVE LINKAGE, FAN DRIVE SPEED CONTROL	140-46	2F15	SOLENOID CONTROL VALVE BRACKETS	70-12
1H3	SHEAVE, ALTERNATOR (185 AMP)	40-56	2F16	SOLENOID CONTROL VALVE MODULE, 6-STACK	70-14
1H1	SHEAVE, ALTERNATOR (95 AMP)	40-54	2G1	SOLENOID CONTROL VALVE UNBALANCED LOAD (HEADER LIFT MODULE)	70-24
4C13	SHEAVE, BEATER DRIVE AND TIGHTENER	140-40	2G5	SOLENOID CONTROL VALVE, AUGER SWING	70-28
3I13	SHEAVE, CLEAN GRAIN ELEVATOR GEARCASE	125-12	2G5	SOLENOID CONTROL VALVE, REEL FORE/AFT	70-28
1B16	SHEAVE, ENGINE DRIVE	20-14	2G3	SOLENOID CONTROL VALVE, REEL LIFT	70-26
1B16	SHEAVE, ENGINE FAN	20-14	2F20	SOLENOID VALVE MODULE ASSEMBLY, 4-STACK	70-18
1B14	SHEAVE, ENGINE FAN DRIVE	20-12	2F18	SOLENOID VALVE MODULE ASSEMBLY, 5-STACK	70-16
3F12	SHEAVE, FEEDER HOUSE DUST PAN, L.H.	100-46	2C24	SOLENOID, CONTROL VALVE	50-51
3F6	SHEAVE, FEEDER HOUSE, UPPER COUNTERSHAFT, VARIABLE DRIVE	100-40	1E5	SOLENOID, FUEL SHUT-OFF	30-4
3F16	SHEAVE, FRONT DRIVE SHAFT (FIXED SPEED WITH REVERSER)	100-50	2F23	SOLENOID, MAIN VALVE, HEADER CONTROL	70-21
3J1	SHEAVE, LOWER TAILINGS TIGHTENER	125-24	1E5	SOLENOID, SHUT-OFF	30-4
			1E13	SOLENOID, STARTING AID	30-12