

HP8673

-UN-23JUN99



*JOHN DEERE 9650 STS SELF-PROPELLED COMBINE™ WITH 90 SERIES CORN HEAD  
MANUFACTURED (1999- )*

*(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)*

*COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS, USA. ALL RIGHTS RESERVED.*

## NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE 900 SERIES PLATFORM PARTS CATALOG - PC-2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 40 SERIES CORN HEAD PARTS CATALOG - PC-1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE 50A SERIES ROW-CROP HEAD PARTS CATALOG - PC-1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE THREE-ROLLER BELT PICKUP PARTS CATALOG - PC-2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE 918 AND 920 DRAPER PLATFORMS PARTS CATALOG - PC-2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 90 SERIES CORN HEAD PARTS CATALOG - PC-2404.

## IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9650 STS SELF-PROPELLED COMBINE. VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

## PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION NUMBER (PIN) PLATE IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX.  
AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9650X685000  
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9650 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

900000 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

## PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES THE PART MAY BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

### SHORT BLOCK SERIAL NUMBER PLATE

( -RGSB076882500)

RGP3513 -UN-01JAN94



RGP3513

THE REPLACEMENT SHORT BLOCK ASSEMBLY HAS A SERIAL NUMBER PLATE ATTACHED. THE ORIGINAL ENGINE SERIAL NUMBER MUST BE STAMPED ONTO THE NEW PLATE IN THE BLANK SPACE PROVIDED, AS A REFERENCE FOR YOUR DEALER. THE PLATE CAN BE ATTACHED WITH (2) 37H44 DRIVE SCREWS.

- |                                       |                            |
|---------------------------------------|----------------------------|
| 1. DESIGNATES ENGINE MANUFACTURER     | RG - WATERLOO ENGINE WORKS |
| 2. DESIGNATES REPLACEMENT SHORT BLOCK | SB                         |
| 3. DESIGNATES LITERS                  | XXX- 081 (8.1)             |
| 4. DESIGNATES THE PRODUCTION DATE     | 8825                       |
| 5. DESIGNATES COMPONENT SEQUENCE      | 00                         |

# 1A6

9650 STS AND 9750 STS SELF-PROPELLED COMBINES

## TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE

RGP5228

-UN-21JUN99



RGP5228

### FIRST LINE

RG - WATERLOO ENGINE WORKS

6

081 (8.1 LITERS)

H - AIR-TO-AIR

H

XXXXXX

### SECOND LINE

6081HH005

6081HH006

### DEFINES

DESIGNATES ENGINE MANUFACTURER.

DESIGNATES NUMBER OF CYLINDERS.

DESIGNATES LITER DISPLACEMENT.

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

DESIGNATES HARVESTER VEHICLE.

DESIGNATES ENGINE SERIAL NUMBER.


### APPLICATION

9750

9650

## SHORT BLOCK SERIAL NUMBER IDENTIFICATION

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490995

- |                                   |         |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED     | 09      |
| 3. DESIGNATES YEAR ASSEMBLED      | 95      |

## **DIRECTION ARROW**

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

## **BOX-ENCLOSED ILLUSTRATIONS**

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

## **KITS**

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

## **JDM REMANUFACTURED COMPONENTS**

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

## **BOLT AND CAP SCREW STRENGTH IDENTIFICATION**

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

## **SI UNITS OF MEASURE**

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

## TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™  
DIAL-A-MATIC™  
HARVESTRAK™  
CONTOUR MASTER™

POSI-TORQ™  
TORQ-GARD SUPREME®  
QUIK-TATCH™

## CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

## FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

## COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.



## SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE ACCESSORIES

SECTION 25 - ENGINE

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - BODY AND SHIELDS

SECTION 90 - OPERATOR'S STATION

SECTION 95 - AIR CONDITIONING AND HEATING

SECTION 110 - FEEDER HOUSE

SECTION 120 - THRESHING AND SEPARATION

SECTION 125 - CLEANING SHOE

SECTION 130 - ELEVATORS

SECTION 135 - RESIDUE DISPOSAL

SECTION 140 - DRIVES

SECTION 150 - GRAIN TANK AND UNLOADING AUGER

SECTION 155 - GREENSTAR YIELD MAPPING AND MONITOR SYSTEMS

SECTION 160 - RUBBER TRACK SYSTEM

SECTION 170 - DECALS

SECTION 180 - NUMERICAL INDEX

## ALPHABETICAL INDEX

GRID	A	PAGE	GRID	PAGE	
3B20	A/C COMPRESSOR HARDWARE R134A .....	95 - 14	3D7	ARM, FEEDER HOUSE CONVEYOR..... 110 - 30	
3B17	A/C COMPRESSOR MANIFOLD.....	95 - 11	3C17	ARM, FEEDER HOUSE DRIVE TIGHTENER .....	110 - 16
3B17	A/C COMPRESSOR R134A .....	95 - 11	3D5	ARM, FEEDER HOUSE FLOOR.....	110 - 28
4D9	ABSORBER, AIR SUSPENSION (RUBBER TRACK) ....	160 - 8	3C15	ARM, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER.....	110 - 14
3D24	ACCELERATOR WINGS .....	120 - 4	4D7	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY (RUBBER TRACK) .....	160 - 6
2I8	ACCESS DOOR, ENGINE.....	80 - 34	1B10	ARM, IDLER, ROTARY SCREEN .....	20 - 4
2H24	ACCESS DOOR, REAR.....	80 - 24	2D21	ARM, PARKING BRAKE .....	60 - 2
2G13	ACCUMULATOR PRESSURE GAUGE.....	70 - 42	3J8	ARM, PRIMARY COUNTERSHAFT .....	140 - 30
2G11	ACCUMULATOR, ONE GALLON .....	70 - 40	4D11	ARM, REAR (RUBBER TRACK) .....	160 - 10
2G12	ACCUMULATOR, ONE HALF GALLON .....	70 - 41	1D4	ARM, ROCKER .....	25 - 22
1H17	ACTUATOR, STRAW CHOPPER .....	40 - 64	1B8	ARM, ROTARY SCREEN DRIVE .....	20 - 2
1D11	ADAPTER, OIL COOLER .....	25 - 30	3E21	ARM, SHAKER PAN .....	120 - 28
1D10	ADAPTER, OIL COOLER BYPASS .....	25 - 29	3J21	ARM, SHOE/CONVEYOR AUGER DRIVE IDLER ASSEMBLY .....	140 - 43
1B5	ADHESIVE, ROCKER ARM COVER GASKET .....	25 - 23	3F14	ARM, SIEVE ELEMENT.....	125 - 14
1B23	ADJUSTABLE FAN DRIVE .....	20 - 18	2D3	ARM, STEERING .....	50 - 48
4D7	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM (RUBBER TRACK) .....	160 - 6	2J16	ARM, STEERING COLUMN (LOWER) .....	90 - 28
2B11	ADJUSTABLE REAR AXLE (NON-POWERED) .....	50 - 3	3H12	ARM, STRAW CHOPPER JACKSHAFT .....	135 - 12
2B10	ADJUSTABLE REAR AXLE (POWERED) .....	50 - 2	2G15	ARM, STRAW SPREADER .....	70 - 44
3E14	ADJUSTING ASSEMBLY, CONCAVE.....	120 - 20	3J19	ARM, TAILINGS ELEVATOR DRIVE IDLER ASSEMBLY .....	140 - 41
3E16	ADJUSTING ASSEMBLY, CONCAVE.....	120 - 22	3K6	ARM, UNLOADER DRIVE IDLER ASSEMBLY .....	140 - 54
1D22	AFTERCOOLER AND INTAKE MANIFOLD SENSOR....	25 - 43	2J12	ARMREST CONTROL PANEL .....	90 - 24
1E25	AIR CLEANER .....	30 - 21	2J14	ARMREST CONTROL PANEL (CONTINUED).....	90 - 26
1F1	AIR CLEANER BRACKETS, SUPPORTS.....	30 - 22	1G9	ARMREST WIRING HARNESS.....	40 - 32
1E24	AIR CLEANER HOSES .....	30 - 20	2J9	ARMREST, OPERATOR'S SEAT .....	90 - 20
3B10	AIR CONDITIONER AND HEATER HOUSING, LOWER .....	95 - 4	3F6	ARMS, CHAFFER FRAME .....	125 - 6
3B8	AIR CONDITIONER AND HEATER HOUSING, UPPER.....	95 - 2	3K3	ARMS, STRAW CHOPPER DRIVE IDLER ASSEMBLY	140 - 50
3B8	AIR CONDITIONER AND HEATER TEMPERATURE SENSOR .....	95 - 2	1G17	ARMS, WINDSHIELD WIPER .....	40 - 40
1C2	AIR CONDITIONER COMPRESSOR BRACKETS .....	20 - 22	1F3	ASPIRATOR HOSE .....	30 - 24
3B18	AIR CONDITIONER COMPRESSOR HOSE .....	95 - 12	1H13	ASSEMBLY, CLUTCH (STARTER).....	40 - 60
2F1	AIR CONDITIONER CONDENSER AND OIL COOLER .....	70 - 6	2F13	ASSEMBLY, SIX STACK SOLENOID CONTROL VALVE .....	70 - 18
3B13	AIR CONDITIONING AND HEATER DUCTS .....	95 - 7	2E11	ATTENUATOR .....	60 - 16
3B16	AIR CONDITIONING SYSTEM EVAPORATOR HEATER.....	95 - 10	3F2	AUGER BED ASSEMBLY .....	125 - 2
3B15	AIR CONDITIONING SYSTEM RECEIVER-DRYER .....	95 - 9	3K4	AUGER COUNTERSHAFT DRIVE, UNLOADING .....	140 - 52
3B14	AIR CONDITIONING SYSTEM WATER VALVE ASSEMBLY .....	95 - 8	3G6	AUGER HOUSING, LOADING, UPPER CLEAN GRAIN .....	130 - 10
1G13	AIR CONDITIONING WIRING HARNESS .....	40 - 36	3F4	AUGER SHAFT AND BEARINGS.....	125 - 4
1B17	AIR COOLER, CHARGE .....	20 - 12	4C5	AUGER, CROSS .....	150 - 24
2I10	AIR DEFLECTORS, ENGINE .....	80 - 36	4B21	AUGER, HORIZONTAL UNLOADING (17- AND 20-FT.).....	150 - 16
1E24	AIR DUCT, AIR CLEANER .....	30 - 20	3G10	AUGER, LOADING, CLEAN GRAIN .....	130 - 14
3B10	AIR DUCT, BLOWER.....	95 - 4	3G20	AUGER, LOWER TAILINGS .....	130 - 24
3B8	AIR DUCT, INTAKE .....	95 - 2	3F23	AUGER, LOWER, CLEAN GRAIN .....	130 - 2
1B13	AIR DUCT, RADIATOR FRAME .....	20 - 8	3G16	AUGER, UPPER TAILINGS ELEVATOR .....	130 - 20
1B11	AIR DUCT, ROTARY SCREEN DOOR.....	20 - 6	4B19	AUGER, VERTICAL UNLOADING .....	150 - 14
2J7	AIR SEAT SUSPENSION .....	90 - 18	2B12	AXLE SPACERS .....	50 - 4
4D9	AIR SUSPENSION (RUBBER TRACK).....	160 - 8	2B13	AXLE SPACERS .....	50 - 5
2J7	AIR SUSPENSION, SEAT .....	90 - 18	2B11	AXLE, ADJUSTABLE REAR (NON-POWERED) .....	50 - 3
1H11	ALTERNATOR ADJUSTING STRAP.....	40 - 58	4D14	AXLE, BOGEY WHEEL (RUBBER TRACK).....	160 - 14
1H11	ALTERNATOR SUPPORT.....	40 - 58	4D11	AXLE, IDLER (RUBBER TRACK) .....	160 - 10
1H9	ALTERNATOR, SHEAVE AND BELT (185 AMP) .....	40 - 56	2B10	AXLE, REAR, ADJUSTABLE (POWERED) .....	50 - 2
1H7	ALTERNATOR, SHEAVE AND BELT (95 AMP) .....	40 - 54	2B9	AXLE, REAR, FIXED (NON-POWERED) .....	50 - 1
2K3	ANTENNA, SPEAKERS AND RADIO .....	90 - 40	2E15	AXLE, REAR, SPINDLES (HEAVY DUTY).....	60 - 20
3K1	ARM, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER .....	140 - 48	<b>B</b>		
3J13	ARM, CLEAN GRAIN ELEVATOR DRIVE IDLER ASSEMBLY .....	140 - 35	2J9	BACKREST, OPERATOR'S.....	90 - 20
3J22	ARM, DISCHARGE BEATER DRIVE IDLER ASSEMBLY .....	140 - 44	2E17	BALL JOINT, STEERING TIE ROD .....	60 - 22
3J17	ARM, FAN DRIVE .....	140 - 39	2I22	BARRIERS, CAB INTERIOR .....	90 - 8
3J10	ARM, FEED ACCELERATOR DRIVE IDLER .....	140 - 32	2I24	BASE, DOME LIGHT .....	90 - 10
			1E14	BASE, FUEL FILTER.....	30 - 10
			1D12	BASE, OIL FILTER .....	25 - 32

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H4	BATTERIES AND CABLES .....	40 - 51	1G17	BLADE, WIPER (LONG) .....	40 - 40
1C21	BEARING KIT, UNDERSIZED MAIN BEARING CRANKSHAFT .....	25 - 13	3F16	BLADES, CLEANING FAN ASSEMBLY .....	125 - 16
4D16	BEARING, BOGEY WHEEL (RUBBER TRACK) .....	160 - 16	3H18	BLADES, STRAW SPREADER .....	135 - 18
4D14	BEARING, BOGEY WHEEL AXLE (RUBBER TRACK) .....	160 - 14	1C14	BLOCK, SHORT .....	25 - 6
3E8	BEARING, ROTOR .....	120 - 13	3B10	BLOWER AIR DUCT .....	95 - 4
3H22	BEARING, STRAW SPREADER .....	135 - 22	3B10	BLOWER FAN, AIR CONDITION AND HEATER .....	95 - 4
1C22	BEARING, THRUST .....	25 - 14	4D16	BOGEY WHEEL ASSEMBLY (RUBBER TRACK) .....	160 - 16
3F4	BEARINGS, AUGER BED .....	125 - 4	4D14	BOGEY WHEEL AXLES (RUBBER TRACK) .....	160 - 14
2C20	BEARINGS, CAM LOBE MOTOR .....	50 - 40	1D2	BOLTS, CYLINDER HEAD .....	25 - 20
3F19	BEARINGS, CLEANING FAN .....	125 - 20	3G5	BOOT ASSEMBLY, CLEAN GRAIN ELEVATOR .....	130 - 8
2C6	BEARINGS, FINAL DRIVE .....	50 - 24	4D17	BOX, GEAR, TRANSFER (RUBBER TRACK) .....	160 - 18
4D13	BEARINGS, IDLER WHEEL (RUBBER TRACK) .....	160 - 12	2I12	BOX, TOOL .....	80 - 38
1C22	BEARINGS, MAIN .....	25 - 14	3C15	BRACE, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER .....	110 - 14
2B24	BEARINGS, TRANSMISSION .....	50 - 16	3H12	BRACE, STRAW CHOPPER JACKSHAFT .....	135 - 12
2C1	BEARINGS, TRANSMISSION PINION SHAFT .....	50 - 18	3C13	BRACE, VARIABLE SPEED FEEDER HOUSE DRIVE TIGHTENER .....	110 - 12
3E19	BEATER ASSEMBLY, DISCHARGE .....	120 - 26	2B11	BRACKET, ADJUSTABLE REAR AXLE (NON-POWERED) .....	50 - 3
3F2	BED ASSEMBLY, AUGER .....	125 - 2	2B10	BRACKET, ADJUSTABLE REAR AXLE (POWERED) .....	50 - 2
2J20	BELLCRANK, FEEDER HOUSE REVERSER FOOT CONTROL .....	90 - 32	1E24	BRACKET, AIR CLEANER .....	30 - 20
4D23	BELT AND DRIVE WHEEL (RUBBER TRACK) .....	160 - 24	1H9	BRACKET, ALTERNATOR (185 AMP) .....	40 - 56
2F21	BELT PICKUP/REEL DRIVE, PUMP MOUNTING SHEAVE .....	70 - 26	1H7	BRACKET, ALTERNATOR (95 AMP) .....	40 - 54
1H9	BELT, ALTERNATOR (185 AMP) .....	40 - 56	3B8	BRACKET, ATC CONTROLLER .....	95 - 2
1H7	BELT, ALTERNATOR (95 AMP) .....	40 - 54	3F4	BRACKET, AUGER BED SHAFT .....	125 - 4
4F6	BELT, CLEAN GRAIN ELEVATOR .....	170 - 28	2E8	BRACKET, BRAKE CABLE SUPPORT .....	60 - 13
3K1	BELT, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER .....	140 - 48	2E1	BRACKET, BRAKE LINES .....	60 - 6
4F6	BELT, CLEANING FAN .....	170 - 28	2J1	BRACKET, CAB GLASS .....	90 - 12
3J16	BELT, CLEANING FAN DRIVE .....	140 - 38	2I20	BRACKET, CAB REAR SIDE PANELS .....	90 - 6
3H12	BELT, COUNTERSHAFT .....	135 - 12	3G5	BRACKET, CLEAN GRAIN ELEVATOR BOOT ASSEMBLY .....	130 - 8
4F8	BELT, COUNTERSHAFT, DISCHARGE BEATER AND CHOPPER .....	170 - 30	3F23	BRACKET, CLEAN GRAIN LOWER AUGER .....	130 - 2
3H12	BELT, DISCHARGE BEATER .....	135 - 12	3F17	BRACKET, CLEANING FAN .....	125 - 18
3J24	BELT, ELEVATOR DRIVE JACKSHAFT ASSEMBLY .....	140 - 46	4C5	BRACKET, CROSS AUGERS .....	150 - 24
3J17	BELT, FAN DRIVE .....	140 - 39	4C11	BRACKET, DISPLAY YIELD MAPPING .....	155 - 4
4F6	BELT, FEED ACCELERATOR .....	170 - 28	3I7	BRACKET, ENGINE GEARCASE OIL FILTER ASSEMBLY .....	140 - 4
3J10	BELT, FEED ACCELERATOR DRIVE IDLER .....	140 - 32	1H15	BRACKET, FEEDER HOUSE BACKSHAFT SPEED SENSOR .....	40 - 62
3C17	BELT, FEEDER HOUSE DRIVE TIGHTENER .....	110 - 16	2G5	BRACKET, FEEDER HOUSE GEARCASE OIL COOLER .....	70 - 34
3C17	BELT, HEADER AND REEL PUMP (HI-CAPACITY) .....	110 - 16	3D3	BRACKET, FEEDER HOUSE UPPER SHAFT .....	110 - 26
3C17	BELT, HEADER AND REEL PUMP (STANDARD) .....	110 - 16	2B9	BRACKET, FIXED REAR AXLE (NON-POWERED) .....	50 - 1
3J7	BELT, HEADER ELECTROMAGNETIC CLUTCH (HI-CAPACITY) .....	140 - 28	3C15	BRACKET, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER .....	110 - 14
3J7	BELT, HEADER ELECTROMAGNETIC CLUTCH (STANDARD) .....	140 - 28	2J22	BRACKET, GEARSHIFT LEVER .....	90 - 34
4F6	BELT, R.H. JACKSHAFT (FRONT) .....	170 - 28	3J7	BRACKET, HEADER ELECTROMAGNETIC CLUTCH .....	140 - 28
4F6	BELT, R.H. JACKSHAFT (REAR) .....	170 - 28	4C3	BRACKET, HORIZONTAL UNLOADING AUGER SWIVEL .....	150 - 22
1B10	BELT, ROTARY SCREEN .....	20 - 4	2I19	BRACKET, HORN ASSEMBLY .....	90 - 4
1B8	BELT, ROTARY SCREEN DRIVE .....	20 - 2	3D9	BRACKET, IDLER, FEEDER CONVEYOR .....	110 - 32
4F10	BELT, ROTARY SCREEN DRIVE (ENGINE SIDE) .....	170 - 32	2B24	BRACKET, INPUT SHAFT .....	50 - 16
4F10	BELT, ROTARY SCREEN DRIVE (SCREEN SIDE) .....	170 - 32	1H23	BRACKET, L.H. FRONT LIGHT .....	40 - 70
3I19	BELT, SEPARATOR DRIVE VARIABLE SPEED .....	140 - 16	2K7	BRACKET, LADDER EXTENSION ASSEMBLY .....	90 - 44
4F6	BELT, SHOE FAN AND CONVEYOR AUGERS .....	170 - 28	1I5	BRACKET, LIGHT SWITCH .....	40 - 77
3H12	BELT, STRAW CHOPPER .....	135 - 12	3G20	BRACKET, LOWER TAILINGS AUGER .....	130 - 24
3H12	BELT, STRAW CHOPPER JACKSHAFT .....	135 - 12	2F17	BRACKET, MAIN HYDRAULIC FILTER .....	70 - 22
4F8	BELT, STS VARIABLE BELT .....	170 - 30	4C13	BRACKET, MASS FLOW SENSOR YIELD MAPPING .....	155 - 6
4F6	BELT, TAILINGS AUGER AND ELEVATOR .....	170 - 28	1I6	BRACKET, MOISTURE SENSOR .....	40 - 78
3K4	BELT, UNLOADING AUGER COUNTERSHAFT DRIVE .....	140 - 52	4C15	BRACKET, MOISTURE SENSOR YIELD MAPPING .....	155 - 8
4F8	BELT, UNLOADING AUGER SYSTEM .....	170 - 30	2G12	BRACKET, ONE HALF GALLON ACCUMULATOR .....	70 - 41
3G14	BELT, UPPER TAILINGS ELEVATOR .....	130 - 18	4C9	BRACKET, POSITION RECEIVER YIELD MAPPING .....	155 - 2
3C4	BELT, VARIABLE SPEED FEEDER HOUSE (HI-CAPACITY) .....	110 - 2	3J8	BRACKET, PRIMARY COUNTERSHAFT .....	140 - 30
3C4	BELT, VARIABLE SPEED FEEDER HOUSE (STANDARD) .....	110 - 2			
3H8	BLADE, STRAW CHOPPER ROTOR .....	135 - 8			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H24	BRACKET, R.H. FRONT LIGHT .....	40 - 71	1D1	BUSHING, CAMSHAFT .....	25 - 18
2H19	BRACKET, R.H. FRONT PANEL .....	80 - 18	4D5	BUSHINGS, MAIN FRAME PIVOT (RUBBER TRACK) .....	160 - 4
1B11	BRACKET, ROTARY SCREEN DOOR .....	20 - 6	1D10	BYPASS TUBES, OIL COOLER .....	25 - 29
3E8	BRACKET, ROTOR .....	120 - 13	1D12	BYPASS VALVE, OIL FILTER.....	25 - 32
2J5	BRACKET, SEAT CONSOLE .....	90 - 16			
3I19	BRACKET, SEPARATOR DRIVE VARIABLE SPEED ....	140 - 16		<b>C</b>	
2E13	BRACKET, STEERING CYLINDER AND HOSES .....	60 - 18	3B12	CAB AIR FILTER AND HOUSING .....	95 - 6
3H3	BRACKET, STRAW CHOPPER .....	135 - 2	2J1	CAB DOOR .....	90 - 12
3H24	BRACKET, STRAW SPREADER LATCH AND HANDLE	135 - 24	2J3	CAB DOOR LATCH .....	90 - 14
3H20	BRACKET, STRAW SPREADER SHIELDS .....	135 - 20	2J1	CAB GLASS .....	90 - 12
3G18	BRACKET, TAILINGS ELEVATOR .....	130 - 22	2K12	CAB HARDWARE KIT .....	90 - 50
3J19	BRACKET, TAILINGS ELEVATOR DRIVE IDLER ASSEMBLY .....	140 - 41	2I22	CAB INTERIOR PANELS, SEALS AND FLOOR MAT....	90 - 8
2I12	BRACKET, TOOL BOX .....	80 - 38	2K8	CAB LANDING AND MIRROR L.H. ....	90 - 46
4C13	BRACKET, TRANSDUCER MOUNTING YIELD MAPPING .....	155 - 6	2K10	CAB LANDING AND MIRROR R.H. ....	90 - 48
3C13	BRACKET, VARIABLE SPEED FEEDER HOUSE DRIVE TIGHTENER .....	110 - 12	1G7	CAB MAIN WIRING HARNESS.....	40 - 30
3B14	BRACKET, WATER VALVE ASSEMBLY (AIR CONDITIONING SYSTEM) .....	95 - 8	2I20	CAB REAR, SIDE AND FLOOR PANELS .....	90 - 6
2D14	BRACKET, 4-WHEEL DRIVE HOSES AND LINES .....	50 - 60	1H22	CAB ROOF LIGHTS .....	40 - 69
1F1	BRACKETS AND SUPPORTS, AIR CLEANER .....	30 - 22	2I24	CAB ROOF, INTERIOR .....	90 - 10
1C2	BRACKETS, AIR CONDITIONER COMPRESSOR .....	20 - 22	2I17	CAB SUPPORT .....	90 - 2
2I22	BRACKETS, CAB INTERIOR .....	90 - 8	2E5	CABLE, BRAKE SHOES AND DRUM .....	60 - 10
1H3	BRACKETS, CENTRAL ELECTRONICS BOARD .....	40 - 50	4C21	CABLE, DATASTORE/COMPUTER .....	155 - 14
2I8	BRACKETS, ENGINE ACCESS DOOR .....	80 - 34	3D1	CABLE, FEEDER HOUSE (CONTOUR MASTER).....	110 - 24
2I6	BRACKETS, ENGINE PLATFORM LADDER, HANDRAIL .....	80 - 32	2J20	CABLE, FEEDER HOUSE REVERSER FOOT CONTROL .....	90 - 32
3D15	BRACKETS, FEEDER HOUSE POSITION SENSOR ....	110 - 38	2J22	CABLE, GEARSHIFT LEVER .....	90 - 34
4B8	BRACKETS, GRAIN TANK .....	150 - 2	3C19	CABLE, L.H. DRIVE SHIELDS .....	110 - 18
4B12	BRACKETS, GRAIN TANK EXTENSIONS (9750 STS).....	150 - 6	3C21	CABLE, R.H. DRIVE SHIELDS .....	110 - 20
1I4	BRACKETS, GRAIN TANK FULL BIN SENSOR .....	40 - 76	1F14	CABLE, WIRING .....	40 - 8
2D6	BRACKETS, HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE) .....	50 - 52	1H4	CABLES, BATTERY.....	40 - 51
2H13	BRACKETS, L.H. GULLWING DOOR.....	80 - 12	2C8	CABLES, CONTROL, HYDROSTATIC DRIVE .....	50 - 26
2H11	BRACKETS, LEFT FRONT PANEL AND DOOR .....	80 - 10	2C22	CAM LOBE MOTOR INNER COVER, MANIFOLD, AND PACKING .....	50 - 42
1H20	BRACKETS, LOW SHAFT SPEED SENSORS .....	40 - 67	2C20	CAM LOBE MOTOR SHAFT, OUTER COVER, BEARINGS, AND SEALS .....	50 - 40
2F1	BRACKETS, OIL COOLER AND AIR CONDITIONER CONDENSER .....	70 - 6	2C24	CAM, CARRIER, AND PISTON.....	50 - 45
2H21	BRACKETS, R.H. GULLWING DOOR .....	80 - 20	3F6	CAMS, CHAFFER FRAME .....	125 - 6
2H23	BRACKETS, R.H. REAR RADIATOR DOOR .....	80 - 22	3I21	CAMS, SEPARATOR DRIVE TORQUE SENSING .....	140 - 18
2H24	BRACKETS, REAR ACCESS DOOR .....	80 - 24	3F14	CAMS, SIEVE ELEMENT .....	125 - 14
2F15	BRACKETS, SOLENOID CONTROL VALVE .....	70 - 20	1D1	CAMSHAFT .....	25 - 18
3H10	BRACKETS, STRAW CHOPPER .....	135 - 10	1C12	CAMSHAFT BUSHING .....	25 - 4
3H16	BRACKETS, STRAW SPREADER FRAME .....	135 - 16	1D1	CAMSHAFT BUSHING .....	25 - 18
1G17	BRACKETS, WINDSHIELD WIPER .....	40 - 40	1D1	CAMSHAFT FOLLOWER.....	25 - 18
2E8	BRAKE CABLE SUPPORT BRACKET .....	60 - 13	1D4	CAMSHAFT FOLLOWER.....	25 - 22
2E3	BRAKE CYLINDER, MASTER.....	60 - 8	1D1	CAMSHAFT GEAR.....	25 - 18
2E1	BRAKE LINES AND RESERVOIR .....	60 - 6	1E18	CAP, FILLER, FUEL TANK .....	30 - 14
2D23	BRAKE PEDALS .....	60 - 4	4B17	CAP, GRAIN TANK CLEAN OUT CHUTE .....	150 - 12
2E5	BRAKE SHOES AND DRUM.....	60 - 10	1C12	CAPS, MAIN BEARING .....	25 - 4
4D21	BRAKE SHOES AND DRUM (RUBBER TRACK) .....	160 - 22	2D1	CAPS, YOKE AND PIVOTS .....	50 - 46
2E7	BRAKE SLAVE CYLINDER .....	60 - 12	2C24	CARRIER, PISTON, AND CAM.....	50 - 45
1E20	BREATHING, DOUBLE, FUEL TANK.....	30 - 16	2D16	CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES .....	50 - 62
1E18	BREATHING, FUEL TANK .....	30 - 14	4D17	CASE, GEAR, TRANSFER (RUBBER TRACK) .....	160 - 18
2B24	BREATHING, INPUT SHAFT HOUSING .....	50 - 16	1H1	CENTRAL ELECTRONICS MODULE AND CIRCUIT BOARDS .....	40 - 48
1B11	BRUSH, ROTARY SCREEN DOOR .....	20 - 6	1H1	CENTRAL ELECTRONICS MODULE CIRCUIT BOARDS .....	40 - 48
1I8	BULB, CLEANING SHOE INSPECTION LIGHT.....	40 - 80	2G18	CHAFF SPREADER MOTOR, HOSE AND FITTINGS....	70 - 47
2I24	BULB, DOME LIGHT .....	90 - 10	2G1	CHAFF SPREADER PUMP .....	70 - 30
1H23	BULB, L.H. FRONT LIGHT .....	40 - 70	2G1	CHAFF SPREADER PUMP, REEL/BELT PICKUP DRIVE .....	70 - 30
1H24	BULB, R.H. FRONT LIGHT .....	40 - 71	3F6	CHAFFER FRAME .....	125 - 6
1H25	BULB, REAR LIGHT (AMBER) .....	40 - 72	3F8	CHAFFER FRAME (CONTINUED) .....	125 - 8
1I1	BULB, REAR TURN AND TAIL LIGHTS .....	40 - 73	3J20	CHAFFER FRAME SHOE DRIVE .....	140 - 42
1I2	BULB, SIDE FINDER LIGHTS.....	40 - 74	3F10	CHAFFER SHAFT AND ELEMENT ADJUST.....	125 - 10
1H22	BULBS, CAB ROOF LIGHT.....	40 - 69			
1C12	BUSHING, CAMSHAFT .....	25 - 4			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4C5	CHAIN SPROCKET, CROSS AUGERS .....	150 - 24	1H18	CONCAVE ADJUSTING MOTOR .....	40 - 65
3G20	CHAIN SPROCKET, LOWER TAILINGS AUGER .....	130 - 24	1H19	CONCAVE ADJUSTING MOTOR .....	40 - 66
3K4	CHAIN SPROCKET, UNLOADING AUGER COUNTERSHAFT DRIVE .....	140 - 52	3E14	CONCAVE CLEARANCE INDICATOR SENSOR .....	120 - 20
3G14	CHAIN SPROCKET, UPPER TAILINGS ELEVATOR ....	130 - 18	3E16	CONCAVE CLEARANCE INDICATOR SENSOR .....	120 - 22
3F23	CHAIN SPROCKET, CLEAN GRAIN LOWER AUGER ....	130 - 2	3E14	CONCAVES .....	120 - 20
3D9	CHAIN, DRIVE, FEEDER CONVEYOR .....	110 - 32	3E16	CONCAVES .....	120 - 22
4F6	CHAIN, FEEDER CONVEYOR .....	170 - 28	2F1	CONDENSER, AIR CONDITIONER AND OIL COOLER .....	70 - 6
3D7	CHAIN, FEEDER HOUSE CONVEYOR .....	110 - 30	1C11	CONDITIONER, COOLANT .....	25 - 2
3K7	CHAIN, UNLOADING AUGER DRIVE SPROCKET IDLER ASSEMBLY .....	140 - 55	3E13	CONE ASSEMBLY, SEPARATOR .....	120 - 18
4F8	CHAIN, UNLOADING AUGER SYSTEM .....	170 - 30	1C18	CONNECTING RODS .....	25 - 10
3E8	CHANNEL, ROTOR .....	120 - 13	1F8	CONNECTORS, ELECTRICAL, WEATHERPACK .....	40 - 2
3F14	CHANNEL, SIEVE ELEMENT .....	125 - 14	1C6	CONNECTORS, ENGINE HEATER HOSE .....	20 - 27
1B17	CHARGE AIR COOLER .....	20 - 12	1E10	CONNECTORS, FUEL INJECTION PUMP HOUSING ..	30 - 6
4B19	CHARGE HOUSING AND VERTICAL UNLOADING AUGER .....	150 - 14	1F16	CONNECTORS, SUPPLEMENTARY TERMINALS .....	40 - 10
3H14	CHOPPER AND SPREADER DRIVE SHIELDS .....	135 - 14	2K1	CONSOLE, OVERHEAD .....	90 - 38
3H5	CHOPPER DEFLECTORS .....	135 - 4	2J5	CONSOLE, SEAT .....	90 - 16
3H6	CHOPPER HOUSING AND KNIFEBANK .....	135 - 6	2J5	CONTAINER, SEAT CONSOLE .....	90 - 16
3H3	CHOPPER, STRAW .....	135 - 2	1E16	CONTAINER, STARTING FLUID .....	30 - 12
4B17	CHUTE, GRAIN TANK CLEAN OUT .....	150 - 12	2F8	CONTOUR MASTER SOLENOID CONTROL RELIEF VALVE .....	70 - 13
2K1	CIRCUIT BOARD, OVERHEAD CONSOLE .....	90 - 38	2G8	CONTOUR MASTER TILT CYLINDER .....	70 - 37
1H1	CIRCUIT BOARDS, CENTRAL ELECTRONICS MODULE .....	40 - 48	2G9	CONTOUR MASTER TILT CYLINDER HOSES FITTINGS .....	70 - 38
3B8	CIRCUIT BOX, ATC .....	95 - 2	2C8	CONTROL CABLES, HYDROSTATIC DRIVE .....	50 - 26
1H5	CIRCUIT BREAKER, RELAY PANEL .....	40 - 52	2J12	CONTROL PANEL, ARMREST .....	90 - 24
3G1	CLEAN GRAIN ELEVATOR .....	130 - 4	2J14	CONTROL PANEL, ARMREST (CONTINUED) .....	90 - 26
3G5	CLEAN GRAIN ELEVATOR BOOT ASSEMBLY .....	130 - 8	1E8	CONTROL UNIT, ELECTRONIC .....	30 - 4
3J13	CLEAN GRAIN ELEVATOR DRIVE IDLER ASSEMBLY .....	140 - 35	2D4	CONTROL VALVE .....	50 - 50
3K1	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER .....	140 - 48	2F13	CONTROL VALVE MODULE, SIX STACK SOLENOID ASSEMBLY & MOUNTINGS .....	70 - 18
3G8	CLEAN GRAIN ELEVATOR GEARCASE AND SHEAVE	130 - 12	2C15	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT .....	50 - 34
3G3	CLEAN GRAIN ELEVATOR UPPER SHAFT, SPROCKET AND SHEAVE .....	130 - 6	2F7	CONTROL VALVE, SOLENOID, AUGER SWING .....	70 - 12
3G10	CLEAN GRAIN LOADING AUGER .....	130 - 14	2G17	CONTROL VALVE, STRAW SPREADER .....	70 - 46
3F23	CLEAN GRAIN LOWER AUGER AND HINGED DOOR	130 - 2	1G19	CONTROLLERS, GRAIN LOSS MONITOR .....	40 - 42
4B17	CLEAN OUT CHUTE, GRAIN TANK .....	150 - 12	1F17	CONVENIENCE OUTLET, KIT .....	40 - 12
1E25	CLEANER, AIR .....	30 - 21	3J23	CONVEYOR AUGER DRIVE/TAILINGS ELEVATOR SLIP CLUTCH .....	140 - 45
3F16	CLEANING FAN ASSEMBLY .....	125 - 16	1C11	COOLANT CONDITIONER, ENGINE .....	25 - 2
3F17	CLEANING FAN COVERS AND SUPPORTS .....	125 - 18	1C3	COOLANT HEATER, ENGINE BLOCK .....	20 - 24
3J16	CLEANING FAN DRIVE .....	140 - 38	1B19	COOLANT RECOVERY TANK .....	20 - 14
3F19	CLEANING FAN SHAFT AND BEARINGS .....	125 - 20	1C11	COOLANT SCAN TEST KIT .....	25 - 2
1I8	CLEANING SHOE INSPECTION LIGHT .....	40 - 80	1B17	COOLER, CHARGE AIR .....	20 - 12
1E22	CLEAT MATS, ENGINE PLATFORM .....	30 - 18	1D11	COOLER, ENGINE OIL .....	25 - 30
1H13	CLUTCH ASSEMBLY (STARTER) .....	40 - 60	2J24	CORNERPOST DISPLAY PANEL, R.H. ....	90 - 36
3I11	CLUTCH DISK, MAIN GEARCASE (9650 STS) .....	140 - 8	3K4	COUNTERSHAFT DRIVE, UNLOADING AUGER .....	140 - 52
3I13	CLUTCH DISK, MAIN GEARCASE (9750 STS) .....	140 - 10	3J5	COUNTERSHAFT GEARCASE, PRIMARY .....	140 - 26
3B19	CLUTCH, COMPRESSOR R134A .....	95 - 13	3J8	COUNTERSHAFT, PRIMARY .....	140 - 30
3J7	CLUTCH, HEADER ELECTROMAGNETIC .....	140 - 28	3D11	COUNTERSHAFT, UPPER, VARIABLE SPEED FEEDER HOUSE .....	110 - 34
3D19	CLUTCH, SLIP (RADIAL PIN) .....	110 - 42	1B25	COUPLING HUB, ENGINE GEARCASE .....	20 - 20
3J23	CLUTCH, SLIP, CONVEYOR AUGER DRIVE/ TAILINGS ELEVATOR .....	140 - 45	2C5	COUPLING, DRIVE SHAFT, FINAL DRIVE .....	50 - 23
3J23	CLUTCH, SLIP, TAILINGS ELEVATOR/ CONVEYOR AUGER DRIVE .....	140 - 45	2B24	COUPLING, INPUT SHAFT .....	50 - 16
2J18	COLD WEATHER START BUTTON .....	90 - 30	2B12	COUPLINGS, AXLE .....	50 - 4
1E16	COLD WEATHER STARTING AID .....	30 - 12	2B13	COUPLINGS, AXLE .....	50 - 5
2J16	COLUMN, STEERING (LOWER) .....	90 - 28	3E11	COVER REPAIR KIT .....	120 - 16
2J18	COLUMN, STEERING (UPPER) .....	90 - 30	1E25	COVER, AIR CLEANER .....	30 - 21
1C2	COMPRESSOR BRACKETS, AIR CONDITIONER .....	20 - 22	3H6	COVER, CHOPPER HOUSING .....	135 - 6
3B18	COMPRESSOR HOSE, AIR CONDITIONER .....	95 - 12	3H14	COVER, CHOPPER/SPREADER DRIVE SHIELDS .....	135 - 14
3B21	COMPRESSOR PARTS .....	95 - 15	3G8	COVER, CLEAN GRAIN ELEVATOR GEARCASE .....	130 - 12
3B17	COMPRESSOR, AIR CONDITIONING, R134A .....	95 - 11	3F23	COVER, CLEAN GRAIN LOWER AUGER .....	130 - 2
3B19	COMPRESSOR, CLUTCH R134A .....	95 - 13	3F17	COVER, CLEANING FAN .....	125 - 18
3E14	CONCAVE ADJUSTING ASSEMBLY .....	120 - 20	4C5	COVER, CROSS AUGERS .....	150 - 24
3E16	CONCAVE ADJUSTING ASSEMBLY .....	120 - 22	2I24	COVER, DOME LIGHT .....	90 - 10
			2I10	COVER, ENGINE .....	80 - 36
			2C14	COVER, HYDROSTATIC DRIVE CHARGE PUMP .....	50 - 33

## ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
2C17	COVER, HYDROSTATIC DRIVE MOTOR .....	50 - 36	4D11	CYLINDER, TENSION AND ATTACHING HARDWARE (RUBBER TRACK) .....	160 - 10
2C10	COVER, HYDROSTATIC DRIVE PUMP .....	50 - 28	2G8	CYLINDER, TILT (CONTOUR MASTER) .....	70 - 37
2C22	COVER, INNER, CAM LOBE MOTOR .....	50 - 42	2G19	CYLINDER, UNLOADING AUGER BELT TENSIONING .....	70 - 48
3I15	COVER, MAIN GEARCASE .....	140 - 12	2G21	CYLINDER, UNLOADING AUGER SWING .....	70 - 50
4C15	COVER, MOISTURE SENSOR YIELD MAPPING .....	155 - 8	3D11	CYLINDER, VARIABLE SPEED FEEDER HOUSE .....	110 - 34
1D11	COVER, OIL COOLER .....	25 - 30			
2C20	COVER, OUTER, CAM LOBE MOTOR .....	50 - 40		<b>D</b>	
4C9	COVER, POSITION RECEIVER YIELD MAPPING .....	155 - 2	1C19	DAMPER KEY .....	25 - 11
3B8	COVER, PRESSURE BLOWER .....	95 - 2	1E3	DAMPER, CRANKSHAFT .....	25 - 50
3B10	COVER, RECIRCULATION BLOWER .....	95 - 4	4C21	DATASTORE .....	155 - 14
3C9	COVER, REVERSER GEARBOX (STANDARD) .....	110 - 8	4C19	DATASTORE MODULE .....	155 - 12
1D5	COVER, ROCKER ARM .....	25 - 23	4C21	DATASTORE MODULE .....	155 - 14
3E8	COVER, ROTOR .....	120 - 13	4C19	DATASTORE W/DISPLAY .....	155 - 12
3I21	COVER, SEPARATOR DRIVE TORQUE SENSING .....	140 - 18	4C22	DECALS YIELD MONITOR .....	155 - 15
3E18	COVER, SEPARATOR GRATE .....	120 - 24	4E11	DECALS AND LOCATIONS, SAFETY .....	170 - 8
1C1	COVER, START RELAY .....	20 - 21	4E9	DECALS AND ROADWAY MARKINGS LOCATIONS, SAFETY .....	170 - 6
2J16	COVER, STEERING COLUMN (LOWER) .....	90 - 28	4C22	DECALS, DISPLAY YIELD MONITOR .....	155 - 15
3H8	COVER, STRAW CHOPPER ROTOR .....	135 - 8	4E25	DECALS, FRENCH CANADIAN .....	170 - 22
3G18	COVER, TAILINGS ELEVATOR .....	130 - 22	4E19	DECALS, FRONT AND REAR .....	170 - 16
1D19	COVER, THERMOSTAT .....	25 - 40	4E23	DECALS, FRONT AND REAR TIRE .....	170 - 20
1C25	COVER, TIMING GEAR .....	25 - 17	4E17	DECALS, L.H. ....	170 - 14
3G6	COVER, UPPER GRAIN LOADING AUGER HOUSING .....	130 - 10	4C22	DECALS, MOISTURE SENSOR YIELD MONITOR .....	155 - 15
3G16	COVER, UPPER TAILINGS ELEVATOR .....	130 - 20	4F1	DECALS, PORTUGUESE .....	170 - 23
2I24	COVERS, CAB ROOF .....	90 - 10	4E15	DECALS, R.H. ....	170 - 12
3E5	COVERS, DUST .....	120 - 10	4F2	DECALS, ROMANIAN .....	170 - 24
4B8	COVERS, GRAIN TANK .....	150 - 2	4F3	DECALS, RUSSIAN .....	170 - 25
4C1	COVERS, HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.) .....	150 - 20	4E13	DECALS, SAFETY AND LOCATIONS .....	170 - 10
4B23	COVERS, HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.) .....	150 - 18	4E7	DECALS, SAFETY, L.H. SIDE .....	170 - 4
3I9	COVERS, MAIN GEARCASE .....	140 - 6	4E5	DECALS, SAFETY, R.H. SIDE .....	170 - 2
1I6	COVERS, MOISTURE SENSOR .....	40 - 78	4E21	DECALS, SAFETY, RUBBER TRACK .....	170 - 18
4C17	COVERS, MOISTURE SENSOR YIELD MAPPING .....	155 - 10	4F4	DECALS, SPANISH .....	170 - 26
3C6	COVERS, REVERSER GEARBOX (HI-CAPACITY) .....	110 - 4	4F5	DECALS, UKRAINIAN .....	170 - 27
3E3	COVERS, TOP SEPARATOR .....	120 - 8	4C13	DEFLECTOR DOOR, MASS FLOW SENSOR YIELD MAPPING .....	155 - 6
4B17	COVERS, VERTICAL AUGER LOWER GEARCASE .....	150 - 12	3F17	DEFLECTOR, CLEANING FAN .....	125 - 18
4C17	COVERS, WHEN MOISTURE SENSOR IS NOT USED YIELD MAPPING .....	155 - 10	2I8	DEFLECTOR, ENGINE ACCESS DOOR .....	80 - 34
2C3	CRADLE, TRANSMISSION/DIFFERENTIAL .....	50 - 20	1E22	DEFLECTOR, ENGINE PLATFORM .....	30 - 18
2J16	CRANK, STEERING COLUMN (LOWER) .....	90 - 28	3C23	DEFLECTOR, FEEDER HOUSE FRAME .....	110 - 22
1C5	CRANKCASE, ENGINE, OIL DRAIN .....	20 - 26	3G12	DEFLECTOR, LOADING AUGER SPOUT ASSEMBLY .....	130 - 16
1C19	CRANKSHAFT .....	25 - 11	3H10	DEFLECTOR, STRAW CHOPPER .....	135 - 10
1C25	CRANKSHAFT FRONT OIL SEAL .....	25 - 17	3H3	DEFLECTOR, STRAW CHOPPER SIDE .....	135 - 2
1C20	CRANKSHAFT KIT, UNDERSIZE (CONNECTING ROD JOURNAL) .....	25 - 12	3G6	DEFLECTOR, UPPER GRAIN LOADING AUGER HOUSING .....	130 - 10
1C21	CRANKSHAFT KIT, UNDERSIZED MAIN BEARING .....	25 - 13	2I10	DEFLECTORS, AIR, ENGINE .....	80 - 36
1E3	CRANKSHAFT PULLEY AND DAMPER .....	25 - 50	3F8	DEFLECTORS, CHAFFER FRAME .....	125 - 8
3H18	CROP DIVIDER, STRAW SPREADER .....	135 - 18	3H5	DEFLECTORS, CHOPPER .....	135 - 4
4C5	CROSS AUGERS .....	150 - 24	3D22	DEFLECTORS, SEPARATOR/FEEDER HOUSE .....	120 - 2
3H18	CURTAIN, LIMIT, STRAW SPREADER .....	135 - 18	3H18	DEFLECTORS, STRAW SPREADER .....	135 - 18
3H20	CURTAINS, LIMIT, STRAW SPREADER SHIELDS .....	135 - 20	2F16	DIAL-A-MATIC HEADER HEIGHT CONTROL VALVE .....	70 - 21
2J9	CUSHIONS, OPERATOR'S SEAT .....	90 - 20	2C3	DIFFERENTIAL GEARS .....	50 - 20
1C12	CYLINDER BLOCK FITTINGS .....	25 - 4	2C3	DIFFERENTIAL SHAFTS .....	50 - 20
1D2	CYLINDER HEAD .....	25 - 20	3G8	DIPSTICK, CLEAN GRAIN ELEVATOR GEARCASE .....	130 - 12
1D2	CYLINDER HEAD BOLTS .....	25 - 20	1D16	DIPSTICK, ENGINE OIL .....	25 - 36
1D2	CYLINDER HEAD GASKET .....	25 - 20	3I15	DIPSTICK, MAIN GEARCASE .....	140 - 12
1E1	CYLINDER HEAD GASKET KIT .....	25 - 48	3J5	DIPSTICK, PRIMARY COUNTERSHAFT GEARCASE .....	140 - 26
1C18	CYLINDER LINERS .....	25 - 10	3C6	DIPSTICK, REVERSER GEARBOX (HI-CAPACITY) .....	110 - 4
2F5	CYLINDER SPEED SOLENOID CONTROL VALVE .....	70 - 10	3C9	DIPSTICK, REVERSER GEARBOX (STANDARD) .....	110 - 8
2E7	CYLINDER, BRAKE SLAVE .....	60 - 12			
2E3	CYLINDER, BRAKE, MASTER .....	60 - 8			
2F19	CYLINDER, HEADER LIFT, HYDRAULIC .....	70 - 24			
2E13	CYLINDER, STEERING .....	60 - 18			
4E3	CYLINDER, TENSION (RUBBER TRACK) .....	160 - 28			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3J1	DIPSTICK, TWO-SPEED GEARBOX .....	140-22	3C19	DRIVE SHIELDS, L.H. ....	110-18
3E19	DISCHARGE BEATER ASSEMBLY .....	120-26	3C21	DRIVE SHIELDS, R.H. ....	110-20
3J22	DISCHARGE BEATER DRIVE IDLER ASSEMBLY .....	140-44	3D9	DRIVE SPROKET, FEEDER CONVEYOR .....	110-32
3E23	DISCHARGE GRATE ASSEMBLY .....	120-30	3K1	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR .....	140-48
3E9	DISCHARGE HOUSING, SEPARATOR .....	120-14	3C17	DRIVE TIGHTENER, FEEDER HOUSE .....	110-16
3I11	DISK, CLUTCH, MAIN GEARCASE (9650 STS) .....	140-8	3C13	DRIVE TIGHTENER, FEEDER HOUSE, VARIABLE SPEED .....	110-12
3I13	DISK, CLUTCH, MAIN GEARCASE (9750 STS) .....	140-10	3C15	DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE .....	110-14
3H18	DISK, STRAW SPREADER .....	135-18	4D23	DRIVE WHEEL AND BELT (RUBBER TRACK) .....	160-24
2C15	DISPLACEMENT CONTROL VALVE, HYDROSTATIC DRIVE .....	50-34	2B14	DRIVE WHEELS .....	50-6
4C11	DISPLAY YIELD MAPPING .....	155-4	2B15	DRIVE WHEELS, HIGH FLOTATION .....	50-7
4C11	DISPLAY BRACKET YIELD MAPPING .....	155-4	2F21	DRIVE, BELT PICKUP/REEL PUMP MOUNTING SHEAVE .....	70-26
4C22	DISPLAY DECALS YIELD MONITOR .....	155-15	3J16	DRIVE, CLEANING FAN .....	140-38
2J24	DISPLAY PANEL, R.H. CORNERPOST .....	90-36	1B21	DRIVE, FAN, ENGINE .....	20-16
4C19	DISPLAY W/DATASTORE .....	155-12	2C6	DRIVE, FINAL .....	50-24
3H18	DIVIDER, CROP, STRAW SPREADER .....	135-18	2D8	DRIVE, HYDROSTATIC OIL HOSES, UPPER .....	50-54
2I24	DOME LIGHT .....	90-10	2D6	DRIVE, HYDROSTATIC, LOWER OIL LINES (TWO WHEEL DRIVE) .....	50-52
2J3	DOOR LATCH, CAB .....	90-14	2F23	DRIVE, REEL, FLOW CONTROL VALVE .....	70-28
3F2	DOOR, AUGER BED ASSEMBLY .....	125-2	3J20	DRIVE, SHOE, CHAFFER FRAME .....	140-42
2J1	DOOR, CAB .....	90-12	3K4	DRIVE, UNLOADING AUGER COUNTERSHAFT .....	140-52
3H14	DOOR, CHOPPER AND SPREADER DRIVE SHIELDS .....	135-14	3J12	DRIVER SECONDARY JACKSHAFT, FEED ACCELERATOR .....	140-34
2I10	DOOR, ENGINE .....	80-36	3B8	DRIVER, AMBIENT AIR .....	95-2
2I8	DOOR, ENGINE ACCESS .....	80-34	3J3	DRIVESHAFTS, UNIVERSAL, PRIMARY COUNTERSHAFT .....	140-24
3F23	DOOR, HINGED, CLEAN GRAIN LOWER AUGER .....	130-2	4D21	DRUM AND SHOES, BRAKE (RUBBER TRACK) .....	160-22
4B21	DOOR, HORIZONTAL UNLOADING AUGER (17- AND 20-FT.) .....	150-16	2E5	DRUM, BRAKE .....	60-10
4C1	DOOR, HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.) .....	150-20	3D7	DRUM, FEEDER HOUSE CONVEYOR .....	110-30
4B23	DOOR, HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.) .....	150-18	3I11	DRUM, MAIN GEARCASE (9650 STS) .....	140-8
2H13	DOOR, L.H. GULLWING .....	80-12	3I13	DRUM, MAIN GEARCASE (9750 STS) .....	140-10
2H15	DOOR, L.H. REAR GULLWING .....	80-14	2B16	DUAL WHEELS (WIDE-SPACED) .....	50-8
2H11	DOOR, LEFT FRONT .....	80-10	3B13	DUCTS, HEATER AND AIR CONDITIONING .....	95-7
4C13	DOOR, MASS FLOW SENSOR DEFLECTOR YIELD MAPPING .....	155-6	3E5	DUST COVERS .....	120-10
2H23	DOOR, R.H. REAR RADIATOR .....	80-22	3B10	DUST SHIELD, AIR CONDITION AND HEATER .....	95-4
2H24	DOOR, REAR ACCESS .....	80-24			
1B11	DOOR, ROTARY SCREEN .....	20-6		E	
3D22	DOOR, SEPARATOR/FEEDER HOUSE .....	120-2	1E8	E.C.U. ....	30-4
3H3	DOOR, STRAW CHOPPER .....	135-2	1F3	EJECTOR .....	30-24
3G5	DOORS, CLEAN GRAIN ELEVATOR BOOT ASSEMBLY .....	130-8	1F10	ELECTRICAL CONNECTOR SERVICE KIT .....	40-4
4B8	DOORS, GRAIN TANK .....	150-2	1F12	ELECTRICAL CONNECTOR SERVICE KIT (CONTINUED) .....	40-6
3E7	DOORS, SEPARATOR .....	120-12	1F8	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK .....	40-2
3E3	DOORS, SEPARATOR TOP COVER .....	120-8	3J7	ELECTROMAGNETIC CLUTCH, HEADER .....	140-28
3G18	DOORS, TAILINGS ELEVATOR .....	130-22	1E8	ELECTRONIC CONTROL UNIT .....	30-4
1C3	DRAIN PLUG, ENGINE BLOCK .....	20-24	1E8	ELECTRONIC FUEL INJECTION PUMP .....	30-4
2F8	DRAIN PLUG, RELIEF VALVE .....	70-13	1H1	ELECTRONICS MODULE, CENTRAL AND CIRCUIT BOARDS .....	40-48
1D19	DRAIN VALVE, CYLINDER HEAD .....	25-40	3F10	ELEMENT ADJUST, CHAFFER .....	125-10
1D14	DRAIN VALVE, OIL PAN .....	25-34	3F14	ELEMENT, SIEVE .....	125-14
1B18	DRAIN VALVE, RADIATOR .....	20-13	3J24	ELEVATOR DRIVE JACKSHAFT ASSEMBLY .....	140-46
3D9	DRIVE CHAIN, FEEDER CONVEYOR .....	110-32	3G1	ELEVATOR, CLEAN GRAIN .....	130-4
1C19	DRIVE GEAR, OIL PUMP .....	25-11	3G18	ELEVATOR, TAILINGS .....	130-22
2D17	DRIVE LINES AND HOSES, TWO-WHEEL DRIVE .....	50-64	2I8	ENGINE ACCESS DOOR .....	80-34
2C5	DRIVE SHAFT, FINAL DRIVE .....	50-23	2I10	ENGINE AIR DEFLECTORS .....	80-36
3C11	DRIVE SHAFT, FIXED SPEED FEEDER HOUSE .....	110-10	2I10	ENGINE COVERS .....	80-36
3I11	DRIVE SHAFT, MAIN GEARCASE (9650 STS) .....	140-8	1B21	ENGINE FAN AND DRIVES .....	20-16
3I13	DRIVE SHAFT, MAIN GEARCASE (9750 STS) .....	140-10	1C24	ENGINE FLYWHEEL .....	25-16
3I23	DRIVE SHAFT, TWO-SPEED GEARBOX .....	140-20	1B25	ENGINE GEARCASE COUPLING HUB .....	20-20
3D17	DRIVE SHAFT, UPPER, FIXED SPEED FEEDER HOUSE .....	110-40	3I7	ENGINE GEARCASE OIL FILTER ASSEMBLY .....	140-4
2B12	DRIVE SHAFTS .....	50-4	3I5	ENGINE GEARCASE PRESSURE REGULATOR .....	140-2
2B13	DRIVE SHAFTS .....	50-5	1C10	ENGINE OIL (TORQ-GARD PLUS-50) .....	25-1
3H14	DRIVE SHIELDS, CHOPPER AND SPREADER .....	135-14			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1D11	ENGINE OIL COOLER .....	25 - 30	3D15	FEEDER HOUSE POSITION SENSOR .....	110 - 38
1D16	ENGINE OIL DIPSTICK .....	25 - 36	3D13	FEEDER HOUSE RETURN FLOOR .....	110 - 36
1D16	ENGINE OIL DIPSTICK TUBE .....	25 - 36	2J20	FEEDER HOUSE REVERSER FOOT CONTROL .....	90 - 32
1D12	ENGINE OIL FILTER .....	25 - 32	3D1	FEEDER HOUSE SHELL, WEAR PLATES AND SEALS (CONTOUR MASTER) .....	110 - 24
1D7	ENGINE OIL PUMP .....	25 - 26	3D3	FEEDER HOUSE UPPER SHAFT .....	110 - 26
1D9	ENGINE OIL PUMP INTAKE .....	25 - 28	2G7	FEEDER HOUSE VARIABLE DRIVE HYDRAULIC HOSE .....	70 - 36
1C16	ENGINE OVERHAUL KIT .....	25 - 8	3D22	FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR .....	120 - 2
1E22	ENGINE PLATFORM .....	30 - 18	1B17	FILLER CAP, RADIATOR .....	20 - 12
1E1	ENGINE REBUILD GASKET KIT .....	25 - 48	3I7	FILTER ASSEMBLY, OIL, ENGINE GEARCASE .....	140 - 4
1G21	ENGINE SPEED SENSOR .....	40 - 44	1E25	FILTER, AIR CLEANER .....	30 - 21
1F19	ENGINE WIRING HARNESS .....	40 - 14	3B10	FILTER, AIR, RECIRCULATION .....	95 - 4
2J18	ETHER START BUTTON .....	90 - 30	3B12	FILTER, CAB AIR .....	95 - 6
1E17	ETHER STARTING FITTINGS .....	30 - 13	1D12	FILTER, ENGINE OIL .....	25 - 32
3B16	EVAPORATOR HEATER, AIR CONDITIONING SYSTEM .....	95 - 10	3B16	FILTER, EVAPORATOR HEATER (AIR CONDITIONING SYSTEM) .....	95 - 10
3B16	EVAPORATOR TEMPERATURE SENSOR (AIR CONDITIONING SYSTEM) .....	95 - 10	1E14	FILTER, FUEL .....	30 - 10
1D25	EXHAUST MANIFOLD .....	25 - 46	1E18	FILTER, FUEL TANK .....	30 - 14
1D25	EXHAUST MANIFOLD GASKETS .....	25 - 46	2C14	FILTER, HYDROSTATIC DRIVE CHARGE PUMP .....	50 - 33
1D2	EXHAUST VALVE SHIELD .....	25 - 20	2F17	FILTER, MAIN HYDRAULIC .....	70 - 22
1D2	EXHAUST VALVES .....	25 - 20	1C25	FILTER, WATER PUMP (WEEP HOLE) .....	25 - 17
2K7	EXTENSION ASSEMBLY, LADDER .....	90 - 44	1G15	FILTER, WINDSHIELD WASHER .....	40 - 38
1C3	EXTENSION CORD, ENGINE BLOCK COOLANT HEATER .....	20 - 24	2C6	FINAL DRIVE .....	50 - 24
2K5	EXTENSION, LADDER AND HANDRAILS .....	90 - 42	4D19	FINAL DRIVE MOUNTING (SINGLE REDUCTION) (RUBBER TRACK) .....	160 - 20
1E22	EXTENSIONS, ENGINE PLATFORM .....	30 - 18	2C5	FINAL DRIVE, DRIVE SHAFT .....	50 - 23
4B10	EXTENSIONS, GRAIN TANK (9650 STS) .....	150 - 4	3F10	FINGERS, CHAFFER ELEMENT .....	125 - 10
4B12	EXTENSIONS, GRAIN TANK (9750 STS) .....	150 - 6	3F6	FINGERS, CHAFFER FRAME .....	125 - 6
<b>F</b>					
3F16	FAN ASSEMBLY, CLEANING .....	125 - 16	2G19	FITTINGS AND HOSES, UNLOADING AUGER BELT TENSIONING CYLINDER .....	70 - 48
1H18	FAN DRIVE ADJUSTING MOTOR, SEPARATOR .....	40 - 65	1C12	FITTINGS, CYLINDER BLOCK .....	25 - 4
1H19	FAN DRIVE ADJUSTING MOTOR, SEPARATOR .....	40 - 66	1E17	FITTINGS, ETHER STARTING .....	30 - 13
1B23	FAN DRIVE HOUSING .....	20 - 18	2C6	FITTINGS, FINAL DRIVE .....	50 - 24
3J17	FAN DRIVE SHEAVE .....	140 - 39	1E18	FITTINGS, FUEL TANK .....	30 - 14
3J14	FAN DRIVE SPEED CONTROL SUPPORT AND SHAFT .....	140 - 36	2F20	FITTINGS, HEADER LIFT .....	70 - 25
1B23	FAN DRIVE, ADJUSTABLE .....	20 - 18	2G18	FITTINGS, HOSE, CHAFF SPREADER MOTOR .....	70 - 47
3J18	FAN DRIVER JACKSHAFT ASSEMBLY .....	140 - 40	2G9	FITTINGS, HOSES, CONTOUR MASTER TILT CYLINDER .....	70 - 38
1B23	FAN PULLEY ADJUSTABLE .....	20 - 18	2G21	FITTINGS, HOSES, UNLOADING AUGER SWING CYLINDER .....	70 - 50
3F19	FAN SHAFT, CLEANING .....	125 - 20	2B24	FITTINGS, INPUT SHAFT HOUSING .....	50 - 16
3B8	FAN, AIR CONDITIONER AND HEATER .....	95 - 2	3C8	FITTINGS, REVERSER GEARBOX (HI CAPACITY) .....	110 - 6
1H7	FAN, ALTERNATOR (95 AMP) .....	40 - 54	3J1	FITTINGS, TWO-SPEED GEARBOX .....	140 - 22
3B10	FAN, BLOWER, AIR CONDITION AND HEATER .....	95 - 4	1G15	FITTINGS, WINDSHIELD WASHER .....	40 - 38
1B21	FAN, DRIVES, ENGINE .....	20 - 16	2B9	FIXED REAR AXLE (NON-POWERED) .....	50 - 1
3D24	FEED ACCELERATOR .....	120 - 4	3C11	FIXED SPEED FEEDER HOUSE DRIVE SHAFT, SHEAVE, AND MOUNTINGS .....	110 - 10
3J10	FEED ACCELERATOR DRIVE IDLER .....	140 - 32	3C15	FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER ..	110 - 14
3J12	FEED ACCELERATOR DRIVER SECONDARY JACKSHAFT .....	140 - 34	3D17	FIXED SPEED FEEDER HOUSE UPPER DRIVE SHAFT, SHEAVE AND MOUNTINGS .....	110 - 40
3E1	FEED HOUSING ASSEMBLY .....	120 - 6	2I5	FIXED, REAR LANDING, HANDRAIL .....	80 - 30
3D5	FEED PLATE LATCH HANDLE .....	110 - 28	3E11	FLIGHT REPAIR KIT .....	120 - 16
3D9	FEEDER CONVEYOR DRIVE CHAIN, IDLER BRACKET .....	110 - 32	1I8	FLOODLAMP, CLEANING SHOE INSPECTION LIGHT .....	40 - 80
1H15	FEEDER HOUSE BACKSHAFT SPEED SENSOR .....	40 - 62	1I2	FLOODLAMP, SIDE FINDER LIGHTS .....	40 - 74
3D7	FEEDER HOUSE CONVEYOR IDLER SHAFT, DRUM AND CHAIN .....	110 - 30	2I22	FLOOR MAT, CAB .....	90 - 8
3C17	FEEDER HOUSE DRIVE TIGHTENER .....	110 - 16	3F6	FLOOR, CHAFFER FRAME .....	125 - 6
3C15	FEEDER HOUSE DRIVE TIGHTENER, FIXED SPEED .....	110 - 14	3F17	FLOOR, CLEANING FAN .....	125 - 18
3C13	FEEDER HOUSE DRIVE TIGHTENER, VARIABLE SPEED .....	110 - 12	3E1	FLOOR, FEED HOUSING ASSEMBLY .....	120 - 6
3D5	FEEDER HOUSE FLOOR AND LATCH HANDLE .....	110 - 28	3D5	FLOOR, FEEDER HOUSE .....	110 - 28
3C23	FEEDER HOUSE FRAME .....	110 - 22	2I20	FLOOR, REAR AND SIDE PANELS, CAB .....	90 - 6
2G5	FEEDER HOUSE GEARCASE OIL COOLER .....	70 - 34	3D13	FLOOR, RETURN, FEEDER HOUSE .....	110 - 36
3C3	FEEDER HOUSE LIFT SUPPORT .....	110 - 1	2F23	FLOW CONTROL VALVE, REEL DRIVE .....	70 - 28
			4C13	FLOW SENSOR, MASS YIELD MAPPING .....	155 - 6





## ALPHABETICAL INDEX - CONTINUED

GRID	H	PAGE	GRID	PAGE
2J3	HANDLE, CAB DOOR .....	90 - 14	1C3	HEATER, COOLANT, ENGINE BLOCK .....
3D5	HANDLE, FEED PLATE LATCH .....	110 - 28	2B15	HIGH FLOTATION DRIVE WHEELS .....
3H24	HANDLE, STRAW SPREADER.....	135 - 24	2I10	HINGE, ENGINE DOOR .....
3H20	HANDLE, STRAW SPREADER SHIELDS .....	135 - 20	4B21	HINGE, HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....
2I6	HANDRAIL, ENGINE PLATFORM.....	80 - 32	2H23	HINGE, R.H. REAR RADIATOR DOOR .....
2K8	HANDRAIL, L.H.....	90 - 46	2I5	HINGE, REAR FIXED LANDING AND HANDRAIL .....
2K10	HANDRAIL, R.H. ....	90 - 48	3F23	HINGED DOOR, CLEAN GRAIN LOWER AUGER .....
2I5	HANDRAIL, REAR FIXED LANDING .....	80 - 30	2H13	HINGES, L.H. GULLWING DOOR .....
2I3	HANDRAIL, REAR LADDER LANDING .....	80 - 28	2H15	HINGES, L.H. REAR GULLWING DOOR.....
2K5	HANDRAILS, EXTENSION AND LADDER .....	90 - 42	2H21	HINGES, R.H. GULLWING DOOR .....
2K12	HARDWARE KIT, CAB .....	90 - 50	3D22	HINGES, SEPARATOR/FEEDER HOUSE .....
1G23	HARNESS EXTENSION, WIRING, GROUND SPEED....	40 - 46	4B21	HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....
4C19	HARNESS, DATASTORE .....	155 - 12	4B16	HORIZONTAL UNLOADING AUGER DRIVE GEARCASE .....
1G1	HARNESS, MAIN WIRING, R.H. W/O/ GREENSTAR - REFERENCE .....	40 - 23	4C1	HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.).....
4C15	HARNESS, MOISTURE SENSOR MOTOR YIELD MAPPING.....	155 - 8	4B23	HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.) .....
1H13	HARNESS, STARTER, WIRING .....	40 - 60	4C3	HORIZONTAL UNLOADING AUGER SWIVEL.....
2G13	HARNESS, WIRING, ACCUMULATOR PRESSURE GAUGE.....	70 - 42	2I19	HORN ASSEMBLY.....
1G13	HARNESS, WIRING, AIR CONDITIONING .....	40 - 36	2J18	HORN BUTTON .....
2J7	HARNESS, WIRING, AIR SUSPENSION SEAT.....	90 - 18	2G13	HOSE, ACCUMULATOR PRESSURE GAUGE .....
1G9	HARNESS, WIRING, ARMREST.....	40 - 32	1F3	HOSE, ASPIRATOR.....
1G7	HARNESS, WIRING, CAB MAIN.....	40 - 30	3B18	HOSE, COMPRESSOR, AIR CONDITIONER .....
1F19	HARNESS, WIRING, ENGINE.....	40 - 14	2G18	HOSE, FITTINGS, CHAFF SPREADER MOTOR.....
1G24	HARNESS, WIRING, FOLDING CHOPPER .....	40 - 47	3I19	HOSE, HYDRAULIC, SEPARATOR DRIVE VARIABLE SPEED .....
1G22	HARNESS, WIRING, GRAIN TANK .....	40 - 45	2G7	HOSE, HYDRAULIC, VARIABLE DRIVE, FEEDER HOUSE.....
1I4	HARNESS, WIRING, GRAIN TANK FULL BIN SENSOR .....	40 - 76	3E19	HOSE, LUBE, DISCHARGE BEATER ASSEMBLY .....
1G20	HARNESS, WIRING, HARVESTRAK .....	40 - 43	2G11	HOSE, ONE GALLON ACCUMULATOR .....
3J7	HARNESS, WIRING, HEADER ELECTROMAGNETIC CLUTCH.....	140 - 28	2G12	HOSE, ONE HALF GALLON ACCUMULATOR .....
2H13	HARNESS, WIRING, L.H. GULLWING DOOR SERVICE LIGHT .....	80 - 12	2G19	HOSES AND FITTINGS, UNLOADING AUGER BELT TENSIONING CYLINDER .....
1F21	HARNESS, WIRING, L.H. MAIN .....	40 - 17	2D10	HOSES AND LINES, HYDROSTATIC OIL COOLER.....
1F22	HARNESS, WIRING, L.H. MAIN .....	40 - 18	2D12	HOSES AND LINES, L.H. 4-WHEEL DRIVE HYDRAULIC.....
1F24	HARNESS, WIRING, L.H. MAIN .....	40 - 20	2F3	HOSES AND LINES, WET CLUTCH OIL COOLER, .....
1I6	HARNESS, WIRING, MOISTURE SENSOR.....	40 - 78	1E24	HOSES, AIR CLEANER.....
2J24	HARNESS, WIRING, R.H. CORNERPOST DISPLAY PANEL .....	90 - 36	2D17	HOSES, DRIVE, TWO-WHEEL DRIVE.....
2H21	HARNESS, WIRING, R.H. GULLWING DOOR SERVICE LIGHT .....	80 - 20	1C5	HOSES, ENGINE CRANKCASE OIL DRAIN .....
1G4	HARNESS, WIRING, R.H. MAIN, W/O GREENSTAR (REFERENCE).....	40 - 27	3B16	HOSES, EVAPORATOR HEATER (AIR CONDITIONING SYSTEM) .....
2H17	HARNESS, WIRING, REAR WALL SERVICE LIGHT ....	80 - 16	2G9	HOSES, FITTINGS, CONTOUR MASTER TILT CYLINDER .....
3E8	HARNESS, WIRING, ROTOR SPEED SENSOR.....	120 - 13	2G21	HOSES, FITTINGS, UNLOADING AUGER SWING CYLINDER .....
1G11	HARNESS, WIRING, STEERING COLUMN.....	40 - 34	1E18	HOSES, FUEL TANK.....
3H22	HARNESS, WIRING, STRAW SPREADER .....	135 - 22	1E20	HOSES, FUEL TANK DOUBLE BREATHER .....
1I3	HARNESS, WIRING, TRANSPORT WARNING LIGHTS.....	40 - 75	2F20	HOSES, HEADER LIFT .....
1H21	HARNESS, WIRING, UNLOADING AUGER LIGHT.....	40 - 68	4C3	HOSES, HORIZONTAL UNLOADING AUGER SWIVEL .....
1G20	HARVESTRAK WIRING HARNESS .....	40 - 43	2F17	HOSES, MAIN HYDRAULIC FILTER .....
1D2	HEAD BOLT KIT .....	25 - 20	2F1	HOSES, OIL COOLER AND AIR CONDITIONER CONDENSER .....
1D2	HEAD, CYLINDER .....	25 - 20	2D6	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE) .....
3J7	HEADER ELECTROMAGNETIC CLUTCH .....	140 - 28	2D8	HOSES, OIL, HYDROSTATIC DRIVE, UPPER .....
2F16	HEADER HEIGHT CONTROL VALVE .....	70 - 21	2E24	HOSES, PRESSURE, HYDRAULIC .....
2F19	HEADER LIFT CYLINDER, HYDRAULIC .....	70 - 24	1B15	HOSES, RADIATOR .....
2F20	HEADER LIFT HOSES AND FITTINGS .....	70 - 25	3B15	HOSES, RECEIVER-DRYER (AIR CONDITIONING SYSTEM) .....
2I24	HEADLINERS, CAB ROOF .....	90 - 10	1B19	HOSES, RECOVERY TANK, COOLANT .....
3B10	HEATER AND AIR CONDITIONER HOUSING, LOWER .....	95 - 4	2G4	HOSES, REEL DRIVE .....
3B8	HEATER AND AIR CONDITIONER HOUSING, UPPER.....	95 - 2	2G3	HOSES, REEL LIFT.....
3B13	HEATER AND AIR CONDITIONING DUCTS .....	95 - 7		
1C6	HEATER HOSE CONNECTORS.....	20 - 27		

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G3	HOSES, REEL POSITION.....	70 - 32	3E19	HUB, DISCHARGE BEATER ASSEMBLY .....	120 - 26
2F21	HOSES, REEL/BELT PICKUP PUMP.....	70 - 26	3J24	HUB, ELEVATOR DRIVE JACKSHAFT ASSEMBLY .....	140 - 46
2E13	HOSES, STEERING.....	60 - 18	1B21	HUB, ENGINE FAN .....	20 - 16
2E11	HOSES, STEERING, UPPER .....	60 - 16	3D24	HUB, FEED ACCELERATOR ASSEMBLY .....	120 - 4
2G15	HOSES, STRAW SPREADER.....	70 - 44	3J7	HUB, HEADER ELECTROMAGNETIC CLUTCH .....	140 - 28
3J1	HOSES, TWO-SPEED GEARBOX .....	140 - 22	4D13	HUB, IDLER WHEEL (RUBBER TRACK).....	160 - 12
3B14	HOSES, WATER VALVE ASSEMBLY (AIR CONDITIONING SYSTEM) .....	95 - 8	3I9	HUB, MAIN GEARCASE .....	140 - 6
1G15	HOSES, WINDSHIELD WASHER .....	40 - 38	2F21	HUB, REEL/BELT PICKUP PUMP .....	70 - 26
2D14	HOSES, 4-WHEEL DRIVE.....	50 - 60	1B11	HUB, ROTARY SCREEN DOOR .....	20 - 6
3E1	HOUSING ASSEMBLY, FEED .....	120 - 6	3I21	HUB, SEPARATOR DRIVE TORQUE SENSING.....	140 - 18
1E10	HOUSING CONNECTORS, FUEL INJECTION PUMP ..	30 - 6	3I19	HUB, SEPARATOR DRIVE VARIABLE SPEED.....	140 - 16
2B23	HOUSING COVER, TRANSMISSION/ DIFFERENTIAL .....	50 - 15	3J23	HUB, SLIP CLUTCH .....	140 - 45
1B23	HOUSING, ADJUSTABLE FAN DRIVE.....	20 - 18	3H18	HUB, STRAW SPREADER .....	135 - 18
3B10	HOUSING, AIR CONDITIONER AND HEATER, LOWER .....	95 - 4	2G15	HUB, STRAW SPREADER PUMP .....	70 - 44
3B8	HOUSING, AIR CONDITIONER AND HEATER, UPPER.....	95 - 2	3G14	HUB, UPPER TAILINGS ELEVATOR .....	130 - 18
4D9	HOUSING, AIR SUSPENSION (RUBBER TRACK) .....	160 - 8	3D11	HUB, VARIABLE SPEED FEEDER HOUSE.....	110 - 34
3B12	HOUSING, CAB AIR FILTER .....	95 - 6	3K1	HUBS, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER .....	140 - 48
2I24	HOUSING, CAB ROOF .....	90 - 10	3I11	HUBS, MAIN GEARCASE (9650 STS).....	140 - 8
3H6	HOUSING, CHOPPER.....	135 - 6	3I13	HUBS, MAIN GEARCASE (9750 STS).....	140 - 10
3G8	HOUSING, CLEAN GRAIN ELEVATOR GEARCASE ....	130 - 12	3K4	HUBS, UNLOADING AUGER COUNTERSHAFT DRIVE .....	140 - 52
3E9	HOUSING, DISCHARGE, SEPARATOR.....	120 - 14	2F17	HYDRAULIC FILTER, MAIN .....	70 - 22
1B21	HOUSING, ENGINE FAN .....	20 - 16	3I19	HYDRAULIC HOSE, SEPARATOR DRIVE VARIABLE SPEED .....	140 - 16
3B10	HOUSING, EVAPORATOR .....	95 - 4	2G7	HYDRAULIC HOSE, VARIABLE DRIVE, FEEDER HOUSE.....	70 - 36
3D7	HOUSING, FEEDER HOUSE CONVEYOR .....	110 - 30	2D12	HYDRAULIC LINES AND HOSES, L.H. 4-WHEEL DRIVE .....	50 - 58
3D3	HOUSING, FEEDER HOUSE UPPER SHAFT.....	110 - 26	2D16	HYDRAULIC LINES, CASE DRAIN, 4-WHEEL DRIVE .....	50 - 62
2C6	HOUSING, FINAL DRIVE .....	50 - 24	2E21	HYDRAULIC OIL RESERVOIR .....	70 - 1
3C11	HOUSING, FIXED SPEED FEEDER HOUSE .....	110 - 10	2E24	HYDRAULIC PRESSURE LINES AND HOSES .....	70 - 4
2J22	HOUSING, GEARSHIFT LEVER.....	90 - 34	2E22	HYDRAULIC PUMP, MAIN .....	70 - 2
4C1	HOUSING, HORIZONTAL UNLOADING AUGER (EXPORT) (17 AND 20 FT.).....	150 - 20	4E1	HYDRAULICS, TENSION CYLINDER (RUBBER TRACK) .....	160 - 26
4B23	HOUSING, HORIZONTAL UNLOADING AUGER (17 AND 20 FT.) .....	150 - 18	2C14	HYDROSTATIC DRIVE CHARGE PUMP .....	50 - 33
4B21	HOUSING, HORIZONTAL UNLOADING AUGER (17- AMD 20-FT.).....	150 - 16	2C8	HYDROSTATIC DRIVE CONTROL CABLES .....	50 - 26
4C3	HOUSING, HORIZONTAL UNLOADING AUGER SWIVEL .....	150 - 22	2C15	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE .....	50 - 34
2C12	HOUSING, HYDROSTATIC PUMP .....	50 - 30	2C17	HYDROSTATIC DRIVE MOTOR.....	50 - 36
2B24	HOUSING, INPUT SHAFT.....	50 - 16	2D8	HYDROSTATIC DRIVE OIL HOSES, UPPER .....	50 - 54
1H23	HOUSING, L.H. FRONT LIGHT .....	40 - 70	2D6	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE) .....	50 - 52
3G6	HOUSING, LOADING AUGER, UPPER CLEAN GRAIN .....	130 - 10	2C12	HYDROSTATIC DRIVE PUMP .....	50 - 30
3I9	HOUSING, MAIN GEARCASE .....	140 - 6	2C10	HYDROSTATIC DRIVE PUMP COVER .....	50 - 28
1D12	HOUSING, OIL FILTER .....	25 - 32	2C10	HYDROSTATIC DRIVE PUMP SHAFT.....	50 - 28
2J24	HOUSING, R.H. CORNERPOST DISPLAY PANEL .....	90 - 36	2C19	HYDROSTATIC MOTOR VALVE .....	50 - 39
1H24	HOUSING, R.H. FRONT LIGHT .....	40 - 71	2D10	HYDROSTATIC OIL COOLER LINES AND HOSES .....	50 - 56
1C23	HOUSING, REAR OIL SEAL.....	25 - 15			
3C8	HOUSING, REVERSER GEARBOX (HI CAPACITY).....	110 - 6			
3C9	HOUSING, REVERSER GEARBOX (STANDARD) .....	110 - 8			
2J16	HOUSING, STEERING COLUMN (LOWER) .....	90 - 28			
1D19	HOUSING, THERMOSTAT, FRONT .....	25 - 40	1B10	IDLER ARM, ROTARY SCREEN .....	20 - 4
2B22	HOUSING, TRANSMISSION .....	50 - 14	4D7	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM (RUBBER TRACK) .....	160 - 6
2C3	HOUSING, TRANSMISSION/DIFFERENTIAL .....	50 - 20	3J13	IDLER ASSEMBLY, CLEAN GRAIN ELEVATOR DRIVE .....	140 - 35
1I3	HOUSING, TRANSPORT WARNING LIGHTS .....	40 - 75	3J22	IDLER ASSEMBLY, DISCHARGE BEATER DRIVE.....	140 - 44
3I23	HOUSING, TWO-SPEED GEARBOX .....	140 - 20	3J10	IDLER ASSEMBLY, FEED ACCELERATOR .....	140 - 32
3I15	HOUSINGS, MAIN GEARCASE .....	140 - 12	3J21	IDLER ASSEMBLY, SHOE/CONVEYOR AUGER DRIVE .....	140 - 43
3I11	HOUSINGS, MAIN GEARCASE (9650 STS) .....	140 - 8	3K3	IDLER ASSEMBLY, STRAW CHOPPER DRIVE .....	140 - 50
3I13	HOUSINGS, MAIN GEARCASE (9750 STS) .....	140 - 10	3J19	IDLER ASSEMBLY, TAILINGS ELEVATOR DRIVE.....	140 - 41
3C6	HOUSINGS, REVERSER GEARBOX (HI-CAPACITY)....	110 - 4	3K6	IDLER ASSEMBLY, UNLOADER DRIVE .....	140 - 54
2J18	HOUSINGS, STEERING COLUMN (UPPER).....	90 - 30	3K7	IDLER ASSEMBLY, UNLOADING AUGER DRIVE SPROCKET .....	140 - 55
4D16	HUB, BOGEY WHEEL (RUBBER TRACK).....	160 - 16			
3J20	HUB, CHAFFER FRAME SHOE DRIVE.....	140 - 42			
3G3	HUB, CLEAN GRAIN ELEVATOR.....	130 - 6			
1B25	HUB, COUPLING, ENGINE GEARCASE .....	20 - 20			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE
4D11	IDLER AXLE (RUBBER TRACK) .....	160 - 10
3D9	IDLER BRACKET, FEEDER CONVEYOR .....	110 - 32
1C2	IDLER PULLEY, AIR CONDITIONER DRIVE.....	20 - 22
3D7	IDLER SHAFT, FEEDER HOUSE CONVEYOR.....	110 - 30
4D13	IDLER WHEEL ASSEMBLY (RUBBER TRACK) .....	160 - 12
3K1	IDLER, CLEAN GRAIN ELEVATOR DRIVE .....	140 - 48
3C15	IDLER, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER.....	110 - 14
3C13	IDLER, VARIABLE SPEED FEEDER HOUSE DRIVE TIGHTENER.....	110 - 12
2J18	IGNITION SWITCH .....	90 - 30
3F12	INDICATOR, SIEVE FRAME .....	125 - 12
3F10	INDICATORS, CHAFFER ELEMENT .....	125 - 10
3F8	INDICATORS, CHAFFER FRAME .....	125 - 8
1E8	INJECTION PUMP GEAR .....	30 - 4
1E8	INJECTION PUMP LUBE LINE.....	30 - 4
1E8	INJECTION PUMP, ELECTRONIC FUEL.....	30 - 4
2C22	INNER COVER, CAM LOBE MOTOR .....	50 - 42
2B24	INPUT SHAFT, TRANSMISSION .....	50 - 16
1D2	INSERTS, VALVE SEAT .....	25 - 20
1D21	INTAKE MANIFOLD.....	25 - 42
1D21	INTAKE MANIFOLD GASKET.....	25 - 42
1D2	INTAKE VALVES .....	25 - 20
1D9	INTAKE, ENGINE OIL PUMP .....	25 - 28
2I24	INTERIOR CAB ROOF .....	90 - 10
2I22	INTERIOR PANELS, CAB .....	90 - 8

J

3J24	JACKSHAFT ASSEMBLY, ELEVATOR DRIVE .....	140 - 46
3J18	JACKSHAFT ASSEMBLY, FAN DRIVER .....	140 - 40
3J12	JACKSHAFT, DRIVER, FEED ACCELERATOR.....	140 - 34
3H12	JACKSHAFT, STRAW CHOPPER .....	135 - 12
3K4	JACKSHAFT, UNLOADING AUGER COUNTERSHAFT DRIVE .....	140 - 52
1C12	JETS, PISTON COOLING .....	25 - 4

K

1C19	KEY, DAMPER.....	25 - 11
3G8	KIT, CLEAN GRAIN ELEVATOR GEARCASE .....	130 - 12
1F17	KIT, CONVENIENCE, OUTLET.....	40 - 12
3E11	KIT, COVER REPAIR .....	120 - 16
1E1	KIT, CYLINDER HEAD .....	25 - 48
1F10	KIT, ELECTRICAL CONNECTOR SERVICE .....	40 - 4
1F12	KIT, ELECTRICAL CONNECTOR SERVICE (CONTINUED) .....	40 - 6
1C16	KIT, ENGINE OVERHAUL.....	25 - 8
1E1	KIT, ENGINE REBUILD .....	25 - 48
3E11	KIT, FLIGHT REPAIR .....	120 - 16
2J22	KIT, GEARSHIFT LEVER .....	90 - 34
1D2	KIT, HEAD BOLT .....	25 - 20
2C15	KIT, HYDROSTATIC DRIVE DISPLACMENT CONTROL VALVE.....	50 - 34
2C10	KIT, HYDROSTATIC DRIVE PUMP .....	50 - 28
2C12	KIT, HYDROSTATIC DRIVE PUMP (CONTINUED) .....	50 - 30
2C19	KIT, HYDROSTATIC MOTOR VALVE .....	50 - 39
3E11	KIT, NOSE SPIDER REPAIR .....	120 - 16
1C18	KIT, PISTON/LINER.....	25 - 10
3E11	KIT, RIVNUT REPAIR .....	120 - 16
2C17	KIT, SEAL, HYDROSTATIC DRIVE MOTOR .....	50 - 36
2E9	KIT, SEAL, STEERING VALVE.....	60 - 14
1F14	KIT, TERMINAL AND WIRING .....	40 - 8
3E11	KIT, THRESHING ELEMENT REPAIR .....	120 - 16

GRID		PAGE
3E11	KIT, TINE REPAIR.....	120 - 16
1C21	KIT, UNDERSIZED MAIN BEARING CRANKSHAFT .....	25 - 13
3C4	KIT, VARIABLE SPEED FEEDER HOUSE.....	110 - 2
1D17	KIT, WATER PUMP SEAL.....	25 - 38
1C20	KIT,UNDERSIZE CRANKSHAFT (CONNECTING ROD JOURNAL) .....	25 - 12
2E3	KITS, BRAKE MASTER CYLINDER .....	60 - 8
2E5	KITS, BRAKE SHOES AND DRUM .....	60 - 10
2J9	KITS, OPERATOR'S SEAT .....	90 - 20
3E11	KITS, SEPARATOR CONE REPAIR.....	120 - 16
1B11	KNIFE, ROTARY SCREEN DOOR .....	20 - 6
3H6	KNIFEBANK, CHOPPER .....	135 - 6

L

4E17	L.H. DECALS .....	170 - 14
3C19	L.H. DRIVE SHIELDS .....	110 - 18
1H23	L.H. FRONT LIGHT .....	40 - 70
2H13	L.H. GULLWING DOOR.....	80 - 12
1F21	L.H. MAIN WIRING HARNESS .....	40 - 17
1F22	L.H. MAIN WIRING HARNESS (CONTINUED) .....	40 - 18
1F24	L.H. MAIN WIRING HARNESS (CONTINUED) .....	40 - 20
2H15	L.H. REAR GULLWING DOOR .....	80 - 14
2H5	L.H. SEPARATOR FRAME .....	80 - 4
2H7	L.H. SHIELDS.....	80 - 6
4E7	L.H. SIDE SAFETY DECALS .....	170 - 4
4E25	LABELS, FRENCH CANADIAN.....	170 - 22
4F1	LABELS, PORTUGESE .....	170 - 23
4F2	LABELS, ROMANIAN.....	170 - 24
4F3	LABELS, RUSSIAN .....	170 - 25
4E21	LABELS, SAFETY, RUBBER TRACK.....	170 - 18
4F4	LABELS, SPANISH .....	170 - 26
4F5	LABELS, UKRAINIAN .....	170 - 27
2K7	LADDER EXTENSION ASSEMBLY .....	90 - 44
2I6	LADDER, ENGINE PLATFORM .....	80 - 32
2K5	LADDER, HANDRAILS AND EXTENSION .....	90 - 42
2I1	LADDER, REAR LANDING .....	80 - 26
1I3	LAMP, TRANSPORT WARNING LIGHTS .....	40 - 75
2H24	LAMP, TURN SIGNAL, REAR ACCESS DOOR .....	80 - 24
2H17	LAMPS, TURN SIGNAL, REAR WALL .....	80 - 16
2K8	LANDING, L.H.....	90 - 46
2I1	LANDING, LADDER, REAR.....	80 - 26
2K10	LANDING, R.H. ....	90 - 48
2I5	LANDING, REAR FIXED .....	80 - 30
2I3	LATCH ARM, REAR LADDER LANDING.....	80 - 28
3D5	LATCH HANDLE, FEED PLATE .....	110 - 28
2J3	LATCH, CAB DOOR .....	90 - 14
3H14	LATCH, CHOPPER AND SPREADER DRIVE SHIELD ..	135 - 14
4B17	LATCH, GRAIN TANK CLEAN OUT CHUTE .....	150 - 12
4B15	LATCH, GRAIN TANK WINDOW .....	150 - 9
1B18	LATCH, RADIATOR .....	20 - 13
3H24	LATCH, STRAW SPREADER .....	135 - 24
2H11	LEFT FRONT PANEL AND DOOR.....	80 - 10
1H23	LENS, L.H. FRONT LIGHT .....	40 - 70
1H24	LENS, R.H. FRONT LIGHT .....	40 - 71
1I1	LENS, REAR TURN AND TAIL LIGHTS .....	40 - 73
1H22	LENSES, CAB ROOF LIGHT .....	40 - 69
3G5	LEVER, CLEAN GRAIN ELEVATOR BOOT ASSEMBLY .....	130 - 8
2J22	LEVER, GEARSHIFT .....	90 - 34
2C8	LEVER, HYDROSTATIC DRIVE CONTROL CABLES....	50 - 26
2C15	LEVER, HYDROSTATIC DRIVE DISPLACMENT CONTROL VALVE.....	50 - 34
2K7	LEVER, LADDER EXTENSION ASSEMBLY .....	90 - 44
3G12	LEVER, LOADING AUGER SPOUT ASSEMBLY.....	130 - 16