

LG958L轮式装载机 零部件图册

LG958L WHEEL LOADER PARTS CATALOG

山东临工工程机械有限公司

SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

配件与服务 Spare parts and services

对于山东临工机器的所有者来说,只有山东临工配件和服务才能够使您的机器更好地保持原有的特性。

For the owner of the machines of SDLG,only the space parts and services of SDLG can mark your machine to better maintain the original features.

只有山东临工才能够为您提供完美匹配且优质纯正的配件和对您的机器了如指掌的专业维修人员。这样才能保证及其可持续的高产能和更长的使用寿命。

Only SDLG is able to provide you with the perfect match of pure quality spare parts for your machine and knowledge of professional maintenance staff.Only in this way it can ensure sustainable high productivity and longer service life.

LG958L轮式装载机 零部件图册 LG958L WHEEL LOADER PARTS CATALOG

2009年2月 第1版 第1次印刷

2009-2 Version 1 Printed 1

山 东 临 工 程 机 械 有 限 公 司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

地址: 中国·临沂经济开发区临工工业园

Add: Lingong Industry Park,Linyi Economic Development Zone,Shandong,china

电话: 86-0539-8785668

Tel: 86-0539-8785624/86-0531-66590955

传真: 86-0539-8785698

Fax: 86-0539-8785618/86-0531-66590959

技术服务: 86-0539-8785800 400-6587999

Web: www.sdlg.cn

前言

LG958L轮式装载机零部件图册，是为了方便用户使用、维修和保养而绘制的，以供在使用过程中查阅及参考，也可帮助用户了解本机的结构和装配关系。发动机的零部件详见其随机资料，本图册不再绘出。

本图册按系统划分绘制出了各零部件的图形及相互装配关系。凡装机后不可拆卸的部件(如焊接件、铆合件)，只标出部件代号，不另列其组成零件。本图册明细表采用中英文对照编排。

本图册主要根据标准型产品(订货号E5814215A39)编绘，其它非标准配置，可参照执行，详情请咨询山东临工、或当地经销商、或登录山东临工网站查询。随着科技的进步，产品将会不断改进，故本图册的内容可能会有部分与以后的产品不一致，恕不另行通知。敬请用户在定购配件时，指明所购整车的出厂日期和编号。

编者

2009年12月

FOREWORD

THIS PARTS LIST OF LG958L WHEEL LOADER IS MADE FOR THE CONVENIENCE OF USERS TO USE ,REPAIR AND MAINTAIN THE MACHINE,AND IT CAN BE REFERED IN THE PROCESS OF USING.IT CAN ALSO HELP THE USERS TO BE FAMILIAR WITH THE CONSTRUCTION AND ASSEMBLY RELATION OF THE MACHINE. THE PART OF THE ENGINE IS SHOWED IN DETAIL IN ITS STRUCTION HANDBOOK.SO THIS CATALOG DOES NOT CONTAIN THE ENGING PART LIST.

THE CATALOG CONTAINS THE PART DRAWINGS OF DEFERENT ASSEMBLIES,SHOWING THE SHAPE OF THE PARTS AS WELL AS THE ASSEMBLING RELATION.THE COMPONENTS WHICH CAN NOT BE TAKEN APART (SUCH AS THE WELDMENT OR RIVETED ASSEMBLIES) ARE INDICATED ONLY BY THEIR COMPONET NUMBERS WITHOUT THE CONSISTING PART NUMBERS .THE LIST IN THE CATALOG IS ARRANGED BY CHINESE VERSUS ENGLISH.

THIS CATALOG IS MAINLY BASED ON THE STANDARD PRODUCT(ORDER NUMBER E5814215A39) THE OTHERS OF NONSTANDARD PRODUCT CAN REFER THE STANDARD PRODUCT,AND THE DETAILED INFORMATION CAN BE KNOWN FROM SHANDONG LINGONG,THE LOACAL DEALER OR LINGONG WEBSITE ALTERATIONS IN DESIGN ARE NECESSARILY WITH THE THECHNICAL DEVELOPMENT SO SOME CONTENT IN THE CATALOG PROBABLY IS NOT CONSISTANT WITH THE FUTURE PRODUCTS,AND THIS WILL NOT NOTICE USERS.THEREFORE WHEN ORDERING SPARE PARTS, USERS ARE KINDLY REQUSETED TO INFORM US THE MANUFACTURING DATE AND BATCHNUMBER OF THE WHEEL LOADER.

THE COMPILER

2009.12

目录 CONTENTS

A. 发动机系统

A. DIESEL ENGINE SYSTEM

发动机总成	A1-2901001449
DIESEL ENGINE ASSEMBLY	A1-2901001449
燃油箱总成	A2-2902000845
FUEL TANK ASSEMBLY	A2-2902000845
散热器总成	A3-2903001015
RADIATOR ASSEMBLY	A3-2903001015
油门操纵机构	A4-2901000867
GOVERNOR CONTROL SYSTEM	A4-2901000867
进气预热组AH 9141	A5-4110000081
AID,AIR HEATER STARTING	A5-4110000081
参数牌组AP 9484	A6-4110000081
APPROVAL,AGENCY	A6-4110000081
缸体管路连接件组BB9093	A7-4110000081
PLUMBING,CY BLK LBC	A7-4110000081
缸体冷却管路组BB9099	A8-4110000081
PLUMBING,CYL BLK COOLANT	A8-4110000081
缸体组BB9110	A9-4110000081
BLOCK,ENGINE	A9-4110000081

齿轮室组BB 9881	A10-4110000081
HOUSING, FRONT GEAR	A10-4110000081
曲轴箱通风组BR 9198	A11-4110000081
BREATHER,CRANKCASE	A11-4110000081
空压机冷却水管组CC9287	A12-4110000081
PLUMBING,CPR COOLANT	A12-4110000081
冷却液辅助连接管组CH9087	A13-4110000081
PLUMBING,COO HTR STG AID	A13-4110000081
空压机进气布置组CI9168	A14-4110000081
ARRANGEMENT,CPR AIR INLE	A14-4110000081
空压机组CP 9551	A15-4110000081
COMPRESSOR,AIR	A15-4110000081
扭振减振器组DA9728	A16-4110000081
DAMPER,VIBRATION	A16-4110000081
前端齿轮系附件安装件组DF9159	A17-4110000081
MOUNTING,FRO GER TRA AC	A17-4110000081
电子附件组EA9077	A18-4110000081
ACCESSORIES,ELECTRICAL	A18-4110000081
搭铁线组EA9089	A19-4110000081
ACCESSORIES,ELECTRICAL	A19-4110000081

节温器组EC9702	A20-4110000081
THERMOSTAT	A20-4110000081
标签组ED9071	A21-4110000081
DOCUMENTATIO,ENG IDT	A21-4110000081
发电机组EE9176	A22-4110000081
ALTERNATOR	A22-4110000081
发电机安装件组EH9434	A23-4110000081
MOUNTINT,ALTERNATOR	A23-4110000081
传感器组EO9135	A24-4110000081
DEVICE,SIGNAL GENERATING	A24-4110000081
风扇驱动件组FA9371	A25-4110000081
DRIVE,FAN	A25-4110000081
风扇驱动件组FA9739	A26-4110000081
DRIVE,FAN	A26-4110000081
增压补偿器连接管组FE9050	A27-4110000081
PLUMBING,AIR FUEL CONTR	A27-4110000081
燃油滤清器组FF 9340	A28-4110000081
FILTER, FUEL	A28-4110000081
燃油滤清器连接管路组FF 9489	A29-4110000081
PLUMBING,FUEL FILTER	A29-4110000081

飞轮壳组FH 9464	A30-4110000081
HOUSING,FLYWHEEL	A30-4110000081
基本燃油泵组FP90506	A31-4110000081
PUMP,FUEL	A31-4110000081
燃油泵连接件组FP90636	A32-4110000081
MOUNTING,FUEL PUMP	A32-4110000081
供油系附件组FS9724	A33-4110000081
ACCESSORIES, FUEL SUPP	A33-4110000081
燃油管路组FT 9142	A34-4110000081
PLUMBING,FUEL	A34-4110000081
断油电磁阀FV 9373	A35-4110000081
VALVE,FUEL SHUTOFF	A35-4110000081
飞轮组FW 9826	A36-4110000081
FLYWHEEL	A36-4110000081
飞轮安装件组FW90025	A37-4110000081
MOUNTING,FLYWHEEL	A37-4110000081
齿轮室盖组GG 9779	A38-4110000081
COVER,FRONT GEAR	A38-4110000081
齿轮室盖安装件组GG 9804	A39-4110000081
MOUNTING, GEAR COVER	A39-4110000081

空压机控制装置组GV 9035	A40-4110000081
GOVERNOR,AIR COMPRESSOR	A40-4110000081
暖风安装件组HC 9073	A41-4110000081
PLUMBING,CABIN HEATER	A41-4110000081
发动机吊耳组LA 9068	A42-4110000081
BRACKET, LIFTING	A42-4110000081
机油冷却器组LC 9227	A43-4110000081
COOLER,ENGINE OIL	A43-4110000081
机油滤清器组LF 9130	A44-4110000081
FILTERMLUBRICATING OIL	A44-4110000081
机油标尺组LG 9939	A45-4110000081
GAUGE,OIL LEVEL	A45-4110000081
机油组LO 9701	A46-4110000081
OIL,ENGINE	A46-4110000081
机油泵组LP 9725	A47-4110000081
PUMP,LUBRICATING OIL	A47-4110000081
加机油装置OB 9329	A48-4110000081
ARRANGEMENT,OIL FILL	A48-4110000081
缸体加油附件组OB 9337	A49-4110000081
COVER,HAND HOLE	A49-4110000081

油底壳组OP 9352	A50-4110000081
PAN, OIL	A50-4110000081
附件驱动皮带轮组PA 9001	A51-4110000081
PULLEY,ACCESSORY	A51-4110000081
性能件组PP40722	A52-4110000081
PERFORMANCE,PARTS	A52-4110000081
气缸盖管路组PP98457	A53-4110000081
PLUMBING,HEAD CYLINDER	A53-4110000081
增压器组PP98560	A54-4110000081
TURBOCHARGER	A54-4110000081
喷油器连接件组PP98841	A55-4110000081
PLUMBING,INJECTOR	A55-4110000081
发动机冷却液出气管组RP 9036	A56-4110000081
VENT, ENGINE COOLANT	A56-4110000081
起动机安装件组SM 9104	A57-4110000081
MOUNTING,STARTING MOTOR	A57-4110000081
风扇隔块SP 9078	A58-4110000081
SPACE,FAN	A58-4110000081
油漆组SS 9471	A59-4110000081
PAINT	A59-4110000081

起动机组ST 9345	A60-411000081
MOTOR, STARTING	A60-411000081
增压器布置组TB91070	A61-411000081
ARRANGEMENT,TURBOCHARGER	A61-411000081
排气歧管组TB91072	A62-411000081
MANIFOLD,EXHAUST	A62-411000081
中冷器组TB91073	A63-411000081
AFTERCOOLER	A63-411000081
扭矩转换器冷却组TK 9022	A64-411000081
COOLER, TOR CONVERTER	A64-411000081
加速操纵线调整固定板TL 9098	A65-411000081
LEVER,THROTTLE	A65-411000081
服务工具组TO L006	A66-411000081
TOOL,SERVICE	A66-411000081
增压器管路组TP97293	A67-411000081
PLUMBING,TURBOCHARGER	A67-411000081
气阀室罩组VC 9221	A68-411000081
COVER, VALVE	A68-411000081
中冷器管路组WA 9754	A69-411000081
PLUMBING,AFT WATER	A69-411000081

水滤清器组WF 9094	A70-4110000081
RESISTOR, CORROSION	A70-4110000081
进水连接管组WI 9145	A71-4110000081
CONNECTION, WATER INLE	A71-4110000081
出水连接管组WO 9052	A72-4110000081
CONNECTION, WATER OUTL	A72-4110000081
皮带张紧轮组WP 9916	A73-4110000081
TENSIONER, BELT	A73-4110000081
水泵组WP 9918	A74-4110000081
PUMP, WATER	A74-4110000081
水泵驱动件组WP 9967	A75-4110000081
DRIVE,WATER PUMP	A75-4110000081
增压器排气连接件组XS 9268	A76-4110000081
CONNECTOR,TUR OUTLET	A76-4110000081
摇臂组RL 9732	A77-4110000081
LEVER, ROCKER	A77-4110000081

B. 变矩器系统

B. TORQUE CONVERTER SYSTEM

双变总成	B1-2905001267
TRANSMISSION ASSEMBLY	B1-2905001267

C. 变速箱系统

C. TRANSMISSION SYSTEM

发动机连接总成4644 130	C2-4110000042
ENGINE CONNECT ASSEMBLY 4644 130	C2-4110000042
输入装置4644 102	C4-4110000042
INPUT 4644 102	C4-4110000042
变速箱总成4644 101	C5-4110000042
GEARBOX HOUSING ASSEMBLY 4644 101	C5-4110000042
中间轴4644 108	C6-4110000042
LAYSHAFT 4644 108	C6-4110000042
离合器KV+K1 4644 151	C7-4110000042
COUPLNG KV+K1 4644 151	C7-4110000042
离合器KR+K2 4644 152	C8-4110000042
COUPLNG KR+K2 4644 152	C8-4110000042
离合器4644 153	C9-4110000042
COUPLNG 4644 153	C9-4110000042
输出装置4644 103	C10-4110000042
OUTPUT 4644 103	C10-4110000042
停车制动器4644 109	C11-4110000042
PARKING BRAKE 4644 109	C11-4110000042

停车制动器0501 003	C12-4110000042
PARKING BRAKE 0501 003	C12-4110000042
取力器 4644 154	C13-4110000042
POWER TAKE-OFF 4644 154	C13-4110000042
取力器4644 155	C14-4110000042
POWER TAKE-OFF 4644 155	C14-4110000042
变速调档系统4644 106	C15-4110000042
GEARSHIFT SYST 4644 106	C15-4110000042
变速调档系统4644 159	C16-4110000042
GEARSHIFT SYST 4644 159	C16-4110000042
调压阀4644 120	C17-4110000042
PRESS.REGULATOR 4644 120	C17-4110000042
过滤器4644 138	C18-4110000042
FILTER 4644 138	C18-4110000042
应急转向泵4644 137	C19-4110000042
EMCY.STEER.PUMP 644 137	C19-4110000042
感应式传感器4644 125	C20-4110000042
IND.TRANSMITTER 4644 125	C20-4110000042
注入管接头4644 131	C21-4110000042
FILLER NECK 4644 131	C21-4110000042

油管4644 121	C22-4110000042
OIL PIPES 644 121	C22-4110000042
散件4644 199	C23-4110000042
LOOSE PARTS 4644 199	C23-4110000042

E. 驱动桥系统

E. AXLE SYSTEM

前桥总成	E1-2907001228
FRONT AXLE ASSEMBLY	E1-2907001228
前主传动总成	E2-2907000006
FRONT AXLE MAIN DRIVE ASSEMBLY	E2-2907000006
轮边减速器(前桥)	E3-2907001091
FINAL DRIVE ASSEMBLY	E3-2907001091
传动轴总成	E4-2908000778
DRIVE SHAFT GROUP	E4-2908000778
后桥总成	E5-2909000817
REAR AXLE ASSEMBLY	E5-2909000817
后主传动总成	E6-2909000003
REAR AXLE MAIN DRIVE ASSEMBLY	E6-2909000003
制动钳(371328)	E8-4120001739
DISK BRAKE(371328)	E8-4120001739

轮胎GB2980-23.5-25 (520101)	E11-4110000006
TIRE GB2980-23.5-25 (520101)	E11-4110000006
轮胎 23.5-25-18PR-L3 (371002)	E12-4110000582
TIRE 23.5-25-18PR-L3	E12-4110000582

F. 工作装置液压系统

F. IMPLEMENT HYDRAULIC SYSTEM

液压操纵总成	F1-2912001715
HYDRAULIC CONTROL ASSEMBLY	F1-2912001715
工作泵总成	F2-2911000876
WORKING PUMP ASSEMBLY	F2-2911000876
举升缸总成	F3-2913001205
LIFTING CYLINDER ASSEMBLY	F3-2913001205
转斗缸总成	F4-2914001017
DUMP CYLINDER ASSEMBLY	F4-2914001017
液压油箱总成	F5-2910001003
HYDRAULIC TANK ASSEMBLY	F5-2910001003
转斗油缸 (371368)	F7-4120002264
TILT CYLINDER	F7-4120002264
动臂油缸 (371368)	F9-4120002263
LIFT ARM CYLINDER	F9-4120002263

H. 工作装置

H. WORKING EQUIPMENT

工作装置	H1-2915001046
WORKING EQUIPMENT	H1-2915001046
铲斗总成	H2-2917003706
BUCKET ASSEMBLY	H2-2917003706

I. 转向系统

I. STEERING SYSTEM

转向泵总成	I1-2919000901
STEERING PUMP ASSEMBLY	I1-2919000901
转向器总成	I2-2920000831
STEERING GEAR ASSEMBLY	I2-2920000831
转向缸总成	I3-2921000862
STEERING CYLINDER ASSEMBLY	I3-2921000862
转向油缸(371368)	I5-4120000553
STEERING CYLINDER	I5-4120000553

J. 制动系统

J. BRAKE SYSTEM

行车制动总成	J1-2922000915
SERVICE BRAKE SYSTEM	J1-2922000915

储气罐	J2-2922000053
AIR RESERVOIR	J2-2922000053
加力泵(340201)	J3-4120000675
BRAKE BOOSTER	J3-4120000675
驻车制动系统	J4-2923000751
PARKING BRAKE SYSTEM	J4-2923000751

K. 车架

K. FRAME

前车架总成	K1-2924001161
FRONT FRAME	K1-2924001161
铰接	K2-2925000001
ARTICULATION	K2-2925000001
灯架及挡泥瓦	K3-2925000850
LAMP FRAME AND FRONT FENDER	K3-2925000850
后车架及配件	K4-2926001376
REAR FRAME AND ACCESSORIES	K4-2926001376
配重铁总成	K5-2928000819
COUNTER WEIGHT	K5-2928000819

L. 驾驶室

L. CAB GROUP

驾驶室总成	L1-2929000881
CAB ASSEMBLY	L1-2929000881
驾驶室	L2-2929000916
CAB	L2-2929000916
操作台架	L3-2931001426
OPERATE BENCH	L3-2931001426
座椅总成	L4-2930000772
SEAT ASSEMBLY	L4-2930000772
操纵箱	L5-2932000957
OPERATE BOX	L5-2932000957

M. 覆盖件系统

M. CONVER SYSTEM

发动机罩总成	M1-2933001510
HOOD OF DIESEL ENGINE ASSEMBLY	M1-2933001510
左台架总成	M2-2934001541
LEFT BENCH GROUP	M2-2934001541
右台架总成	M3-2934001556
RIGHT BENCH GROUP	M3-2934001556
后转向灯罩	M4-2934001568
REAR STEERING LAMP HOOD	M4-2934001568



标志与标识	M5-2936001200
SIGN AND LOGO	M5-2936001200
电瓶箱	M6-2934001572
BATTERY CASE	M6-2934001572
工具箱	M7-2934001581
TOOL CASE	M7-2934001581
N. 空调系统	
N. AIR CONDITIONER SYSTEM	
暖风机	N1-2935000888
WARMING MACHINE	N1-2935000888
空调系统	N2-2935000899
AIR CONDITIONER SYSTEM	N2-2935000899
暖风机	N3-4190000917
WARMING MACHING	N3-4190000917
O. 电气系统	
O. ELECTRIC SYSTEM	
电气系统	O1-2937001519
ELECTRIC SYSTEM	O1-2937001519
仪表盘总成	O2-2937001531
PANEL ASSEMBLY	O2-2937001531