


Manitou Buggie Mc20p Instructions Sec Wat

Full download: <http://manualplace.com/download/manitou-buggie-mc20p-instructions-sec-wat/>

10241387
LOC: BH 02 C 02
Qty: st
Ord: 0
0M-MC 20P

MANITOU



BUGGIE
MC 20P
OPERATORS
MANUAL
S/N 72562

MANITOU BF SA

Z.I ROUTE de CHATEAUBRIANT

44 150 ANCENIS FRANCE

TEL. (40) 83 14 00

Télex pièce de rechange 710 513

RC NANTES B 857 802 508

CCP NANTES 1683 51

BUGGIE

MC 20P

OPERATOR'S

MANUAL

S/N 72562

D. 635

INDEX

INTRODUCTION	4
DESCRIPTION	5
SPECIFICATIONS	6
INSTRUMENTS AND CONTROLS	10
OPERATING ADVICE TO DRIVERS	15
OPERATING INSTRUCTIONS	16
BEFORE OPERATING A NEW TRUCK	17
DRIVING THE TRUCK	18
OILS, GREASES, LIQUIDS, FUELS, FILTERS	20
SERVICING SCHEDULE	22
DAILY OR EVERY 10 HOURS SERVICE	23
EVERY 50 HOURS SERVICE	24
EVERY 150 HOURS SERVICE	28
EVERY 300 HOURS SERVICE	32
EVERY 450 HOURS SERVICE	33
EVERY 900 HOURS SERVICE	35
SEASONAL MAINTENANCE	37
ELECTRICAL SYSTEM	39
HYDRAULIC CIRCUIT	43

INTRODUCTION

This fork lift truck is designed and constructed so that it is easy for the driver to maneuver and all parts are accessible for the mechanic to maintain it.

Before using the truck, the operator should study the various chapters in this manual to familiarize himself with the driving controls and the maintenance instructions contained in it. The operator should follow these instructions and insure that the capacities of the truck are not exceeded.

In the manual, the terms left, right, forward and rearward should be read as if the observer was sitting in the driver's seat and looking forward.

Whenever ordering parts or making a technical inquiry, always specify :

- Truck model number (Fig. A) : -----
- Truck serial number (Fig. A) : -----
- Attachment model number (Fig. A) : -----
- Attachment serial number (Fig. A) : -----
- Power train number (Fig. A) : -----
- Mast model number (Fig. B) : -----
- Mast serial number (Fig. B) : -----
- Year of manufacture (Fig. A) : -----
- engine number (Fig. C) : -----
- Drive axle number (Fig. D) : -----

Fig. A

MANITOU
K-D MANITOU, Inc.
WACO, TEXAS 76792

TRUCK MODEL: _____
 TRUCK SERIAL NO.: _____
 ATTACHMENT: _____
 ATTACHMENT SERIAL NO.: _____
 POWER TRAIN NO.: _____
 MAST MODEL: _____
 MAST SERIAL NO.: _____
 YEAR OF MFG.: _____
 ENGINE NO.: _____
 DRIVE AXLE NO.: _____

CAPACITIES WITH ATTACHMENTS LISTED ABOVE ARE WITH
 100% EFFICIENCY FACTOR. FOR OTHER CAPACITIES CON-
 TACT THE FACTORY.
 AS RELEASED FROM THE FACTORY, THIS TRUCK CON-
 FORMS TO AMERICAN NATIONAL STANDARDS INSTITUTE
 DESIGN STANDARDS B56.1 & B56.2 1979

For the owners' convenience, it is recommended that a note of these numbers is made in the spaces above.

Fig. D




Fig. C



Fig. B

