

HYSTER

SERVICE MANUAL INDEX

- **Class IV – Space Saver**
- **Class V – Challenger**
- **Class I – Electric Sit Drive**
- **Parts & Service Grams**
- **Class II – Narrow Aisle**
- **Class II – Order Picker**
- **Class II – Hi-Racker & RackLoader II**
- **Class III – Walkie & Walkie/Rider**
- **Class V – Reach Stacker & Yard Master**

INDEX
HELP

CLASS IV – SPACE SAVER

S25-35XL

S25-35XM, S40XMS

S30-50E, S60ES

S40-50F

S40-60XL

S40-65XM

TEMP SPACE

S60-120E

S70-120XL

S135-155XL

TEMP SPACE

S70-120XM (ODYSSEY)

TEMP SPACE

CLASS V – CHALLENGER

H25-35XL

H25-35XM, H40XMS

H30-60H (E3)

H40-60J, H60JS

H40-60XL (A177)

H40-60XL (B177/C177)

H45-65XM (D177)

H45-65XM (H177/K177)

H60-110E

H70-120XL (F005/G005)

H70-120XM (LASER)

H135-155XL

TEMP SPACE

H150-275H, P150-200B

H165-280XL, H300-360XL

H170-280HD, H300-360HD

H330-360HD-EC

H300-350B

H360-620B

H360-650C, H370-700C

H400H-EC, H450H-EC

H440-700F/FS

H700-920B

H800-970C, H1050CH

H800-970E, H1050EH

CLASS I – ELECTRIC

A20XL, A25XL, A30XL

E20-25B, E30BS

E30-50B, E60BS, E60-120B

E25-60XL

E25-35XM, E40XMS

E25-35XM₂, E40XMS₂

E30-40-50ER

E30-50FR, E30FR-24

E30FR₂

E30-40HSD

E45-65XM

E45-65XM₂

E70-120XL

E70-120XL₃

J25A, J30AS, J35A

J25-35B, J30BS

J30-35-40XMT

J30-35-40XMT₂

TEMP SPACE

J40-50A, J60AS

J40-60XL

J40-65XM

J40-65XM₂

N30XMH

N30XMH₂

PARTS & SERVICE GRAMS

Technical Notes:

Refer to the Gram index for appropriate gram for the selected unit.

At the bottom of truck content page will be a **Technical Note** link for additional information for that unit.

CLASS II

NARROW - AISLE

N30-50CA, N30-40CR

**N40-50EA, N40-45ER, N30FR,
N40-45FR, N50FA**

**N30-45XMR, N30-45XMR₂,
N25-30XMDR, N25-30XMDR₂, N30XMXDR,
N45XMXR, N50XMA, N50XMA₂**

N25-30XMDR₃

TEMP SPACE

TEMP SPACE

CLASS II

ORDER PICKER

R25A

R30C, R30CA, R30CR

**R30E, R30EA, R30EF, R30ES, R30F, R30FA,
R30FF**

R30XM, R30XMA, R30XMF, R30XMS

R30XM₂, R30XMA₂, R30XMF₂, R30XMS₂

TEMP SPACE

TEMP SPACE

CLASS II

HI-RACKER and RACKLOADER II

R40BH

R40EH

R30CH

V30XMU

TEMP SPACE

TEMP SPACE