

THIS MANUAL IS AN ONLINE BACKUP TO YOUR
ORIGINAL HARDCOPY VERSION.

RX7CITY.COM ASSUMES NO RESPONSIBILITY IN HOW YOU USE
THIS MANUAL. THIS MANUAL IS FOR EXPERIENCED MECHANICS
AND IS TO BE USED AT YOUR OWN RISK!




Before beginning any service procedure, refer to 1993 RX-7 Body Electrical Troubleshooting Manual; see Section S for air bag system precautions and J1 for audio anti-theft system precautions.

STEERING SYSTEM

INDEX	N - 2
OUTLINE	N - 3
SPECIFICATIONS	N - 3
ENGINE SPEED SENSING POWER	
STEERING	N - 3
PREPARATION	N - 3
TROUBLESHOOTING GUIDE	N - 5
AIR BLEEDING	N - 6
POWER STEERING FLUID	N - 6
BOOT	N - 9
STEERING WHEEL AND COLUMN	N -11
STEERING GEAR AND LINKAGE	N -16
POWER STEERING OIL PUMP	N -28
DRIVE BELT	N -31

37UONX-001

INDEX



37UCNX 002

1. Boot Replacement	page N- 9	4. Power steering oil pump Removal / Installation	page N-28
2. Steering wheel and column On-vehicle inspection	page N-11	Disassembly / Inspection / Assembly	page N-29
Removal / Inspection / Installation	page N-12	Air bleeding	page N- 6
Disassembly / Inspection / Assembly	page N-14	Power steering fluid	page N- 6
3. Steering gear and linkage Removal / Installation	page N-16	5. Drive belt Inspection	page N-31
Disassembly / Inspection	page N-18	Adjustment	page N-31
Assembly	page N-23	Replacement	page N-31
Air bleeding	page N- 6		