



## CONTENTS

1. ELECTRIC POWER STEERING FOR FB SERIES .....	1
1-1 WHAT IS EPS ? .....	1
1-2 FEATURES .....	1
1-3 ACTION OF EPS .....	1
1-4 FAIL-SAFE FUNCTION OF CONTROLLER .....	2
1-5 TRUCK EQUIPPED WITH EPS .....	2
2. EPS TROUBLE-SHOOTING .....	3
2-1 PRECAUTIONS ON TROUBLE-SHOOTING .....	3
2-2 TROUBLE-SHOOTING PROCEDURES .....	4
3. REPLACEMENT AND ADJUSTMENT OF PARTS .....	14
3-1 INTERCHANGEABILITY OF MAJOR PARTS .....	14
3-2 WEARING LIMIT OF EPS MOTOR BRUSHES .....	14
3-3 ADJUSTMENT ON REPLACEMENT OF TORQUE SENSOR .....	14
3-4 ADJUSTMENT ON REPLACEMENT OF ACTUATOR ASS'Y .....	16
4. WIRING AND COMPONENTS .....	17
• LOCATION OF COMPONENTS .....	17
• PICTORIAL WIRING .....	18
• WIRING DIAGRAM (EPS ONLY) .....	19
• WIRING DIAGRAM (CHASIS) .....	20
5. DISASSEMBLING ACTUATOR ASS'Y .....	21
5-1 DISASSEMBLING PROCEDURE AND CONSTRUCTIVE PARTS OF ACTUATOR ASS'Y .....	21
5-2 INSPECTION .....	24
5-3 ASSEMBLING .....	24