Volvo S80 Premier 2005 Wiring Diagram

Full download: http://manualplace.com/download/volvo-s80-premier-2005-wiring-diagram/



WIRING DIAGRAM S80 PREMIER



Vehicles with SRS (Airbag)/SIPS bag/ IC (Inflatable curtain)

Warning!

Extra caution must be exercised when working on vehicles equipped with SRS/SIPS bag/IC in order to avoid:

- 1. Personal injuries when performing repair work.
- 2. Damage or malfunction of the SRS/SIPS bag/IC system.

Work involving the SRS/SIPS bag/IC systems or other components in the vehicle that may affect the SRS/SIPS bag/IC systems must always be performed by an authorized Volvo workshop.

In case of doubt, consult the SRS and SIPS bag/IC service manual.

Is the vehicle equipped with SRS/SIPS bag/IC?

Vehicles with SRS are most easily recognised by the letters SRS in the centre of the steering wheel. If the vehicle also has a passenger side airbag, the letters SRS are stamped on the dashboard above the glove compartment. SRS vehicles from 1993 and onward also have explosive seat belt tensioners. SIPS bags are only installed on SRS vehicles from 1995 and onward. SIPS bag decals are located on the windscreen and seat compartment. Vehicles with IC can be recognised by the letters IC on the C/D panel (4 door) or the B panel (5 door).

General recommendations

- Be especially careful when working on or around SRS, SIPS, and IC components.
- Make sure that no wires are pinched, frayed, or pierced.
- Never fit accessories by the sensors.
- Where applicable, work on the steering wheel, steering shaft, or steering gear must be done
 in accordance with the methods in the SRS section of VADIS.
- Certain components of the aforementioned systems must be grounded while working. Read the appropriate sections in VADIS.
- Do not install any accessories in the areas between the A and B-pillars, the B and C-pillars, and the C and D-pillars.

Test terminal

Data link connector in the passenger compartment.

Changes introduced up to and including June 2004

Any changes made to the vehicles after this date are not included in the manual. If necessary refer to service bulletins.

Volvo models are sold in versions adapted for different markets. These adaptations depend on factors such as legal requirements, taxation, and market demands.

This manual may therefore include illustrations and text that do not apply to the vehicles in your country.

Volvo S80 Premier 2005 Wiring Diagram
Full download Contents .com/download/volvo-s80-premier-2005-wiring-diagram/

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)
Abbreviations 4
How to use the wiring diagram 1:2
Electrical distribution 1:2
Licettical distribution 1.2
Fuses
Fuses by the battery9
Fuses in auxiliary fuse box
ruses in auxiliary ruse box
Deleve
Relays
Relays in the cargo compartment 11
Ground connections
31/10 - 31/93
Group 36 Additional electrical equipment
12 V outlet
Group 39 Other, Accessories
Rear Seat Entertainment (RSE)
Electrically heated rear seat
· · · · · · · · · · · · · · · · · · ·
Group 87 Climate control system
Coolbox rear seat 16

Group 88 Internal equipment	
Switch, sun blind	17
Connectors	
54/33 - 54/64	18
54/73 - 54/272B	19
54/274	20
54/275 - 54/276	21
54/277 - 54/305	22
Junction points	
53/550 - 53/726	23
53/737 - 53/738	24
Cable harness routing in vehicle	
Rear Seat Entertainment (RSE) harness	25
Rear seat harness	
Component illustrations	
2/30 - 9/8	27
9/9 - 16/83	
16/122 - 31/93	
54/33 - 54/275B	

Index

List of components