
Full download: http://manualplace.com/download/white-fork-lift-ma60h-to-100-120-fork-lift-trucks-parts-catalog/

PARTS CATALOG

V S CENTURE

R-2222B



SERIAL NUMBERS
4700001-MA60H
37100001-MA70
37200001-MA80
37300001-MA90
37400001-MA100
47600001-MA120
5600101-MA60H-120
5650101-MA60HD-120D

5600450-5600496

Have Chrysler 776

See My 40-80R

Rack for eng

Parts

MA60H,70, 80, 90, 100, AND 120, 150-17° FORK LIFT TRUCKS



White Materials Handling

A SUBSIDIARY OF WHITE MOTOR CORPORATION HOPKINS, MINNESOTA 55343

(Charles)

Ref. No.	Part No.	DESCRIPTION	No. Pcs.
		QUICK REFERENCE CHART	
	35A5533 20-7300207 20-7300253 35P3109 35A8059 35A12878 20-7300314	OIL, FUEL AND AIR FILTERS Filter-sump,in transmission case	1 1 1 1 1 1 1
	20-7000680 20-7300343 20-7300344 20-7300345 35P1448	IGNITION SYSTEM Plug-spark, AC C-86 (8 per package) Plug-spark, Champion D-16 (10 per package) Cap-distributor Rotor-distributor Points-contact, distributor Condenser-distributor Key-ignition switch.	6 1 1 1 1
	10A12727 35A8786	THERMOSTAT AND BELTS Thermostat-engine temperature control,178° Belt-fan and alternator,49"O.C. for 5-9/16" fan pulley. Belt-fan and alternator,48"O.C.for 4-13/16" fan pulley. Belt-power steering pump,35-5/8" O.C.	1 1 1
	20-7300375 35R119 20-7300339 20-7300311	ENGINE GASKET SETS Kit-engine gaskets, TOP Kit-engine gaskets, BOTTOM Kit-engine gaskets, FRONT COVER Kit-carburetor repair (gasoline) Kit-carburetor repair (LP Gas) Kit-regulator repair (LP Gas)	1 1 1 1 1
	20-7380037 20-7380080 10R1193 20-7380071 20-7301946	TRANSMISSION, HYDRAULIC PUMP AND BRAKES Kit-gaskets transmission overhaul	1 1 1 1 1 1
•		STEERING AND TILT CYLINDER KIT Kit-repair, steering cylinder	
	20-7380118 20-7380117	HYDRALIZER KITS Kit-seals, hydralizer	2 2

LE

()

TABLE OF CONTENTS

Accelerator Pedal	Inching Linkage
AccumulatorD-18	Instruments
Air CleanersE-2	
Alternator	Levers, Transmission Control
Axle-Drive	Lights
	LP Gas EquipmentE-5,E-6
Battery and BoxF-4	
Brakes	Manifolds, EngineF-9
Breakaway Couplings, HydraulicD-18	Mast Control ValveD-12,D-13
Brake Controlled Inching CylinderA-24	Master Cylinder
Brake Linkage	Motor, Power SteeringB-11,B-13
Brake Pedal	MufflerF-9
brake redar	
Camshaft, EngineF-14	Neutral Start Switch
Carburetor, GasolineE-3,E-4	
Carburetor, LP GasE-6	Oil Filter, Engine, Diesel
Clutches, Transmission	Oil Filter, Engine, Gasoline & LPGF-15
	Oil Filter, Transmission
Coil, IgnitionF-5	Oil Pan, Engine, Gasoline & LPGF-10
Connecting Rods, EngineF-13	Oil Pump, Engine, Gasoline & LPGF-15
Controls, Transmission	
Control Valve, Aux. Hyd. Upright D-13, D-14	Paint
Control Valve, TransmissionA-17, A-18	Parking Brake
ConverterA-13	Pistons, Engine, Gasoline & LPGF-13
Counterweight	Pump, ConverterA-13
Cow1	Pump, Hydraulic SystemD-7 thru D-10
Crankcase, EngineF-10	Pump, Power Steering (Vickers)B-10
Crankshaft, EngineF-12	Precleaner for Air CleanerE-2
Cylinder Head, EngineF-11	riecleaner for All Oleaner
Cylinder, Power SteeringB-15	RadiatorF-6,F-7
Cylinder, TiltD-16	Regulator, LP GasE-6
	Rods, Connecting, EngineF-13
Deca1sG-2	Mode, connecting, bug inc
Differential	Seat
Dipstick, Engine, Gasoline & LPGF-10	Sediment Filter, DieselE-7
Dipstick, Hydraulic Tank	Spark Plugs, Engine
Dipstick, Transmission	Starting MotorF-2,F-3
Distributor, Ignition, Gas & LPGF-5	
Drive AxleA-10	Steering Linkage
Dual Fuel SystemE-8	Steer Pump, Diesel
·	
Engine Mounts	Tail Lamp
	Tappets, Engine, Gasoline & LPGF-14
Fan, Engine CoolingF-6,F-7	Tappets, Engine, Gasorine & Dr
Filler, Fuel TankE-3, E-7	Thermostat, Engine, Gasoline & LPGF-6 Tilt CylindersD-16
Flashing Light	Till Cylinders
Floor Plate	Tires, Drive Wheels
Flywheel, EngineF-12	Tires, Steer WheelsB-4
Frame	Transmission Case
Fuel Pump, DieselE-7	Transmission Clutches, Shafts A-14.thru A-16
Fuel Pump, GasolineE-3	Transmission Controls
Flywheel, HousingF-11	Transmission Oil
Gear Cover, Engine, Gas & LPGF-16	UprightsSee Upright Catalog
Governor, Engine, Gas & LPGF-17, F-18	Upright Control ValveD-12,D-13
GS and LPS Parts	Valves, Engine, Gasoline & LPGF-14
Hood and Side Panels	Valves, Upright ControlD-12,D-13
HornF-3	Water Pump, Gasoline & LPGF-8
Horn ButtonB-5	Water Pump, Diesel
HydralizersB-3,B-4	Wheels, Drive
Hydraulic Fluid	Wheels, Steer
Hydraulic Oil Lines, Fittings D-2 thru D-6	Wiring Harness
Hydraulic Pump	
	NUMERICAL INDEX

FOREWORD

This catalog contains a complete listing of parts for the lift truck. To assist in determining the part numbers and descriptions, the parts in this catalog are grouped according to their location on the lift truck. Reference numbers only are shown in each illustration. These numbers correspond to those in the reference number column in the list of parts which follows each "exploded view".

TYPICAL PARTS ARE SHOWN, AND MAY NOT ALWAYS BE IDENTICAL WITH CURRENT PARTS. REFER TO THE TEXT. "RIGHT OR LEFT" IS DETERMINED BY FACING TOWARD THE UPRIGHT FROM THE LIFT TRUCK SEAT.

To further assist in locating repair parts, the part numbers are arranged in numerical sequence and indexed at the rear of this catalog.

Component parts of assemblies are listed following the assembly itself and are identified as being part of the assembly by this notation following the description:

Consists of the following ... parts or Includes the following ... parts:

Part numbers only make up an assembly. Hardware items are not to be included.

Parts such as standard bolts, nuts, screws, washers, etc., are indented and listed under the respective individual parts with which they are used. The quantity for many of the shims listed is shown as A.R. (as required). The correct amount of shims should be determined in order to get the proper clearance.

Occasionally new part numbers replace old numbers in the Part No. column. In those cases where the new number substitutes for the old number, the old number will be enclosed in parenthesis and it will appear at the end of the text in description column.

Parts for the Perkins 4.236 diesel engine are to be ordered from your local Perkins Dealer. Give him the Serial Number of engine when ordering parts.

Repair Parts for Continental Engine Spec. F227-8101, F227-8522, F245-8133, F245-8512, are included.

When in need of repair parts, order from your local dealer. All parts orders should plainly specify your name, post office address, and whether shipment is to go by parcel post, express, or freight. Claims of shortage or breakage should be made to the transportation company on receipt of goods.

Before returning repair parts to the factory or parts depot, it is necessary to secure written permission from the Company authorizing the return of such parts. In the returning of repair parts be sure the package is tagged with your name and address. Prepay transportation charges.


It is the policy of the Company to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements in the design or construction of parts at any time without incurring the obligation to install such changes on products previously delivered.

GROUPS

- A thru
- B-2 Drive Wheels, Differential, Transmission and Brakes
- B-3 Steering, Hydralizer and Steer Wheels
- C Frame, Driver Compartment and Wiring Harness
- D Hydraulics
- E Carburetion and LP-Gas Systems
- F Engine and Accessories
- G Decals, Paint, Engine Oil, Hydraulic Oil and Index


Ref. No.	Part No.	DESCRIPTION						
		PERKINS DIESEL ENGINE PARTS						
	31-2753727 20-7301482 20-7301483 20-3005083 20-7301487 20-7301488 20-7301489	Element - fuel filters, on R.H Fuel Pump - engine, with prime Gasket - fuel pump Thermostat - engine, 1800 Gasket-thermostat housing Fan Belt - fan and alternator Water Pump - assembly Kit - repair, water pump Gasket - water pump Bracket - dipstick, engine oil 50A4310 Clip - dipstick tub	. side of engine					
		50A1921 Bolt - hex, 5/16"-1 50A3730 Nut - hex, 5/16"-18 Kits-Perkins Diesel, order fro		. 1				
		GASKET KITS FOR L	IFT TRUCK					
	20-7380037	Kit - gasket, transmission & d Consists of the following:	ifferential overhaul	. 1				
	20-7380080	1-35A227 Gasket	1-35A379 Gasket 1-35A10654 Gasket 1-35A10658 Gasket 2-20-3005610 Gasket (MY 1-35P613 Seal 2-20-3000701 Ring 2-20-3004833 Gasket 1-20-3009076 Ring 1-20-3009388 Retainer 1-50A6326 "O" Ring 1-50A6327 "O" Ring 1-50A768 Ring 3-50A1749 Stat-0-Sea	1				

Ref. No.	Part No. DESCRIPTION					
		GASKET KITS FOR LIFT TRUCK (CONT'D)				
	20-7300376	Kit-engine gaskets, TOP (F227 & F245 Cont.)	1			
	20-7300375	Kit-engine gaskets, BOTTOM (F227 & F245 Cont.) Consists of the following:	1			
		2-15P49 Gasket 1-35P2150 Gasket 2-15P510A Seal 1-9158S Gasket 2-35P789 Seal				
	35R119	Kit-engine gaskets, TIMING GEAR COVER(F227&F245 Cont.) Consists of the following:	1			
		1-15P562 Seal 3-15P97 Gasket 1-35P785 Gasket 1-9240S Gasket 1-15P458 Gasket 1-15P173 Gasket				
	20-7300027	Kit-water pump repair (F227 & F245 Cont.)	. 1			
		1-35P2236 Shaft 1-35P855 Gasket 2-35P1962 Ring 1-15P173 Gasket 1-35P1960 Impeller 1-9240S Gasket 1-35P1961 Seal	Ž.			
	20-7300339 20-7300311 35P3009 35P338 35P1046 10R1193 20-7301946 20-7301943 10P3995 20-7300283 20-7301984 20-7302024	Kit-regulator repair (LP gas)	1 1 2 1 1 1 1 1 1 AR			
	- 14 A					
	* · ·					
·						



Ref.	Part No.	DESCRIPTION DESCRIPTION	No.	Ref.	Part No.	DESCRIPTION	No.
No.	Part No.	DESCRIPTION	Pcs.	No.	Tait No.	DESCRITION	Pcs.
	20-6008151	Wheel-drive, w/tires,			20-3008166	+Tire-dr.whl.,22x12x16	2
		std.,MA60H-80	2		Note (+)	Used w/single dr.tires.	
		Inc. Ref.#1 and tire:		2	35A12985	*Hub-dr.whl.for 1/2 stud	2
1	35A12882	Wheel-drive	2	3	50A5959	*Stud-whl.clmp.1/2x2-3/4	16
	20-3008151	Tire-dr.whl.22x5x16	4		50A5572	1 2.00	16
	20-6008154	Wheel-drive, w/tires,		2	20-3006396	#Hub-dr.whl.for 5/8 stud	2
	gi.	std.,MA90-100	2	3	20-3002919		16
		Inc.Ref.#1 and tire:	2		50A4985	#Nut-hex,5/8-18,Gr.8	16
1	35A12881	Wheel-drive	2	4	981044	Cup-brg.hub,innr(50A5752)	
	20-3008154	Tire-dr.whel,22x6x16	- 4	5	981043	Cone-brg.hb.innr(50A5751)	2
	20-6008157	Wheel-drive, w/tires,		6	50A5758	Cup-bearing, hub, outer	2
		std.,MA120	2	7	50A5757	Cone-bearing, hub, outer	2
	,	Inc.Ref.#1 and tire:		8	35A12890	Seal-oil, wheel hub	2
1	20-3002590	Wheel-drive	2		20-7301879	Adapter-seal tool(special	
	20-3008157	Tire-dr.whl.,22x7x16	4		20-7301880	Handle-seal tool(special)	
	20-6008163	+Wheel-drive,w/tire,10		9	35A12987	*Clamp-wheel, for 1/2 stud	
		wide,optional,MA60H-80	2	9	20-3006393	#Clamp-wheel, for 5/8 stud	
		Inc.Ref.#1 and tire:		1	Note (*)	Used with 1/2 wheel stud.	1
1	35A12882	+Wheel-drive	2		Note (#)	Used with 5/8 wheel stud.	
9	20-3008163	+Tire-dr.whl.,22x10x16	2	10	20-3003066	Key-wheel to hub,1-13/16I	2
	20-6008166	+Wheel-drive,w/tire,12			Note:	When replacing 35A12985	
:+		wide,optional,MA90-100	2		1	hub, #2, order parts w/(#).	• "
1	35A12881	+Wheel-drive	2				
				1			1

Full download: http://manualplace.com/download/white-fork-lift-ma60h-to-100-120-fork-lift-trucks-parts-catalog/



DIFFERENTIAL CAGE

Ref. No.	Part No.	DESCRIPTION	No. Pcs.	Ref. No.	Part No.	DESCRIPTION	•
	20-3003489	Cage-differential,R.H. Cage-differential,L.H. Gear-ring,42T.,4.666:1 Gear-ring,41T.,5.125:1 Bolt-gr.,GR.8,½-20x5-3/4 Nut-self lock,1/2-20 Gear-bevel, 26T.	1 1 1 1 8 8 2	6 7 8 9 10 11 12	30A1710 10A405 20-3010042 10A5560 20-3010041 KA5012A KB5012A	Ring-axle stop, gear bore Washer-thrust bvl.gr. Pinion-bevel,14T(11A5559) Bushing-bvl.gr.for11A5559 Shaft-bvl.pinion(10A1504) Cone-brg.cage(10A6712Int) Cup-brg.cage,in axle hsg. (10A1697 Inter.)	2
					•		