ENAMAK



PARTS CATALOGUE

XJR1300 XJR1300P

(5EAT/5EAW) EUROPE

(5EAV/5EAY) AUSTRALIA



2A5EA-300E2

Full download: http://manualplace.com/download/yamaha-xj1300-parts-catalogue/

Yamaha Xj1300 Parts Catalogue

XJR1300/XJR1300P
PARTS CATALOGUE
©2001 by Yamaha Motor Co., Ltd.
1st Edition, December 2001
All rights reserved.
Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd. is expressly prohibited.



FOREWORD

This Parts Catalogue is related to the parts for the model(s) in the below frame. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

XJR1300/XJR1300P(5EAT,5EAW/5EAV,5EAY)

 Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.

It is advisable that you make necessary corrections to the Parts Catalogue according to the Yamaha Parts News.

2. Abbreviations

The Following abbreviations are used in this Parts Catalogue.

"UR" Use specified parts number.

"UN" Use as many as needed.

"AP" Alternate Parts

"LM" Local Made (Parts need to be ordered locally)

"F#" Frame No. (Applicable machine No.)

3. Parts, which are to be supplied in an assembly, are listed with a dot(.) in front of the part name as shown below.

EXAMPLE

CARBURETOR ASSY

JET, PILOT

.NOZZLE, MAIN

4. Number of component for assembly

The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

EXAMPLE

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	
1M1-83309-60	.REFLECTOR	1	


Applicable colors of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-	X5 .FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	for MXR

6. Applicable Serial No.

Engine Serial No.

Frame Serial No.






- 7. Note that the illustrations for reference in funding parts numbers, not to be used for assembling. When assembling, pleas use the applicable service manual.
- 8. The asterisk (*) before a reference number indicates modification items after the first edition.

MODEL LABEL


- (1) A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross–refer the "model code production code No." in the catalogue to the "model code production code No. "indicated on the Model Label affixed onto the product concemed.
- (2) "Model Label"Indication




a: Model Type Code

b: Production Code No.

c: Colouring Type



(3) Model Label Affixing Location



(4) Model Code – Production Code Number of Model Listed in This Parts Catalog

Model Code	Production Code No.	Country (destination)	Model Code	Production Code No.	Country (destination)
	020	BELGIUM	5EAV	010	AUSTRALIA
	021	BELGIUM	5EAY	010	AUSTRALIA
	030	DENMARK			
	030	NORWAY			
	040	SPAIN			
	041	SPAIN			
	050	ENGLAND			
5EAT	051	ENGLAND			
5EAW	060	GREECE			
	070	ITALY			
	071	ITALY			
	080	HOLLAND			
	081	HOLLAND			
	090	PORTUGAL			
	100	SWEDEN			
	110	S.AFRICA			

(5) Colouring Information

Model Code	Colouring type code	Colour code	Colour Name	Abbrevi- ation
5EAT	А	004B	BLACK 2	BL2
5EAV	В	0564	DEEP PURPLISH BLUE METALLIC C	DPBMC
5EAW	А	0820	BLUISH SILVER 4	BS4
5EAY	A	0020	DEGISTI SIEVEIX 4	D34






FIG. 1 CYLINDER HEAD

FIG.	1 CYLINDER	RHEAD					
REF. NO.	PART NO.	DESCRIPTION	5EAT	5EAW	5EAV	5EAY	REMARKS
1 5E	A-11101-10	CYLINDER HEAD ASSY	1		1		
5E.	A-11101-20	CYLINDER HEAD ASSY		1		1	
2 918	808–16023	.PIN, DOWEL	16	16	16	16	
3 90	105–06305	.BOLT, FLANGE	18	18	18	18	
4 90	153–06029	.SCREW, HEXAGON	1	1	1	1	
5 904	430–06014	.GASKET	1	1	1	1	
6 36	Y-11133-10	.GUIDE, INTAKE VALVE	16	16	16	16	
7 36	Y-12193-10	.CAP, CAMSHAFT 3	1	1	1	1	
8 36	Y-12178-10	.CAP, CAMSHAFT 4	1	1	1	1	
9 956	617–06625	BOLT, STUD	2	2	2	2	
10 956	617–06635	BOLT, STUD	2	2	2	2	
11 956	617–08625	BOLT, STUD	8	8	8	8	
12 5E	A-11161-00	ABSORBER 1	2	2			
13 902	201–102G9	WASHER, PLATE	10	10	10	10	
14 902	201–10128	WASHER, PLATE	2	2	2	2	
15 90	176–10078	NUT, CROWN	12	12	12	12	
16 947	701–00241	PLUG, SPARK (NGK DPR8EA-9)	4	4	4	4	
17 5E	A-11181-10	GASKET, CYLINDER HEAD 1	1	1	1	1	
18 4K	G-11191-10	COVER, CYLINDER HEAD 1	1	1	1	1	
19 5E	A-11193-00	GASKET, HEAD COVER 1	1	1	1	1	
20 90	109–066F0	BOLT	- 8	8	8		
21 5E	A-1111G-00	RUBBER, MOUNT 1	8	8	8	8	
					-		

5EA1010-8020

PART NO.	DESCRIPTION	F < 1	D L A	5EAW	5EAV	5EAY		REMARKS
5EA-11311-00	CYLINDER 1	I	1		1			
5EA-11311-10	CYLINDER 1			1		1		
99530–14016	PIN, DOWEL		4	4	4	4		
90430-14240	GASKET		2	2	2	2		
5EA-11351-00	GASKET, CYLINDER		1	1	1	1		
95627–08330	BOLT, STUD		1	1	1	 1		
90201-08382	WASHER, PLATE		1	1	1	1		
92907-06600	WASHER, PLATE		4	4	4	4		
95317-08600	NUT		1	1	1	1		
95317-06600	NUT		4	4	4	4		
			_	-	. <u>-</u>			
				_				
				-				