

Zf 1367 758 101a En 16 Speed Operating Instruction

Full download: <http://manualplace.com/download/zf-1367-758-101a-en-16-speed-operating-instruction/>

Betriebsanleitung

Operating Instructions

Manuel d'Utilisation

Manual de Servicio

Istruzioni per l'Uso



ZF Synchromesh Transmission
16-Speed

1367 758 101a_en

Subject to technical changes

Copyright by ZF

This documentation is protected by copyright. Any reproduction or dissemination in whatever form which does not comply fully with the intended purpose of this documentation is prohibited without the consent of ZF Friedrichshafen AG.

Printed in Germany

ZF Friedrichshafen AG, MC-C / 2009

Edition: 2010-06

Your vehicle is equipped with a 16-speed synchromesh transmission of the **ZF-Ecosplit model range**.

The more familiar you are with ZF transmissions, the more economically you will be able to operate them. In these operating instructions, you will learn how to derive maximum benefit from the technical advantages of the ZF transmission.

Therefore, we kindly ask the driver to carefully read these operating instructions and the special information provided by the vehicle manufacturer before driving the vehicle for the first time.

In order to ensure reliability of service, please note the specifications governing maintenance. The ZF Customer Service specialists are available to assist you in carrying out maintenance work or to help if any other problems arise.

Motoring pleasure with ZF transmissions is brought to you by

ZF Friedrichshafen AG

Truck Driveline Technology business unit (SL)
D-88038 Friedrichshafen

Phone +49 (0) 75 41 77 0

Fax: +49 (0) 75 41 77-908 000

Internet www.zf.com