



# Installation Manual

Installation Manual for  
ZF-AS Tronic + Intarder +  
System Components For Installation  
and PDI (Delivery Check)

1327 754 106

Subject to technical changes

Copyright by ZF

The present documentation is protected by copyright. Any kind of reproduction or dissemination in whatever form that does not exclusively correspond to documentation objectives will be prosecuted if no prior approval by ZF Friedrichshafen AG was granted.

Printed in Germany

ZF Friedrichshafen AG, MC-C / 2004-08

Edition: 2004-08

**1327 754 106**

	Page
Preface .....	5
Safety notice .....	6
General information .....	6
Instructions for repairs .....	7
List of changes 1327 754 106 .....	9
Preparations .....	11
Preparing for ZF-AS Tronic Installation .....	11
Checks Before Installation .....	13
Preparations for Clutch Installation .....	14
Clutch Installation .....	17
Transmission Installation .....	20
Lifting and Transporting .....	20
Fitting Clutch Actuator.....	25
Venting Clutch Actuator.....	25
Connections to the Vehicle .....	28
Oil Level Check .....	30
Oil level check for transmission versions without an Intarder .....	30
Oil Level Check and Oil Filling for Transmission Versions with an Intarder.....	31
OEM Delivery Check.....	33
OEM Delivery Check for ZF-ASTronic Transmissions in the NAFTA Market.....	35