

PARTS MANUAL

**H16XM-12EC, H18XM-12EC,
H22XM-12EC
(C214)**

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME
2	ENGINE ASSEMBLY
3	FUEL SYSTEM
4	ELECTRICAL SYSTEM
5	TRANSMISSION
6	DRIVE AXLE
7	STEERING SYSTEM
8	BRAKE SYSTEM
9	HYDRAULIC SYSTEM
10	MAST WITH EMPTY CONTAINER HANDLER
11	OPTIONS
12	FIELD CONVERSION KITS
13	NUMERICAL INDEX

This Parts Manual is divided into 13 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

TABLE OF CONTENTS

DESCRIPTION	PAGE
A	
AIR CONDITIONER AND CONTROL PANEL ASSEMBLIES	1-72
AIR CONDITIONER ASSEMBLY	
→ 12/2012	1-74
12/2012 →	1-76
CLIMATE CONTROL CAB	1-124
AIR CONDITIONER FILTER AND COVER ASSEMBLY	1-88
AIR CONDITIONER SYSTEM	
CLIMATE CONTROL CAB	1-122
AIR CONDITIONING SYSTEM	1-66
AIR DUCT ASSEMBLY	
AIR CONDITIONING	1-70
HEATER	1-82
LOUVER, CLIMATE CONTROL CAB	1-120
AIR HEATER STARTING AID	
TIER III ENGINE	2-5
AIR HORN	1-54
AIR INTAKE CONNECTION	
STAGE 3B ENGINE	2-82
TIER III ENGINE	2-6
AIR INTAKE HOSE	
TIER III ENGINE	2-7
AIR INTAKE MANIFOLD	
STAGE 3B ENGINE	2-84
TIER III ENGINE	2-8
AIR INTAKE SYSTEM	
STAGE 3B ENGINE	3-10
TIER III ENGINE	3-8
AIR TRANSFER CONNECTION	
STAGE 3B ENGINE	2-85
TIER III ENGINE	2-9
ALTERNATOR AND MOUNTING	
STAGE 3B ENGINE	4-182
TIER III ENGINE	4-11
ALTERNATOR SUPPORT AND WATER INLET	
TIER III ENGINE	4-12
ARMREST ASSEMBLY	
HYDRAULIC LEVERS	1-110
JOYSTICK	1-108
AUTOMATIC GREASING PUMP	
→ PENDING PER ECN 68570-86	9-54
PENDING PER ECN 68570-86 →	9-56
AUTOMATIC GREASING SYSTEM	
PAGE 1 OF 3	9-58
PAGE 2 OF 3	9-60
PAGE 3 OF 3	9-62
AUTOMATIC GREASING SYSTEM HOSE SUPPORT	
S/N C214E01695K →	9-68

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
B	
BELT TENSIONER	
STAGE 3B ENGINE	2-86
TIER III ENGINE	2-10
BLOCK ASSEMBLY, TWIN 12-PORT	
WITH METERING UNITS NUMBER 3, 4, AND 8	9-66
BLOCK ASSEMBLY, TWIN 4-PORT	
WITH METERING UNIT NUMBER 8	9-65
WITH METERING UNITS NUMBER 3 AND 10	9-64
BRAKE HOSES AND ATTACHING PARTS	
PAGE 1 OF 2	8-2
PAGE 2 OF 2	8-6
BRAKE PEDAL AND LINKAGE	8-8
BRAKE PEDAL ASSEMBLY	8-12
BRAKE VALVE AND ATTACHING PARTS	8-10
BREATHER PLUMBING	
STAGE 3B ENGINE	2-87
C	
CAB	
ATTACHING PARTS	1-18
PAGE 1 OF 2	1-4
PAGE 2 OF 2	1-6
TILT AND LATCH ASSEMBLY	1-34
TILT CYLINDER	1-42
TILT ELECTRIC PUMP	1-38
TILT HAND PUMP	1-40
CAB DOOR	
LEFT HAND	1-44
RIGHT HAND	1-46
CAB FLOORMATS	1-32
CAB HEATER PLUMBING	
TIER III ENGINE	2-11
CAB HOSES AND ATTACHING PARTS	9-6
CAB MAIN DOOR WINDOW	
RIGHT AND LEFT HAND	1-48
CAB RECIRCULATING FAN	
CLOSED CAB ONLY	11-7
CAB SUNSHADE - REAR	
CAB WITH AIRCO - OPTIONAL FOR CAB WITHOUT AIRCO	1-30
CAB SUNSHADE - TOP	
CAB WITH AIRCO - OPTIONAL FOR CAB WITHOUT AIRCO	1-28
CAB TILT PUMP ASSEMBLY	1-36
CAB WINDOWS INSTALLATION	1-26
CAMSHAFT	
TIER III ENGINE	2-12
CAPSULE ASSEMBLY	
RAISE AND LOWER - JOYSTICK AND LEVERS	9-48
TILT - JOYSTICK AND LEVERS	9-50

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
CASE AND REAR COVER	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-44
S/N C214E01687K → (TE-17) PENDING PER ECN 68653 → (TE-13)	5-46
CHARGING PUMP	5-22
CLIMATE CONTROL SYSTEM	1-114
COMBINATION VALVE	9-20
COMPRESSOR ASSEMBLY	1-64
CONDENSER ASSEMBLY	1-68
CONDITIONAL SPEED LIMITER	
LIFT AND TILT	11-10
CONNECTING RODS AND PISTONS	
TIER III ENGINE	2-14
CONTROL PANEL ASSEMBLY	
AIR CONDITIONER (→ 12/2012)	1-78
AIR CONDITIONER (12/2012 →)	1-79
HEATER	1-85
CONTROL VALVE	9-22
AUXILIARY SPOOL SECTION	9-32
LIFT SPOOL SECTION - 1A AND 1B	9-28
LIFT SPOOL SECTION - 4A AND 4B	9-30
MID-INLET SECTION	9-24
OUTLET SECTION	9-25
TILT SPOOL SECTION	9-26
CONTROL VALVE ASSEMBLY	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-31
S/N C214E01687K ↔ PENDING PER ECN 68653	5-32
PENDING PER ECN 68653 →	5-33
CONTROL VALVE ATTACHING PARTS	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-26
S/N C214E01687K ↔ PENDING PER ECN 68653	5-28
PENDING PER ECN 68653 →	5-30
CONVERTER HOUSING	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-4
PENDING PER ECN 68653 → (TE-13) S/N C214E01687K → (TE-17)	5-6
COOLANT HEATER STARTING AID	
TIER III ENGINE	2-16
COOLING SYSTEM	
STAGE 3B ENGINE	2-22
STAGE 3B ENGINE - ALTERNATE CONFIGURATION	2-26
TIER III ENGINE	2-18
TIER III ENGINE - ALTERNATE CONFIGURATION	2-20
COUNTERWEIGHT	1-15
CRANKCASE BREATHER	
STAGE 3B ENGINE	2-88
TIER III ENGINE	2-29
CRANKSHAFT AND BEARINGS	
TIER III ENGINE	2-30
CYLINDER BLOCK	
TIER III ENGINE	2-32

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
CYLINDER HEAD TIER III ENGINE	2-34
D	
DASH ASSEMBLY	1-20
DC-DC CONVERTER AND ATTACHING PARTS	4-21
DIESEL PARTICULATE FILTER AFTERTREATMENT MODULE DEVICE - STAGE 3B ENGINE	4-190
DIFFERENTIAL CARRIER	6-6
DIPSTICK AND TUBE STAGE 3B ENGINE	2-90
DRIVE AXLE ASSEMBLY	6-2
DRIVE PLATES	5-9
DRIVE TIRE AND WHEEL MICHELIN	6-16
TRELLEBORG - SOLID TIRE	6-18
TRELLEBORG	6-19
TRELLEBORG TR900	6-21
E	
ECM MODULE WIRING STAGE 3B ENGINE	4-186
ELECTRICAL SYSTEM STAGE 3B ENGINE	4-8
TIER III ENGINE	4-4
EMPTY CONTAINER HANDLER BEARING BLOCKS AND SHIMS - CARRIAGE	11-14
EMPTY SEAT ENGINE SHUTDOWN	11-5
ENGINE BLOCK HEATER	11-8
ENGINE CONTROL MODULE STAGE 3B ENGINE	4-184
TIER III ENGINE	4-14
ENGINE COOLANT VENT STAGE 3B ENGINE	2-93
TIER III ENGINE	2-36
ENGINE MOUNTS TIER III AND STAGE 3B ENGINE	2-40
ENGINE OIL COOLER STAGE 3B ENGINE	2-91
TIER III ENGINE	2-38
ETR MODULE WIRING TIER III ENGINE	4-16
EXHAUST SYSTEM STAGE 3B ENGINE	2-44
EXHAUST MANIFOLD RECIRCULATION AIR - STAGE 3B ENGINE	2-95
RECIRCULATION WATER - STAGE 3B ENGINE	2-96
TIER III ENGINE	2-41

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
EXHAUST MANIFOLD AND MOUNTING	
STAGE 3B ENGINE	2-94
EXHAUST OUTLET ELBOW	
STAGE 3B ENGINE	2-126
EXHAUST SYSTEM	
TIER III ENGINE	2-42
F	
FAN DRIVE	
STAGE 3B ENGINE	2-98
FAN DRIVE AND MOUNTING	
TIER III ENGINE	2-46
FAN DRIVE MOUNTING	
STAGE 3B ENGINE	2-99
FAN SPACER	
TIER III ENGINE	2-47
FLUID INDICATOR AND ATTACHING PARTS	
STAGE 3B ENGINE	5-49
TIER III ENGINE	5-48
FLYWHEEL	
STAGE 3B ENGINE	2-102
FLYWHEEL AND MOUNTING	
TIER III ENGINE	2-48
FLYWHEEL HOUSING	
STAGE 3B ENGINE	2-100
TIER III ENGINE	2-50
FLYWHEEL MOUNTING	
STAGE 3B ENGINE	2-103
FORWARD AND THIRD SHAFT	5-18
FRONT FENDER LIGHTS	4-188
FRONT GEAR COVER	
STAGE 3B ENGINE	2-104
TIER III ENGINE	2-52
FUEL DRAIN PLUMBING	
STAGE 3B ENGINE	3-28
FUEL FILTER	
STAGE 3B ENGINE (→ PENDING PER ECN 68614-51)	3-34
STAGE 3B ENGINE (PENDING PER ECN 68614-51 →)	3-36
SYSTEM ACCESSORIES - STAGE 3B ENGINE	3-25
TIER III ENGINE	3-11
FUEL FILTER MOUNTING	
STAGE 3B ENGINE	3-24
FUEL FILTER PLUMBING	
STAGE 3B ENGINE	3-26
TIER III ENGINE	3-12
FUEL INJECTION PUMP	
TIER III ENGINE	3-13
FUEL INJECTOR PLUMBING	
TIER III ENGINE	3-14

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
FUEL INJECTORS	
TIER III ENGINE	3-16
FUEL INLET FITTING	
STAGE 3B ENGINE	3-37
TIER III ENGINE	3-17
FUEL PLUMBING	
TIER III ENGINE	3-18
FUEL PUMP	
STAGE 3B ENGINE	3-32
FUEL SUPPLY PLUMBING	
STAGE 3B ENGINE	3-27
FUEL SYSTEM ACCESSORIES	
TIER III ENGINE	3-20
FUEL TANK	
STAGE 3B ENGINE	3-30
TIER III ENGINE	3-22
FULL FLOW VALVE ASSEMBLY	
PENDING PER ECN 68653 →	5-42
G	
GEARS	5-14
H	
HANDRAILS AND FENDERS	1-8
HEADER HOSES	10-14
HEAT SHIELD	
STAGE 3B ENGINE	2-105
HEATED TOP WINDOW	
CLIMATE CONTROL CAB	1-116
HEATER AND AIR CONDITIONER HOSES	
STAGE 3B ENGINE	1-60
STAGE 3B ENGINE - ALTERNATE CONFIGURATION	1-62
TIER III ENGINE	1-58
HEATER AND AIR DUCT	1-80
HEATER AND CONTROL PANEL ASSEMBLIES	1-84
HEATER ASSEMBLY	1-86
HOODS AND COVERS	1-12
HYDRAULIC HOSE ASSEMBLY	
JOYSTICK	9-46
LEVERS	9-36
HYDRAULIC LEVERS	9-34
HYDRAULIC OIL COOLER	9-8
HYDRAULIC SUPPLY AND RETURN	9-2
HYDRAULIC TANK AND ATTACHING PARTS	9-10
HYDRAULIC VALVES AND ATTACHING PARTS	9-16
I	
INDICATOR DISPLAY AND CONTROLS	4-34
INNER MAST	10-6
INPUT SHAFT AND FIRST CLUTCH	5-12

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
INSULATION MATS AND AIR DUCT CLOSED	1-118
J	
JOINT MECHANISM ASSEMBLY	
JOYSTICK	9-40
LEVERS	9-39
JOYSTICK ASSEMBLY	9-44
JOYSTICK CONTROL	9-42
JUMP START AID	11-4
L	
LABELS	
EXTERIOR	1-130
HYDRAULIC CONTROLS	1-126
INTERIOR	1-128
LIFT ACCUMULATOR SYSTEM	9-12
LIFTING BRACKETS	
STAGE 3B ENGINE	2-106
LIFTING BRACKETS AND MOUNTING	
TIER III ENGINE	2-53
LIFTING EYES	
STAGE 3B ENGINE	2-107
LIGHT BAR AND MOUNT	
TWISTLOCK MODULE	4-24
LIGHTS	
DIRECTIONAL AND MARKER	4-28
REAR AND BACKUP ALARM	4-26
WORK - HALOGEN	4-29
WORK - HID	4-30
LOCKOUT LEVER	4-17
LOUVER - HEAVY DUTY AIRCO	12-2
LUBRICATING OIL PUMP	
STAGE 3B ENGINE	2-108
TIER III ENGINE	2-54
M	
MAIN LIFT	10-8
MAIN LIFT CYLINDERS	10-12
MAIN VALVE HOSES	9-14
MAP READING LIGHT	11-3
MAST INSTALLATION	10-2
MAST SUPPLY AND RETURN	9-4
MIRRORS	11-13
MODULATOR VALVE ASSEMBLY	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-38
S/N C214E01687K ↔ PENDING PER ECN 68653	5-40
MONOTROL PEDAL ASSEMBLY	3-4
MONOTROL PEDAL LINKAGE	3-2
MUDFLAPS	1-56

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
O	
OIL FILLER	
TIER III ENGINE	2-55
OIL FILTER	
STAGE 3B ENGINE	2-109
OIL LEVEL GAUGE	
TIER III ENGINE	2-56
OIL PAN	
STAGE 3B ENGINE (→ PENDING PER ECN 68614-51)	2-110
STAGE 3B ENGINE (PENDING PER ECN 68614-51 →)	2-112
TIER III ENGINE	2-58
OPTIONAL MOUNTING EQUIPMENT (HANDLE)	11-2
OUTER MAST	10-4
OUTPUT SHAFT	
→ S/N C214E01686K (TE-17) → PENDING PER ECN 68653 (TE-13)	5-24
S/N C214E01687K → (TE-17) PENDING PER ECN 68653 → (TE-13)	5-25
OVERHEAD GUARD	
WIRE MESH	1-16
P	
PARK BRAKE ASSEMBLY	6-10
PARK BRAKE KITS	12-2
PILOT SUPPLY VALVE ASSEMBLY	
JOYSTICK	9-38
LEVERS	9-37
PIVOT ARM ASSEMBLY	1-112
PROXIMITY SWITCH ASSEMBLY	4-33
PUMP DRIVE	5-20
R	
RADIATOR AND COOLER ASSEMBLY	
STAGE 3B ENGINE	2-62
TIER III ENGINE	2-60
RADIO CONSOLE	1-50
RADIO SPEAKERS	1-52
REAR GEAR HOUSING	
STAGE 3B ENGINE	2-113
TIER III ENGINE	2-64
REAR GEAR TRAIN ACCESSORY MOUNTING COVER	
STAGE 3B ENGINE	2-114
TIER III ENGINE	2-65
REAR VIEW MIRRORS	1-57
REGULATOR VALVE ASSEMBLY	
→ PENDING PER ECN 68653	5-34
PENDING PER ECN 68653 →	5-36
RELAYS AND FUSES	
OPERATOR COMPARTMENT - TIER III ENGINE (→ PENDING PER ECN 68653)	4-56
OPERATOR COMPARTMENT - TIER III ENGINE (PENDING PER ECN 68653 →)	4-70
OPERATOR COMPARTMENT - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-84

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
OPERATOR COMPARTMENT - STAGE 3B ENGINE (PENDING PER ECN 68653 →)	4-98
REMOTE OIL FILTER	
TIER III ENGINE	2-66
REVERSE AND SECOND CLUTCH	5-16
ROCKER LEVERS	
TIER III ENGINE	2-68
S	
SEAT ASSEMBLY	
AIR SUSPENSION	1-94
CLIMATE CONTROL CAB	1-106
DELUXE SUSPENSION	1-104
MECHANICAL AND AIR SUSPENSION	1-101
MECHANICAL SUSPENSION	1-98
SUSPENSION	1-90
SECOND 12V SOCKET OPTION	
CLIMATE CONTROL CAB	4-22
SOLENOID VALVE	
STAGE 3B ENGINE	9-52
STARTER MOTOR AND MOUNTING	
STAGE 3B ENGINE	2-115
TIER III ENGINE	2-70
STEER AXLE ASSEMBLY	7-2
STEER COLUMN	7-20
STEER COLUMN AND ATTACHING PARTS	7-16
STEER COLUMN ASSEMBLY	7-18
STEER CYLINDER	7-6
STEER PUMP ASSEMBLY	7-8
STEER TIRE AND WHEEL	
MICHELIN	7-12
TRELLEBORG - SOLID TIRE	7-13
TRELLEBORG	7-14
TRELLEBORG TR900	7-15
STEERING CONTROL UNIT ASSEMBLY	7-22
STEERING HOSES AND ATTACHING PARTS	7-10
STROBE LIGHT	4-31
STUD GROUNDING	
STAGE 3B ENGINE	2-116
SWITCHES	4-32
T	
TELEMETRY KITS	12-2
THERMOSTAT	
STAGE 3B ENGINE	2-117
TIER III ENGINE	2-71
THREE-POINT SEAT BELT	11-12
THROTTLE PEDAL LINKAGE	3-6
TILT CYLINDER HYDRAULICS	10-18
TILT CYLINDERS	10-20

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
TORQUE CONVERTER	5-8
TORQUE CONVERTER COOLER PLUGS	
TIER III ENGINE	2-72
TRAINING SEAT	11-6
TRANSMISSION CONTROLLER AND SHIFT LEVER	4-18
TRANSMISSION HOSES AND ATTACHING PARTS	5-10
TRANSMISSION MOUNTING	5-2
TURBOCHARGER	
STAGE 3B ENGINE	2-127
TIER III ENGINE	2-73
TURBOCHARGER PLUMBING	
STAGE 3B ENGINE	2-128
TIER III ENGINE	2-74
U	
UNIVERSAL SHAFT	5-50
V	
VALVE COVER	
STAGE 3B ENGINE	2-120
TIER III ENGINE	2-76
VALVE TAPPETS	
TIER III ENGINE	2-77
V-BELT	
STAGE 3B ENGINE	2-118
VIBRATION DAMPER	
STAGE 3B ENGINE	2-125
TIER III ENGINE	2-78
W	
WATER INTAKE CONNECTION	
STAGE 3B ENGINE	2-122
WATER OUTLET CONNECTION	
STAGE 3B ENGINE	2-123
TIER III ENGINE	2-81
WATER PUMP	
STAGE 3B ENGINE	2-124
TIER III ENGINE	2-79
WATER PUMP DRIVE	
TIER III ENGINE	2-80
WET BRAKE ASSEMBLY	6-12
WHEEL HUB ASSEMBLY	
HYSTER TIRE SAVER DRIVE AXLE	6-14
WINDOW WIPER SYSTEM	
REAR AND ROOF WIPER KITS - AND FRONT WIPER OPTIONS	1-24
WASHER BOTTLE KIT	1-22
WIRE HARNESS	
ARM REST	4-36
CAB	4-40
CAB LIGHTS	4-44

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
CAB SIDE CONSOLE, PAGE 1 OF 2 - TIER III ENGINE (→ PENDING PER ECN 68653)	4-46
CAB SIDE CONSOLE, PAGE 1 OF 3 - TIER III ENGINE (PENDING PER ECN 68653 →)	4-60
CAB SIDE CONSOLE, PAGE 1 OF 3 - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-74
CAB SIDE CONSOLE, PAGE 1 OF 3 - STAGE 3B ENGINE (PENDING PER ECN 68653 →)	4-88
CAB SIDE CONSOLE, PAGE 2 OF 2 - TIER III ENGINE (→ PENDING PER ECN 68653)	4-52
CAB SIDE CONSOLE, PAGE 2 OF 3 - TIER III ENGINE (PENDING PER ECN 68653 →)	4-64
CAB SIDE CONSOLE, PAGE 2 OF 3 - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-78
CAB SIDE CONSOLE, PAGE 2 OF 3 - STAGE 3B ENGINE (PENDING PER ECN 68653 →)	4-92
CAB SIDE CONSOLE, PAGE 3 OF 3 - TIER III ENGINE (PENDING PER ECN 68653 →)	4-68
CAB SIDE CONSOLE, PAGE 3 OF 3 - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-82
CAB SIDE CONSOLE, PAGE 3 OF 3 - STAGE 3B ENGINE (PENDING PER ECN 68653 →)	4-96
CAB UNDERFLOOR - TIER III ENGINE	4-102
CAB UNDERFLOOR - STAGE 3B ENGINE	4-104
DPF	4-163
FRONT LIGHTS	4-164
HYDRAULIC RELAYS	4-165
LIFT INTERRUPT BYPASS	4-166
OIL COOLER	4-167
POWERED CAB TILT	4-169
PRESSURE SWITCH BASE - AUTOMATIC GREASING SYSTEM	4-170
PUMP BASE - AUTOMATIC GREASING SYSTEM	4-171
REAR WIPER EXTENSION	4-172
SIDE INDICATOR	4-173
SPEED LIMITER	4-174
STEERING COLUMN - TIER III ENGINE	4-176
STEERING COLUMN - STAGE 3B ENGINE	4-177
TWIN FRONT FENDER WORK LIGHTS	4-192
WIF EXTENSION	4-178
WINDOW WASH PUMPS	4-179
WIRE HARNESS (CHASSIS)	
PAGE 1 OF 2 - TIER III ENGINE (→ PENDING PER ECN 68653)	4-106
PAGE 1 OF 2 - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-114
PAGE 1 OF 2 - STAGE 3B ENGINE (H16XM-12EC, H18XM-12EC) (PENDING PER ECN 68653 →)	4-124
PAGE 1 OF 2 - TIER III ENGINE (H16XM-12EC, H18XM-12EC) (PENDING PER ECN 68653 →)	4-134
PAGE 1 OF 2 - STAGE 3B ENGINE (H22XM-12EC) (PENDING PER ECN 68653 →)	4-144
PAGE 1 OF 2 - TIER III ENGINE (H22XM-12EC) (PENDING PER ECN 68653 →)	4-154
PAGE 2 OF 2 - TIER III ENGINE (→ PENDING PER ECN 68653)	4-110
PAGE 2 OF 2 - STAGE 3B ENGINE (→ PENDING PER ECN 68653)	4-120
PAGE 2 OF 2 - STAGE 3B ENGINE (H16XM-12EC, H18XM-12EC) (PENDING PER ECN 68653 →)	4-130
PAGE 2 OF 2 - TIER III ENGINE (H16XM-12EC, H18XM-12EC) (PENDING PER ECN 68653 →)	4-140
PAGE 2 OF 2 - STAGE 3B ENGINE (H22XM-12EC) (PENDING PER ECN 68653 →)	4-150
PAGE 2 OF 2 - TIER III ENGINE (H22XM-12EC) (PENDING PER ECN 68653 →)	4-160
WIRE HARNESS AND SWITCH ASSEMBLY	
MONOTROL PEDAL	4-180

ABBREVIATIONS QUICK REFERENCE SHEET

Listed below are abbreviations used in parts manuals to denote the following expressions:

TERM	DEFINITION	TERM	DEFINITION
Amp	Amperes	FRE	Freezer Environment
AR	As Required	in.	inches
BDI	Battery Discharge Indicators	LPG	Liquefied Petroleum Gas
BWI	Brush Wear Indicator	MAP	Manifold Absolute Pressure
CE	Communicator End	mm	millimeters
CRE	Corrosive Environment	MSTS	Microprocessor Spark Timing System
D/B	Date Break	NPT	National Pipe Threads
dbA	Decibel "A" Scale	O/S	Oversize
DE	Drive End	PTO	Power Take Off
ECH	Empty Container Handler	RPM	Revolutions per Minute
ECH-3	Empty Container Handler - 3 High Stacking	S/N	Serial Number
ECH-4	Empty Container Handler - 4 High Stacking	TMM	Truck Management Module
ECH-5	Empty Container Handler - 5 High Stacking	UL Type D	Diesel-Powered Safety Rating
ECH-6	Empty Container Handler - 6 High Stacking	UL Type DS	Diesel-Powered Safety Rating
ECH-7	Empty Container Handler - 7 High Stacking	UL Type E	Battery-Powered Safety Rating
ECM	Electronic Control Module	UL Type EE	Battery-Powered Safety Rating
ECN	Engineering Change Notice	UL Type ES	Battery-Powered Safety Rating
EEPROM	Electrically Erasable Programmable Read Only Memory	UL Type G	Gasoline-Powered Safety Rating
EPA	US Environmental Protection Agency	UL Type GS	Gasoline-Powered Safety Rating
EPROM	Electrically Programmable Read Only Memory	UL Type LP	Gas-Powered Safety Rating
		UL Type LPS	LP Gas-Powered Safety Rating
		U/S	Undersize
		UL	Underwriters Laboratory
		V	Volts

HOW TO USE THE ILLUSTRATED PARTS MANUAL

This parts manual describes and illustrates assemblies, subassemblies, and detail parts needed for service replacement.

The different constructions are indicated by keys and footnotes. The callouts correspond to descriptions found on the next page.

The diagram illustrates the structure of the Hyster parts manual. It shows several overlapping pages with callouts 1 through 10 pointing to specific features:

- Callout 1:** Points to the 'DESCRIPTION' column in the Table of Contents.
- Callout 2:** Points to the 'SECTIONS' list on the left side of the manual.
- Callout 3:** Points to the 'HYSTER' logo at the top of the Table of Contents page.
- Callout 4:** Points to the 'TABLE OF CONTENTS' header.
- Callout 5:** Points to the 'NUMERICAL INDEX' table.
- Callout 6:** Points to the 'DESCRIPTION' column in the Transmission Housing parts list.
- Callout 7:** Points to the 'TRANSMISSION HOUSING' header.
- Callout 8:** Points to the 'ITEM' column in the Transmission Housing parts list.
- Callout 9:** Points to the 'QTY' column in the Transmission Housing parts list.
- Callout 10:** Points to the 'KEY' section defining 'A: Diesel' and 'B: Gasoline and LPG'.

Table of Contents (Table 1):

DESCRIPTION	PAGE
ACCELERATOR/MONOTROL PEDAL	5-2
BACKUP ALARM	
BATTERY CONNECTOR	
BATTERY ROLLER AN	
BRAKE ASSEMBLY	
BRAKE MASTER CYLIND	
BRAKE PEDAL LINKAG	
CARRIAGE	
THREE STAGE FULL	
TWO STAGE FULL FF	
TWO STAGE LIMITED	
CONTROL VALVE	
COUNTERWEIGHT	
DASH DISPLAY	
DC-DC CONVERTER	

Numerical Index (Table 2):

PART NO.	PG	ITEM	PART NO.	PG	ITEM	PART NO.	PG	ITEM	PART NO.	PG	ITEM
138	5-9	31	5-17	42	16481	6-25	3	6-7	16882	9-7	28
139	5-13	31	7-13	8	6-25	4	16883	6-25	16883	7-5	5
12921	5-9	32	1-4	45	6-25	53	16982	7-5	16982	8-5	25
14269	5-13	32	5-9	16	10-3	65	16982	8-5	16982	9-5	19
		10	5-9	16	16483	6-25	48	16989	6-25	10	10
		8	5-13	16	16484	6-11	3	17051	7-5	19	19
				42		6-11	9		8-5	13	13
				34		6-13	101		9-5	13	13
				13		6-25	7		6-25	6	6
				10		6-25	8	17061	3-9	24	24
				21		6-25	11	17151	3-11	26	26
				27		9-7	7	17775	6-25	22	22

Sections List (Table 3):

Section Number	Section Name
1	ELEC
2	ST
3	ST
4	BRAKE/ACCEL
5	HYD
6	HYD
7	MAST-TWO STAGE LI
8	MAST-THREE STAGE
9	MAST-TWO STAGE
10	NI
11	NI

Transmission Housing Parts List (Table 4):

ITEM	PART NO.	DESCRIPTION	QTY A	QTY B
	2022547	Transmission	1	1
	2023329	Transmission	2	2
	2064470	Case	4	4
1	2023418	Bearing Cap	1	1
2	296426	Washer	2	2
3	293692	Capscrew	2	2
4	2021390	Cover	4	4
5	1371656	Coller Pin	1	1
6	2021329	O-Ring	4	4
7	2021915	Plug	22	22
8	2021675	Housing	39	39
9	2021336	Pin	1	1
10	287860	Capscrew	1	1
11	292682	Lockwasher	8	8
12		Hydraulic Pump (see Figure 6-6)	8	8
13		Gasket	8	8
14	2021345	Capscrew	1	1
15	214364	Washer	1	1
16	296418	Temperature Switch	1	1
17	2021388	Breather	9	9
18	2021389	Breather	9	9
19	2021383	Dipstick	2	2
20	292515	Capscrew	3	3
21	136692	Nut	3	2
22	292527	Capscrew	4	4
23	292531	Capscrew	4	4
24	292683	Lockwasher	4	4
25	293637	Capscrew	1	1
26	296420	Washer	1	1
	996403	Transmission Kit (Include Item 7)		
	996405	Transmission Kit (Include Item 14)		

Key:
A: Diesel
B: Gasoline and LPG

Footnote:
This Parts Manual is divided into 11 major sections which are listed above. Quick reference can be made by placing the right thumb on the tab of the desired section, bending the bottom edge of the page to the corresponding tab.

Page Information:
©2001 HYSTER COMPANY
See Service Manual for service procedures.
3-15

HP990135

HOW TO FIND THE DESIRED PART NUMBER

WHEN THE PART NUMBER AND THE NEXT HIGHER ASSEMBLY IS NOT KNOWN:

1. Determine the function and application of the part required. Turn to the Sections Page. Choose the general area of reference most likely to include the part.
2. Turn to the section you chose. Use the Section Table of Contents to determine the assembly which would normally contain the part required. Then locate the part on the assembly breakdown page.

WHEN THE PART NUMBER IS NOT KNOWN AND THE NEXT HIGHER ASSEMBLY IS KNOWN:

3. Determine the assembly the required part is used on. Turn to the Table of Contents (Page i).
4. Locate the assembly the required part is used on and turn to the page indicated for that assembly. Then locate the part on the assembly breakdown page.

WHEN THE PART NUMBER IS KNOWN:

5. Use the Numerical Index (Page 13-1) to find the part number. Turn to the page listed and locate the part as indicated by the item number.

GENERAL:

The assembly breakdowns include part numbers, descriptions, quantities required, keys and footnotes to help in selecting correct parts.

6. Parts Supersession Information. Part numbers that have this history will be displayed in the parts list in the order that they were superseded (from oldest to newest). The superseded part numbers will be shown with a line through them.

Five periods in the PART NO. column (.) indicate that the part is either *Not Serviced Separately* or there is a reference to another figure. A figure reference is denoted by a pointing hand followed by a figure number in the DESCRIPTION column (☞ Figure 10)

7. Keys are used to show two or more similar assemblies, RH and LH assembly parts, etc. Select the appropriate key, "A", "B", "C", "D", or "E" and the corresponding quantity column to find the required parts. Two periods in the QTY column (..) indicate that the part is not used for that assembly.
8. Indented descriptions under the DESCRIPTION column are used to indicate assemblies and

subparts of assemblies. In the example on the previous page, *BEARING CAP* (Item 2) is a subpart of the major assembly *CASE*.

9. Quantities shown are for one assembly. The quantities of the subpart *BEARING CAP* are indicated as two and two. This means two per *CASE* assembly.
10. Serial number breaks identify the most current parts information and are shown as follows:
 - **S/N D001H2628**
Indicates last serial number affected.
 - S/N D001H2629** →
Indicates the first serial number affected.
 - S/N D001H1553** ↔ **S/N D001H3291**
Indicates a range of serial numbers affected.

ECN numbers for pending serial numbers are shown to allow for the inclusion of the most current parts information and are identified as follows:

- **S/N Pending Per ECN 63243**
Indicates a pending serial number for last unit affected.
- S/N Pending Per ECN 63243** →
Indicates a pending serial number for first unit affected.

Date breaks are used to indicate when a change occurred but a subsequent serial number break was not recorded. This is an arbitrary date usually based on the ECN release and are identified as follows:


- **D/B 3/00**
Indicates that a change occurred sometime within that month for the item affected.
- D/B 3/00** →
Indicates that a change occurred sometime within that month for the item affected.
- D/B 3/00** ↔ **D/B 4/00**
Indicates a range of production dates of the item affected.

Contact your local dealer for Hyster lift trucks for serial number information for items with a ECN or a date break.

ORDERING PARTS:


When ordering replacement parts, give the unit serial number, part number, name of part and quantity required.

For any further information on parts, service, or ordering, consult your local dealer for Hyster lift trucks.

IDENTIFICATION OF TRUCK SERIAL NUMBERS

- (1) and (2) The first letter and three numbers indicate the truck unit code.
- (3) The second letter indicates the plant of manufacture.
- (4) The four or five digit number indicates the production sequence number of the truck.
- (5) The final letter indicates the year of manufacture starting with "A" in 1957, 1980, and 2003. The letters "I", "O", and "Q" will not be used.


For pending serial numbers contact your local dealer for Hyster lift trucks.



HP990001

Parts referred to in this book as right or left hand parts are in accordance with the illustration above.

IDENTIFICATION OF MAST SERIAL NUMBERS



- (1) and (2) The first letter and number indicates the mast unit code.
- (3) The second letter indicates the plant of manufacture.
- (4) The four or five digit number indicates the production sequence number of the mast.
- (5) Carriage travel in millimeters stamped just below the serial number.

Mast Group identification consists of mast unit code (1) and (2) plus carriage travel (5).


For pending production sequence numbers contact your local dealer for Hyster lift trucks.

LIFT EQUIPMENT IDENTIFICATION

1. Fork part number, capacity rating, plant code letter, and date of manufacture are stamped approximately six inches below the top of most forks.
2. The carriage group number is stamped on the right hand side of the top crossmember (pin type) or on the back of the right hand end of the bottom crossmember (hook type). A date code has two letters in line with or below the carriage group number.
3. The mast identification number has a unit code, a letter indicating the plant of manufacture, and a serial number. Underneath the production sequence number is a four digit number that indicates the carriage travel in millimeters.
4. Tilt and lift cylinder group numbers are stamped on the cylinder shell.

Always refer to the group, serial, or part number when ordering service parts.

Modification of masts and carriages by SPED (Special Products Engineering Department) are identified by a model prefix code beginning with the letter "S". contact your dealer for Hyster lift trucks for information on these assemblies.



HP990002