


HP8902 -UN-10AUG99



*RUBBER TRACK SYSTEM
(MANUFACTURED 1997-)*

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

NOTE

THE RUBBER TRACK SYSTEM IS AVAILABLE FOR JOHN DEERE 9500, 9600, CTS, 9510, 9610 AND CTS-2 COMBINES. THE RUBBER TRACK SYSTEM IS NOT COMPATIBLE WITH THE 9500 SIDEHILL.

FOR 9500 MAXIMIZER™ COMBINE PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2179.

FOR 9600 MAXIMIZER™ COMBINE PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2181.

FOR CTS COMBINE (NORTH AMERICAN VERSION), REFER TO JOHN DEERE PARTS CATALOG - PC2341.

FOR 9510 MAXIMIZER™ COMBINE PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2701.

FOR 9610 MAXIMIZER™ COMBINE PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2702.

FOR CTS-2 COMBINE PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2752.

SERIAL NUMBERS

WHEN WRITING OR FILLING OUT WARRANTY CLAIMS, USE ALL NUMBERS, LETTERS AND SPACES SHOWN ON THE SERIAL NUMBER PLATE. THE SERIAL NUMBER IS ATTACHED TO THE FACE OF THE MAIN PIVOT FRAME

EXAMPLES: L 97 001 0822
R 97 001 0822

L - DESIGNATES LEFT-HAND

R - DESIGNATES RIGHT-HAND

97 - DESIGNATES YEAR OF MANUFACTURE

001 - DESIGNATES SEQUENTIAL UNIT NUMBER

0822 - DESIGNATES THE DATE OF MANUFACTURE

SERIAL NUMBER LISTING INFORMATION

SERIAL NUMBER INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
-000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
A			I		
B8	ACCUMULATOR, ONE HALF GALLON INDIVIDUAL REPAIR PARTS	36	A10	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM	10
A10	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM	10	A14	IDLER AXLE	14
A12	AIR SUSPENSION	12	A16	IDLER WHEEL ASSEMBLY.....	16
A10	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY	10	L		
A14	ARM, REAR	14	B10	LABELS, SAFETY	38
A14	AXLE, IDLER	14	M		
A17	AXLES, BOGEY WHEEL	18	A8	MAIN FRAME PIVOT BUSHINGS	8
B			A22	MOUNTING, FINAL DRIVE SINGLE REDUCTION AND HIGH CLEARANCE	24
A19	BEARING, BOGEY WHEEL.....	20	A24	MOUNTING, FINAL DRIVE - PLANETARY	26
A17	BEARINGS, BOGEY WHEEL AXLE	18	A6	MOUNTING, TRACK FRAME	6
A16	BEARINGS, IDLER WHEEL.....	16	O		
B3	BELT AND DRIVE WHEEL	30	B8	ONE HALF GALLON ACCUMULATOR INDIVIDUAL REPAIR PARTS	36
A19	BOGEY WHEEL ASSEMBLY.....	20	P		
A17	BOGEY WHEEL AXLES	18	A8	PIVOT BUSHINGS, MAIN FRAME	8
A20	BOX, GEAR, TRANSFER.....	22	R		
B1	BRAKE SHOES AND DRUM.....	28	A14	REAR ARM, TENSION CYLINDER & IDLER AXLE.....	14
A8	BUSHINGS, MAIN FRAME PIVOT	8	S		
C			B10	SAFETY DECALS.....	38
A20	CASE, GEAR, TRANSFER	22	B10	SAFETY LABELS	38
B7	CYLINDER, TENSION INDIVIDUAL REPAIR PARTS	34	A6	SHIPPING FRAME	6
A14	CYLINDER, TENSION AND ATTACHING HARDWARE	14	B1	SHOES AND DRUM, BRAKE	28
D			A12	SUSPENSION, AIR	12
B10	DECALS, SAFETY	38	T		
A22	DRIVE MOUNTING, FINAL SINGLE REDUCTION AND HIGH CLEARANCE	24	B7	TENSION CYLINDER INDIVIDUAL REPAIR PARTS	34
A24	DRIVE MOUNTING, FINAL - PLANETARY	26	A14	TENSION CYLINDER AND ATTACHING HARDWARE	14
B3	DRIVE WHEEL AND BELT	30	B5	TENSION CYLINDER HYDRAULICS	32
B1	DRUM AND SHOES, BRAKE	28	A6	TRACK FRAME MOUNTING	6
F			A20	TRANSFER GEAR CASE	22
A22	FINAL DRIVE MOUNTING SINGLE REDUCTION AND HIGH CLEARANCE	24	W		
A24	FINAL DRIVE MOUNTING - PLANETARY	26	A19	WHEEL ASSEMBLY, BOGEY	20
A6	FRAME MOUNTING, TRACK	6	A16	WHEEL ASSEMBLY, IDLER	16
A8	FRAME, MAIN, PIVOT BUSHINGS.....	8	A17	WHEEL AXLES, BOGEY	18
A6	FRAME, SHIPPING	6	B3	WHEEL, DRIVE AND BELT.....	30
A10	FRONT ARM AND ADJUSTABLE IDLER ASSEMBLY	10	H		
G			A19	HUB, BOGEY WHEEL	20
A20	GEAR CASE, TRANSFER.....	22	A16	HUB, IDLER WHEEL	16
H			B5	HYDRAULICS, TENSION CYLINDER	32