

SHOP MANUAL

KOMATSU

82E-98E SERIES

DIESEL ENGINE

PREFACE

This manual describes the service procedures for the 82E – 98E series engines of indirect injection system.

Please use this manual for accurate, quick and safe servicing of the said engine. Since the explanation in this manual assumes the standard type engine, the specifications and components may partially be different from the engine installed on individual machine. Please also refer to the shop manual for each machine for details.

LIST OF REVISED PAGES

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.


LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
●	00-1	(3)		1-51	(2)		2-26			4-13			4-41	
	00-2	(2)		1-52	(2)		2-27			4-14			4-42	
●	00-2-1	(3)					2-28			4-15			4-43	
	00-2-2	(2)		2-1			2-29			4-16			4-44	
	00-3			2-2			2-30			4-17			4-45	
	00-4			2-3			2-31			4-18			4-46	
	00-5			2-4			2-32			4-19			4-47	
	00-6			2-5						4-20			4-48	
	00-7			2-6			3-1			4-21			4-49	
	00-8			2-7			3-2			4-22			4-50	
	00-9			2-8			3-3			4-23				
	00-10			2-9			3-4			4-24			5-1	
	00-11			2-10			3-5			4-25			5-2	
●	00-12	(3)		2-11			3-6			4-26			5-3	
				2-12			3-7			4-27			5-4	
	1-1			2-13						4-28			5-5	
	1-2	(2)		2-14			4-1			4-29				
	1-3	(2)		2-15			4-2			4-30			6-1	
	1-4	(2)		2-16			4-3			4-31			6-2	
	1-5	(2)		2-17			4-4			4-32	(2)		6-3	
	1-6	(2)		2-18			4-5			4-33	(2)			
	1-7	(2)		2-19			4-6			4-34	(2)		7-1	
	1-8	(2)		2-20			4-7			4-35			7-2	
	1-9	(2)		2-21			4-8			4-36			7-3	
	1-10	(2)		2-22			4-9			4-37			7-4	
	1-11	(2)		2-23			4-10			4-38			7-5	
	1-12	(2)		2-24			4-11			4-39				
	1-13	(2)		2-25			4-12			4-40				

LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	8-1			10-1										
	8-2			10-2										
	8-3			10-3										
	8-4			10-4										
	8-5			10-5										
	8-6													
	8-7			11-1										
	8-8			11-2										
	8-9			11-3										
	8-10			11-4										
	8-11			11-5										
	8-12			11-6										
	8-13			11-7										
	8-14													
	8-15			12-1										
	8-16			12-2										
	8-17			12-3										
	8-18			12-4										
	8-19			12-5										
	8-20			12-6										
	8-21			12-7										
				12-8										
	9-1			12-9										
	9-2			12-10										
	9-3			12-11										
	9-4			12-12										
	9-5													
	9-6			13-1										
	9-7			13-2										
	9-8			13-3										
	9-9													
	9-10													
	9-11													
	9-12													
	9-13													
	9-14													
	9-15													
	9-16													
	9-17													

SAFETY LABELS

- Most accidents are caused by negligence of basic safety rules and precautions. For accident prevention, it is important to avoid such causes before development to accidents.
Please read this manual carefully before starting repair or maintenance to fully understand safety precautions and appropriate inspection and maintenance procedures.
Attempting at a repair or maintenance job without sufficient knowledge may cause an unexpected accident.
- It is impossible to cover every possible danger in repair or maintenance in the manual. Sufficient consideration for safety is required in addition to the matters marked . Especially for safety precautions in a repair or maintenance job not described in this manual, receive instructions from a knowledgeable leader.
- Safety marks used in this manual and their meanings are as follows:



DANGER – indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.



WARNING – indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.



CAUTION – indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.

- **NOTICE** – indicates that if not observed, the product performance or quality may not be guaranteed.

SAFETY PRECAUTIONS

(1) SERVICE AREA



- **Sufficient Ventilation**

Inhalation of exhaust fumes and dust particles may be hazardous to ones health. Running engines welding, sanding, painting, and polishing tasks should be only done in well ventilated areas.



- **Safe / Adequate Work Area**

The service area should be clean, spacious, level and free from holes in the floor, to prevent "slip" or "trip and fall" type accidents.



- **Bright, Safely Illuminated Area**


The work area should be well lit or illuminated in a safe manner. For work in enclosed or dark areas, a "drop cord" should be utilized. The drop cord must have a wire cage to prevent bulb breakage and possible ignition of flammable substances.



- **Safety Equipment**

Fire extinguisher(s), first aid kit and eye wash / shower station should be close at hand (or easily accessible) in case of an emergency.

(2) WORK - WEAR (GARMENTS)



- **Safe Work Clothing**

Appropriate safety wear (gloves, special shoes/boots, eye/ear protection, head gear, harness', clothing, etc.) should be used/worn to match the task at hand. Avoid wearing jewelry, unbuttoned cuffs, ties or loose fitting clothes around moving machinery. A serious accident may occur if caught in moving/rotating machinery.

(3) TOOLS




- **Appropriate Lifting / Holding**

When lifting an engine, use only a lifting device (crane, jack, etc.) with sufficient lifting capacity. Do not overload the device. Use only a chain, cable, or lifting strap as an attaching device. Do not use rope, serious injury may result.

To hold or support an engine, secure the engine to a support stand, test bed or test cart designed to carry the weight of the engine. Do not overload this device, serious injury may result.

Never run an engine without being properly secured to an engine support stand, test bed or test cart, serious injury may result.



- **Appropriate Tools**

Always use tools that are designed for the task at hand. Incorrect usage of tools may result in damage to the engine and or serious personal injury.


(4) GENUINE PARTS and MATERIALS



- **Genuine Parts**

Always use genuine KOMATSU parts or KOMATSU recommended parts and goods. Damage to the engine, shortened engine life and or personal injury may result.


(5) FASTENER TORQUE



- **Torquing Fasteners**

Always follow the torque values and procedures as designated in the shop manual. Incorrect values, procedures and or tools may cause damage to the engine and or personal injury.

(6) ELECTRICAL SYSTEM



- **Short Circuits**

Always disconnect the (-) Negative battery cable before working on the electrical system. An accidental "short circuit" may cause damage, fire and or personal injury. Remember to connect the (-) Negative battery cable (back onto the battery) last. Fasten the terminals tightly.



- **Charging Batteries**

Charging wet celled batteries produces hydrogen gas. Hydrogen gas is extremely explosive. Keep sparks, open flame and any other form of ignition away. Explosion may occur causing severe personal injury.



- **Battery Electrolyte**

Batteries contain sulfuric acid. Do NOT allow it to come in contact with clothing, skin and or eyes, severe burns will result.

(7) WASTE MANAGEMENT



Observe the following instructions with regard to hazardous waste disposal. Negligence of these will have a serious impact on environmental pollution concerns.

- 1) Waste fluids such as lube oil, fuel and coolant shall be carefully put into separate sealed containers and disposed of properly.
- 2) Do NOT dispose of waste materials irresponsibly by dumping them into the sewer, overland or into natural waterways.
- 3) Waste materials such as oil, fuel, coolant, solvents, filter elements and batteries, must be disposed of properly according to local ordinances. Consult the local authorities or reclamation facility.

(8) FURTHER PRECAUTIONS**⚠ WARNING****• Fueling / Refueling**

Keep sparks, open flames or any other form of ignition (match, cigarette, etc.) away when fueling/refueling the unit. *Fire and or an explosion may result.*

⚠ WARNING**• Hot Surfaces.**

Do NOT touch the engine (or any of its components) during running or shortly after shutting it down. *Scalding / serious burns may result.* Allow the engine to cool down before attempting to approach the unit.

⚠ WARNING**• Rotating Parts**

Be careful around moving/rotating parts. Loose clothing, jewelry, ties or tools may become entangled causing damage to the engine and or severe personal injury.

⚠ WARNING**• Preventing burns from scalding**

- 1) Never open the radiator filler cap shortly after shutting the engine down.
Steam and hot water will spurt out and seriously burn you. Allow the engine to cool down before attempt to open the filler cap.
- 2) Securely tighten the filler cap after checking the radiator.
Steam can spurt out during engine running, if tightening loose.

PRECAUTIONS FOR SERVICE WORK

PRECAUTIONS FOR SERVICE WORK**1. Precautions for Safety**

Read the safety precautions given at the beginning of this manual carefully and always mind safety in work.

2. Preparation for Service Work

Preparation is necessary for accurate, efficient service work. Check the customer ledger file for the history of the engine.

- Preceding service date
- Period/operation hours after preceding service
- Problems and actions in preceding service
- Replacement parts expected to be required for service
- Recording form/check sheet required for service

3. Preparation before Disassembly

- Prepare general tools, special service tools, measuring instruments, oil, grease, non reusable parts, and parts expected to be required for replacement.
- When disassembling complicated portions, put match marks and other marks at places not adversely affecting the function for easy reassembly.

4. Precautions in Disassembly

- Each time a parts is removed, check the part installed state, deformation, damage, roughening, surface defect, etc.
- Arrange the removed parts orderly with clear distinction between those to be replaced and those to be used again.
- Parts to be used again shall be washed and cleaned sufficiently.
- Select especially clean locations and use clean tools for disassembly of hydraulic units such as the fuel injection pump.

5. Precautions for Inspection and Measurement

Inspect and measure parts to be used again as required to determine whether they are reusable or not.

6. Precautions for Reassembly

- Reassemble correct parts in correct order according to the specified standards (tightening torques, and adjustment standards). Apply oil important bolts and nuts before tightening when specified.
- Always use genuine parts for replacement.
- Always use new oil seals, O-rings, packings and cotter pins.
- Apply sealant to packings depending on the place where they are used. Apply of grease to sliding contact portions, and apply grease to oil seal lips.

7. Precautions for Adjustment and Check

Use measuring instruments for adjustment to the specified service standards.