

Operation & Maintenance Manual

PC600-8 PC600LC-8

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC600-8 - K50001 and up

PC600LC-8 - K50001 and up



WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept inside the cab for reference and periodically reviewed by all personnel who will come into contact with the machine.

KOMATSU

FOREWORD

FOREWORD

This manual provides rules and guidelines which will help you use this machine safely and effectively. The precautions in this manual must be followed at all times when performing operation and maintenance. Most accidents are caused by the failure to follow fundamental safety rules for the operation and maintenance of machines. Accidents can be prevented by knowing beforehand conditions that may cause a hazard when performing operation and maintenance.


WARNING

Before beginning operation or maintenance, operators and maintenance personnel must always observe the following points.

- Read this manual thoroughly and understand its contents fully.
- Read the safety messages and safety labels given in this manual carefully so that they should be understood fully.
- Keep this manual at the storage location for the Operation and Maintenance Manual given below so that all personnel involved in working on the machine can consult it periodically.
- In case this manual should be lost or damaged, immediately contact Komatsu or your Komatsu distributor to obtain a new copy.
- When you sell the machine, make sure that this manual should be provided to the new owner together with the machine.

In this manual, measurements are expressed in international standard units (SI). For the reference purpose, weight units used in the past are also displayed in ().

Storage location for the Operation and Maintenance Manual:
magazine box on the left side of the operator's seat.



9JH02474

SAFETY INFORMATION

To enable you to use this machine safely, safety precautions and labels are given in this manual and affixed to the machine to give explanations of situations involving potential hazards and of the methods of avoiding such situations.

Signal words

The following signal words are used to inform you that there is a potential hazardous situation that may lead to personal injury or damage.

In this manual and on machine labels, the following signal words are used to express the potential level of hazard.



Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. This word is used also to alert against unsafe practices that may cause property damage.

Example of safety message using signal word



When standing up from the operator's seat, always place the lock lever in the LOCK position. If you accidentally touch the control levers when they are not locked, this may cause a serious injury or death.

Other signal words

In addition to the above, the following signal words are used to indicate precautions that should be followed to protect the machine or to give information that is useful to know.

NOTICE

This word is used for precautions that must be taken to avoid actions which could shorten the life of the machine.

REMARKS


This word is used for information that is useful to know.

- Safety labels

Safety labels are affixed to the machine to inform the operator or maintenance worker on the spot when carrying out operation or maintenance of the machine that may involve hazard.

This machine uses “Safety labels using words” and “Safety labels using pictograms” to indicate safety procedures.

Example of safety label using words



Part No.

Safety labels using pictogram

Safety pictograms use a picture to express a level of hazardous condition equivalent to the signal word. These safety pictograms use pictures in order to let the operator or maintenance worker understand the level and type of hazardous condition at all times.

Safety pictograms show the type of hazardous condition at the top or left side, and the method of avoiding the hazardous condition at the bottom or right side. In addition, the type of hazardous condition is displayed inside a triangle and the method of avoiding the hazardous condition is shown inside a circle.



Part No.

Komatsu cannot predict every circumstance that might involve a potential hazard in operation and maintenance. Therefore, the safety messages in this manual and on the machine may not include all possible safety precautions.

If any procedures or actions not specifically recommended or allowed in this manual are used, it is your responsibility to take the necessary steps to ensure safety.


In no event should you engage in prohibited uses or actions described in this manual.

The explanations, values, and illustrations in this manual were prepared based on the latest information available at that time. Continuing improvements in the design of this machine can lead to changes in detail which may not be reflected in this manual. Consult Komatsu or your Komatsu distributor for the latest available information of your machine or for questions regarding information in this manual.

The numbers in circles in the illustrations correspond to the numbers in () in the text. (For example: ① -> (1))

NOISE

- Sound pressure level at the operator's station, measured according to ISO6396 (Dynamic test method, simulated working cycle).



- Sound power level emitted. This is the guaranteed value as specified in the European directive 2000/14/EC



Vibration levels

When used for its intended purpose, levels of vibration for the earth-moving machine transmitted from the operator's seat are lower than or equal to the tested vibrations for the relative machinery class in compliance with ISO 7096.

The actual acceleration value for the hands and arms is less than or equal to 2.5 m/s². The actual acceleration value for the body is less than or equal to 0.5 m/s².

These values were determined using a representative machine and measured during the typical operating condition indicated below according to the measurement procedures that are defined in the standards ISO 2631/1 and ISO 5349.

Operating condition:

Excavating (Digging-loading-rotating-unloading-rotating)

Guide to Reduce Vibration Levels on Machine

The following guides can help an operator of this machine to reduce the whole body vibration levels:

1. Use the correct equipment and attachments.
2. Maintain the machine according to this manual
 - Tension of crawler (for crawler machines)
 - Brake and steering systems
 - Controls, hydraulic system and linkages
3. Keep the terrain where the machine is working and traveling in good condition
 - Remove any large rocks or obstacles
 - Fill any ditches and holes
 - Site manager should provide machine operators with machine and schedule time to maintain terrain conditions
4. Use a seat that meets ISO 7096 and keep the seat maintained and adjusted
 - Adjust the seat and suspension for the weight and size of the operator
 - Wear seat belt
 - Inspect and maintain the seat suspension and adjustment mechanisms
5. Steer, brake, accelerate, and move the attachment levers and pedals slowly so that the machine moves smoothly
6. Adjust the machine speed and travel path to minimize the vibration level
 - When pushing with bucket or blade, avoid sudden loading; load gradually
 - Drive around obstacles and rough terrain conditions
 - Slow down when it is necessary to go over rough terrain
 - Make the curve radius of traveling path as large as possible
 - Travel at low speed when traveling around sharp curves

7. Minimize vibrations for long work cycle or long distance traveling
 - Reduce speed to prevent bounce
 - Transport machines long distances between worksites
8. The following guidelines can be effective to minimize risks of low back pain
 - Operate the machine only when you are in good health.
 - Provide breaks to reduce long periods of sitting in the same posture
 - Do not jump down from the cab or machine
 - Do not repeatedly handle and lift loads


INTRODUCTION

This Komatsu machine is designed to be used mainly for the following work:

- Digging work
- Leveling work
- Ditching work
- Loading work
- Demolition work

See the section "RECOMMENDED APPLICATIONS (3-119)" for further details.

DIRECTIONS OF MACHINE



- | | |
|-----------|---------------------|
| (A) Front | (E) Operator's seat |
| (B) Rear | (F) Sprocket |
| (C) Left | |
| (D) Right | |


In this manual, the terms front, rear, left, and right refer to the travel direction as seen from the operator's seat when the operator's seat is facing the front and the sprocket is at the rear of the machine.

VISIBILITY FROM OPERATOR'S SEAT

The visibility standards (ISO 5006) for this machine require a view shown in the diagram below.

PROXIMITY VISIBILITY


The visibility of this machine in the area 1 m from the outside surface of the machine at a height of 1.5 m is shown in the diagram below. The hatched area (A) shows the area where the view is blocked by part of the machine when mirrors or other aids to visibility are installed as standard. Please be fully aware that there are places that cannot be seen when operating the machine.



9JH08383

12M CIRCUMFERENCE VISIBILITY

The visibility at a radius of 12 m from the machine is as shown in the diagram below. The hatched areas (B) show the areas where the view is blocked when mirrors or other aids to visibility are installed as standard. Please be fully aware that there are places that cannot be seen when operating the machine.



9JH08384

BREAKING-IN THE NEW MACHINE

NOTICE

Your Komatsu machine has been thoroughly adjusted and tested before shipment from the factory. However, operating the machine under full load before breaking the machine in can adversely affect the performance and shorten the machine life.

Be sure to break in the machine for the initial 100 hours (as indicated on the service meter).

Make sure that you fully understand the content of this manual, and pay careful attention to the following points when breaking in the machine.

- Run the engine at idle for 15 seconds after starting it. During this time, do not operate the control levers or fuel control dial.
- Idle the engine for 5 minutes after starting it up.
- Avoid operation with heavy loads or at high speeds.
- Immediately after starting the engine, avoid sudden starts, sudden acceleration, unnecessary sudden stops, and sudden changes in direction.


PRODUCT INFORMATION

When requesting service or ordering replacement parts, please inform your Komatsu distributor of the following items.

PRODUCT IDENTIFICATION NUMBER (PIN)/MACHINE SERIAL NO. PLATE


On the bottom right of the operator's cab

The design of the nameplate differs according to the territory.



ENGINE SERIAL NUMBER PLATE AND ITS LOCATION


On the upper side of the engine cylinder head cover.



EPA: Environmental Protection Agency, U.S.A.

SERVICE METER LOCATION

On top of the machine monitor



YOUR MACHINE SERIAL NUMBERS AND DISTRIBUTOR

Machine serial No.

Engine serial No.


Product Identification Number

Manufacturers name:	KOMATSU UK Ltd.
Address:	Durham Road Birtley Chester-Le street County Durham DH3 2QX United Kingdom

Distributor
Address

Phone

MACHINE SERIAL PLATE



CONTENTS

FOREWORD

FOREWORD	1-2
SAFETY INFORMATION	1-3
SIGNAL WORDS	1-3
EXAMPLE OF SAFETY MESSAGE USING SIGNAL WORD	1-3
OTHER SIGNAL WORDS	1-3
EXAMPLE OF SAFETY LABEL USING WORDS	1-4
SAFETY LABELS USING PICTOGRAM	1-4
NOISE	1-5
Vibration levels	1-6
GUIDE TO REDUCE VIBRATION LEVELS ON MACHINE	1-6
INTRODUCTION	1-8
DIRECTIONS OF MACHINE	1-8
VISIBILITY FROM OPERATOR'S SEAT	1-9
PROXIMITY VISIBILITY	1-9
12M CIRCUMFERENCE VISIBILITY	1-9
BREAKING-IN THE NEW MACHINE	1-10
PRODUCT INFORMATION	1-11
PRODUCT IDENTIFICATION NUMBER (PIN)/MACHINE SERIAL NO. PLATE	1-11
ENGINE SERIAL NUMBER PLATE AND ITS LOCATION	1-11
SERVICE METER LOCATION	1-12
YOUR MACHINE SERIAL NUMBERS AND DISTRIBUTOR	1-12
MACHINE SERIAL PLATE	1-13

SAFETY

SAFETY INFORMATION	2-2
SAFETY LABELS	2-4
LOCATION OF SAFETY LABELS	2-5
SAFETY LABELS	2-6
SAFETY INFORMATION	2-13
SAFETY MACHINE OPERATION	2-22
STARTING ENGINE	2-22
OPERATION	2-24
TRANSPORTATION	2-30
BATTERY	2-31
TOWING	2-32
LIFTING OBJECTS WITH BUCKET	2-33

SAFETY MAINTENANCE INFORMATION	2-34
---	------

OPERATION

MACHINE VIEW ILLUSTRATIONS	3-2
OVERALL MACHINE VIEW.....	3-2
CONTROLS AND GAUGES.....	3-3
DETAILED CONTROLS AND GAUGES	3-5
MONITORING SYSTEM.....	3-5
BASIC OPERATION OF MACHINE MONITOR	3-6
EMERGENCY MONITORS	3-9
CAUTION MONITORS	3-11
BASIC CHECK MONITORS.....	3-13
METER DISPLAY PORTION.....	3-15
MONITOR SWITCHES PORTION	3-20
SWITCHES.....	3-34
CONTROL LEVERS AND PEDALS	3-41
SUN ROOF	3-44
OPENING	3-44
CLOSING.....	3-44
WINDSHIELD	3-45
EMERGENCY EXIT FROM OPERATOR'S CAB	3-50
DOOR LOCK	3-50
CAP WITH LOCK.....	3-51
HOT AND COOL BOX.....	3-52
MAGAZINE BOX.....	3-52
ASHTRAY	3-52
AIR CONDITIONER CONTROLS.....	3-53
AIR CONDITIONER CONTROL PANEL	3-53
METHOD OF OPERATION.....	3-57
USE AIR CONDITIONER WITH CARE	3-63
INSPECTION AND MAINTENANCE OF AIR CONDITIONER EQUIPPED MACHINE.....	3-63
OTHER FUNCTIONS	3-64
CAB RADIO	3-65
USE RADIO WITH CARE.....	3-65
AUXILIARY ELECTRIC POWER.....	3-66
24V POWER SOURCE	3-66
12V POWER SOURCE	3-66
FUSE	3-67
CIRCUIT BREAKER	3-68
CONTROLLER	3-69
TOOL BOX.....	3-69
GREASE PUMP.....	3-70
METHOD OF USE.....	3-70
PRECAUTIONS WHEN USING	3-71
SUPPLYING GREASE	3-71

CONTENTS

ACCUMULATOR	3-73
RELEASING HYDRAULIC PRESSURE WITH ACCUMULATOR.....	3-73
MACHINE OPERATIONS AND CONTROLS.....	3-74
BEFORE STARTING ENGINE	3-74
WALK-AROUND CHECKS.....	3-74
CHECKS BEFORE STARTING.....	3-75
ADJUSTMENT.....	3-84
SEAT BELT	3-87
OPERATIONS BEFORE STARTING ENGINE	3-88
STARTING ENGINE	3-91
AFTER STARTING ENGINE	3-94
WARMING UP ENGINE	3-94
WARMING UP HYDRAULIC EQUIPMENT.....	3-96
OPERATION AFTER COMPLETION OF WARMING-UP OPERATION.....	3-100
STOPPING THE ENGINE	3-101
MACHINE OPERATION	3-102
PREPARATIONS FOR MOVING THE MACHINE.....	3-102
MOVING MACHINE FORWARD	3-103
MOVING MACHINE BACKWARD.....	3-104
STOPPING MACHINE.....	3-105
STEERING THE MACHINE.....	3-106
STEERING	3-106
SWINGING	3-108
WORK EQUIPMENT CONTROLS AND OPERATIONS	3-109
WORKING MODE.....	3-110
PROHIBITED OPERATIONS	3-112
GENERAL OPERATION INFORMATION	3-114
TRAVELING ON SLOPES.....	3-116
ESCAPE FROM MUD.....	3-118
TRACK ON ONE SIDE STUCK.....	3-118
TRACKS ON BOTH SIDES STUCK.....	3-118
RECOMMENDED APPLICATIONS.....	3-119
DITCHING WORK	3-119
LOADING WORK	3-119
BUCKET REPLACEMENT	3-120
REPLACEMENT.....	3-120
PARKING MACHINE	3-122
MACHINE INSPECTION AFTER DAILY WORK.....	3-123
LOCKING.....	3-124
OVERLOAD WARNING DEVICE (option).....	3-124
TRANSPORTATION.....	3-125
PRECAUTIONS FOR TRANSPORTATION	3-125
LIFTING MACHINE.....	3-125
SHIPPING MACHINE INFORMATION	3-127
TRANSPORTATION POSTURE	3-128
PROCEDURE FOR INCREASING OR REDUCING TRACK FRAME GAUGE.....	3-133

COLD WEATHER OPERATION	3-135
COLD WEATHER OPERATION INFORMATION.....	3-135
FUEL AND LUBRICANTS	3-135
COOLING SYSTEM COOLANT	3-135
BATTERY	3-136
MONITOR.....	3-137
AFTER DAILY WORK COMPLETION.....	3-138
AFTER COLD WEATHER SEASON	3-138
LONG TERM STORAGE	3-139
BEFORE STORAGE.....	3-139
DURING STORAGE	3-139
AFTER STORAGE.....	3-140
STARTING MACHINE AFTER LONG-TERM STORAGE	3-140
TROUBLES AND ACTIONS	3-141
RUNNING OUT OF FUEL	3-141
PHENOMENA THAT ARE NOT FAILURES.....	3-142
TOWING THE MACHINE	3-143
SEVERE JOB CONDITION	3-143
DISCHARGED BATTERY	3-144
BATTERY REMOVAL AND INSTALLATION	3-144
BATTERY CHARGES	3-145
STARTING ENGINE WITH BOOSTER CABLES.....	3-146
OTHER TROUBLE	3-148
ELECTRICAL SYSTEM.....	3-148
CHASSIS.....	3-149
ENGINE	3-150
ELECTRONIC CONTROL SYSTEM.....	3-152
POINT OF CONTACT TO TELEPHONE WHEN ERROR OCCURS	3-153

MAINTENANCE

MAINTENANCE INFORMATION	4-2
OUTLINE OF SERVICE	4-4
HANDLING OIL, FUEL, COOLANT, AND PERFORMING OIL CLINIC	4-4
OIL	4-4
FUEL.....	4-4
COOLING SYSTEM COOLANT	4-5
GREASE.....	4-5
CARRYING OUT KOWA (KOMATSU OIL WEAR ANALYSIS).....	4-6
OIL AND FUEL STORAGE.....	4-7
FILTERS.....	4-7
ELECTRIC SYSTEM MAINTENANCE	4-8
WEAR PARTS	4-9
WEAR PARTS LIST.....	4-9

CONTENTS

LUBRICANTS, FUEL AND COOLANT SPECIFICATIONS	4-10
RECOMMENDED BRANDS, RECOMMENDED QUALITY FOR PRODUCTS OTHER THAN KOMATSU GENUINE OIL.....	4-11
TIGHTENING TORQUE SPECIFICATIONS	4-12
TIGHTENING TORQUE LIST.....	4-12
SAFETY CRITICAL PARTS	4-13
SAFETY CRITICAL PARTS LIST	4-14
MAINTENANCE SCHEDULE	4-15
MAINTENANCE SCHEDULE CHART.....	4-15
MAINTENANCE INTERVAL FOR HYDRAULIC BREAKER.....	4-17
MAINTENANCE PROCEDURE	4-18
INITIAL 100 HOURS MAINTENANCE (ONLY AFTER THE FIRST 100 HOURS).....	4-18
INITIAL 500 HOURS MAINTENANCE (ONLY AFTER THE FIRST 500 HOURS).....	4-18
WHEN REQUIRED	4-19
CHECK, CLEAN AND REPLACE AIR CLEANER ELEMENT.....	4-19
CLEAN INSIDE OF COOLING SYSTEM	4-24
CHECK AND TIGHTEN TRACK SHOE BOLTS.....	4-27
CHECK AND ADJUST TRACK TENSION.....	4-28
REPLACE BUCKET TEETH (HORIZONTAL PIN TYPE).....	4-30
ADJUST BUCKET CLEARANCE	4-31
CHECK WINDOW WASHER FLUID LEVEL, ADD FLUID	4-32
CHECK AND MAINTENANCE AIR CONDITIONER	4-33
CLEAN LINE FILTER, REMOVE DIRT	4-34
REPLACE BREAKER CIRCUIT ADDITIONAL OIL FILTER ELEMENT.....	4-35
CLEAN PILOT LINE FILTER, REMOVE DIRT	4-36
BLEEDING AIR FROM HYDRAULIC SYSTEM.....	4-37
CHECK BEFORE STARTING	4-40
EVERY 10 HOURS MAINTENANCE.....	4-41
LUBRICATING.....	4-41
EVERY 100 HOURS MAINTENANCE.....	4-44
LUBRICATING SWING CIRCLE	4-44
EVERY 250 HOURS MAINTENANCE.....	4-45
CHECK OIL LEVEL IN FINAL DRIVE CASE, ADD OIL	4-45
CHECK LEVEL OF BATTERY ELECTROLYTE	4-46
CHECK AND TIGHTEN TRACK FRAME AND AXLE CONNECTING BOLTS	4-48
CHECK ALTERNATOR DRIVE BELT TENSION, ADJUST	4-49
CHECK AIR CONDITIONER COMPRESSOR BELT TENSION, ADJUST	4-50
EVERY 500 HOURS MAINTENANCE.....	4-51
REPLACE FUEL PRE-FILTER CARTRIDGE.....	4-51
CHECK SWING PINION GREASE LEVEL, ADD GREASE	4-54
CLEAN,CHECK RADIATOR FINS,OIL COOLER FINS,FUEL COOLER FINS,AFTERCOOLER FINS,CONDENSER FINS (MACHINES EQUIPPED WITH AIR CONDITIONER),PTO OIL COOLER FINS.....	4-55
CLEAN FRESH/RECIRC AIR FILTERS OF AIR CONDITIONER (ONLY FOR MACHINES EQUIPPED WITH AIR CONDITIONER)	4-57