

Shop Manual

VEBM410101



PW140-7

MACHINE MODEL

PW140-7

SERIAL NUMBER

H55051 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require.
- Materials and specifications are subject to change without notice.
- PW140-7 mount the SAA4D107E-1 engine.
- For details of the engine, see the 107 Series Engine Shop Manual.

CONTENTS

No. of page

00	FOREWORD	00-1
01	GENERAL	01-1
10	STRUCTURE, FUNCTION AND MAINTENANCE STANDARD.....	10-1
20	TESTING AND ADJUSTING.....	20-1
20	TESTING AND ADJUSTING.....	20-101
20	TESTING AND ADJUSTING Troubleshooting	20-201
20	TESTING AND ADJUSTING Troubleshooting when failure code is indicated	20-301
20	TESTING AND ADJUSTING Troubleshooting of electrical system (E-Mode)	20-501
20	TESTING AND ADJUSTING Troubleshooting of electrical system (Error Checking of items without Monitor codes) ...	20-601
20	TESTING AND ADJUSTING Troubleshooting of hydraulic and mechanical system (H-Mode).....	20-701
30	DISASSEMBLY AND ASSEMBLY.....	30-1
90	OTHER	90-1




Blank for technical reason

00 FOREWORD

Safety

Important safety notice

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed for the purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

General precautions

Mistakes in operation are extremely dangerous. Read the OPERATION & MAINTENANCE MANUAL carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

Preparations for work

1. Before adding oil or making repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
2. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
3. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
4. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

Precautions during work

1. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
2. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned. Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
3. Before starting work, remove the leads from the battery. ALWAYS remove the lead from the negative (-) terminal first.
4. When raising heavy components, use a hoist or crane. Check that the wire rope, chains and hooks are free from damage. Always use lifting equipment which has ample capacity. Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
5. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
6. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
7. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
8. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
9. Be sure to assemble all parts again in their original places. Replace any damaged part with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
10. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also check that connecting parts are correctly installed.
11. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
12. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
13. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
14. Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

List of revised pages

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.	Mark	Indication	Action required
	○	Page to be newly added	Add
	●	Page to be replaced	Replace
	()	Page to be deleted	Discard
NOTE Pages having no marks are those previously revised or made additions.			

Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision
●	Cover	(1)		10-13			10-66			10-121			10-176	
	TOC-1			10-14			10-67			10-122			10-177	
	TOC-2			10-15			10-68			10-123			10-178	
	00-1			10-16			10-69			10-124			10-179	
	00-2		●	10-17	(1)		10-70			10-125			10-180	
○	00-2.1	(1)	○	10-17.1	(1)		10-71			10-126			10-181	
○	00-2.2	(1)	○	10-17.2	(1)		10-72			10-127			10-182	
○	00-2.3	(1)	●	10-18	(1)		10-73			10-128			10-183	
○	00-2.4	(1)		10-19			10-74			10-129			10-184	
○	00-2.5	(1)		10-20			10-75			10-130			10-185	
○	00-2.6	(1)		10-21			10-76			10-131			10-186	
	00-3			10-22			10-77			10-132			10-187	
	00-4			10-23			10-78		●	10-133	(1)		10-188	
	00-5			10-24			10-79		●	10-134	(1)		10-189	
	00-6			10-25			10-80		●	10-135	(1)		10-190	
	00-7			10-26			10-81		●	10-136	(1)		10-191	
	00-8			10-27			10-82			10-137			10-192	
	00-9			10-28			10-83			10-138			10-193	
	00-10			10-29			10-84			10-139			10-194	
	00-11			10-30			10-85			10-140			10-195	
	00-12			10-31			10-86			10-141			10-196	
	00-13			10-32			10-87			10-142			10-197	
	00-14			10-33			10-88			10-143			10-198	
	00-15			10-34			10-89			10-144			10-199	
	00-16			10-35			10-90			10-145			10-200	
	00-17			10-36			10-91			10-146			10-201	
	00-18			10-37			10-92			10-147			10-202	
				10-38			10-93			10-148			10-203	
	01-1			10-39			10-94			10-149			10-204	
	01-2			10-40			10-95			10-150			10-205	
	01-3			10-41			10-96			10-151			10-206	
	01-4			10-42			10-97			10-152			10-207	
	01-5			10-43			10-98			10-153			10-208	
	01-6			10-44			10-99			10-154			10-209	
	01-7			10-45			10-100			10-155			10-210	
	01-8			10-46			10-101			10-156			10-211	
	01-9			10-47			10-102			10-157			10-212	
	01-10			10-48			10-103			10-158			10-213	
	01-11			10-49			10-104			10-159			10-214	
	01-12			10-50			10-105			10-160			10-215	
	01-13			10-51			10-106			10-161			10-216	
	01-14			10-52			10-107			10-162			10-217	
				10-53			10-108			10-163			10-218	
●	10-1	(1)		10-54			10-109			10-164			10-219	
●	10-2	(1)		10-55			10-110			10-165			10-220	
	10-3			10-56			10-111			10-166			10-221	
	10-4			10-57			10-112			10-167			10-222	
	10-5			10-58			10-113			10-168			10-223	
	10-6			10-59			10-114			10-169			10-224	
	10-7			10-60			10-115			10-170			10-225	
	10-8			10-61			10-116			10-171			10-226	
	10-9			10-62			10-117			10-172			10-227	
	10-10			10-63			10-118			10-173			10-228	
	10-11			10-64			10-119			10-174			10-229	
	10-12			10-65			10-120			10-175			10-230	

Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision
	10-231			20-120			20-173			20-225			20-280	
	10-232			20-121			20-174			20-226			20-281	
	10-233			20-122			20-175			20-227			20-282	
	10-234			20-123			20-176			20-228			20-283	
	10-235			20-124			20-177			20-229			20-284	
	10-236			20-125			20-178			20-230				
	10-237			20-126			20-179			20-231	●	20-301	(1)	
	10-238			20-127			20-180			20-232	●	20-302	(1)	
	10-239			20-128			20-181			20-233	●	20-303	(1)	
	10-240			20-129			20-182			20-234	●	20-304	(1)	
	10-241			20-130			20-183			20-235		20-305		
	10-242			20-131			20-184			20-236		20-306		
	10-243			20-132			20-185			20-237		20-307		
	10-244			20-133			20-186			20-238		20-308		
○	10-245	(1)		20-134			20-187			20-239		20-309		
○	10-246	(1)		20-135			20-188			20-240		20-310		
○	10-247	(1)		20-136			20-189			20-241		20-311		
○	10-248	(1)		20-137			20-190			20-242		20-312		
				20-138			20-191			20-243		20-313		
	20-1			20-139			20-192			20-244		20-314		
	20-2			20-140		●	20-193	(1)		20-245		20-315		
	20-3			20-141		●	20-194	(1)		20-246		20-316		
	20-4			20-142		○	20-195	(1)		20-247		20-317		
	20-5		●	20-143	(1)	○	20-196	(1)		20-248		20-318		
	20-6		●	20-144	(1)	○	20-197	(1)		20-249		20-319		
	20-7		●	20-145	(1)	○	20-198	(1)		20-250		20-320		
	20-8		○	20-145.1	(1)	○	20-199	(1)		20-251		20-321		
	20-9		○	20-145.2	(1)	○	20-200	(1)		20-252		20-322		
	20-10		●	20-146	(1)	○	20-200.1	(1)		20-253		20-323		
	20-11			20-147		○	20-200.2	(1)		20-254		20-324		
	20-12			20-148						20-255		20-325		
	20-13			20-149			20-201			20-256		20-326		
	20-14			20-150			20-202			20-257		20-327		
	20-15			20-151			20-203			20-258		20-328		
	20-16			20-152			20-204			20-259		20-329		
				20-153			20-205			20-260		20-330		
●	20-101	(1)		20-154			20-206			20-261		20-331		
●	20-102	(1)		20-155			20-207			20-262		20-332		
	20-103			20-156			20-208			20-263		20-333		
	20-104			20-157			20-209			20-264		20-334		
	20-105			20-158			20-210			20-265		20-335		
	20-106			20-159			20-211			20-266		20-336		
	20-107			20-160			20-212			20-267		20-337		
	20-108			20-161			20-213			20-268		20-338		
	20-109			20-162			20-214			20-269		20-339		
	20-110			20-163			20-215			20-270		20-340		
	20-111			20-164			20-216			20-271		20-341		
	20-112			20-165			20-217			20-272		20-342		
	20-113			20-166			20-218			20-273		20-343		
	20-114			20-167			20-219			20-274		20-344		
	20-115			20-168			20-220			20-275		20-345		
	20-116			20-169			20-221			20-276		20-346		
	20-117			20-170			20-222			20-277		20-347		
	20-118			20-171			20-223			20-278		20-348		
	20-119			20-172			20-224			20-279	●	20-349	(1)	

Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision
●	20-350	(1)		20-405			20-448						20-605	
●	20-351	(1)		20-406			20-449			20-501			20-606	
●	20-352	(1)		20-407			20-450			20-502			20-607	
●	20-353	(1)		20-408			20-451			20-503			20-608	
●	20-354	(1)	●	20-409	(1)		20-452			20-504			20-609	
●	20-355	(1)	○	20-409.1	(1)		20-453			20-505			20-610	
●	20-356	(1)	○	20-409.2	(1)		20-454			20-506			20-611	
●	20-357	(1)	●	20-410	(1)		20-455			20-507			20-612	
●	20-358	(1)		20-411			20-456			20-508			20-613	
	20-359			20-412			20-457			20-509			20-614	
	20-360			20-413			20-458			20-510			20-615	
	20-361			20-414			20-459			20-511			20-616	
	20-362			20-415			20-460			20-512			20-617	
	20-363			20-416			20-461			20-513			20-618	
	20-364			20-417			20-462			20-514			20-619	
	20-365			20-418			20-463			20-515			20-620	
	20-366		●	20-419	(1)		20-464			20-516			20-621	
	20-367		○	20-419.1	(1)		20-465			20-517			20-622	
	20-368		○	20-419.2	(1)		20-466			20-518			20-623	
	20-369		●	20-420	(1)		20-467			20-519			20-624	
	20-370			20-421			20-468			20-520			20-625	
	20-371			20-422		●	20-469	(1)		20-521			20-626	
	20-372		●	20-423	(1)	●	20-470	(1)		20-522			20-627	
	20-373		○	20-423.1	(1)	●	20-471	(1)		20-523			20-628	
	20-374		○	20-423.2	(1)	●	20-472	(1)		20-524			20-629	
	20-375		○	20-423.3	(1)	●	20-473	(1)		20-525			20-630	
	20-376		○	20-423.4	(1)	●	20-474	(1)		20-526			20-631	
	20-377		○	20-423.5	(1)	●	20-475	(1)		20-527			20-632	
	20-378		○	20-423.6	(1)	●	20-476	(1)		20-528			20-633	
	20-379		○	20-423.7	(1)	●	20-477	(1)		20-529			20-634	
	20-380		○	20-423.8	(1)	●	20-478	(1)		20-530			20-635	
	20-381		●	20-424	(1)	●	20-479	(1)		20-531			20-636	
	20-382			20-425		●	20-480	(1)		20-532			20-637	
	20-383			20-426		●	20-481	(1)		20-533			20-638	
	20-384			20-427		●	20-482	(1)		20-534			20-639	
	20-385			20-428		●	20-483	(1)		20-535			20-640	
	20-386			20-429		●	20-484	(1)		20-536			20-641	
	20-387			20-430		●	20-485	(1)		20-537			20-642	
	20-388			20-431		○	20-485.1	(1)		20-538			20-643	
	20-389			20-432		○	20-485.2	(1)		20-539			20-644	
	20-390			20-433		○	20-485.3	(1)		20-540			20-645	
	20-391			20-434		○	20-485.4	(1)		20-541			20-646	
	20-392			20-435		○	20-485.5	(1)		20-542			20-647	
	20-393			20-436		○	20-485.6	(1)		20-543			20-648	
	20-394			20-437		●	20-486	(1)		20-544			20-649	
	20-395			20-438			20-487			20-545			20-650	
	20-396			20-439			20-488			20-546			20-651	
	20-397			20-440			20-489			20-547			20-652	
	20-398			20-441			20-490			20-548			20-653	
	20-399			20-442			20-491			20-549			20-654	
	20-400			20-443			20-492			20-550			20-655	
	20-401			20-444			20-493			20-601			20-656	
	20-402			20-445			20-494			20-602			20-657	
	20-403			20-446			20-495			20-603			20-658	
	20-404			20-447			20-496			20-604			20-659	

Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision
	20-660			20-724			30-30			30-85			30-140	
	20-661		●	20-725	(1)		30-31			30-86			30-141	
	20-662		○	20-725.1	(1)		30-32			30-87			30-142	
	20-663		○	20-725.2	(1)		30-33			30-88			30-143	
	20-664		●	20-726	(1)		30-34			30-89			30-144	
	20-665			20-727			30-35			30-90			30-145	
	20-666			20-728			30-36			30-91			30-146	
	20-667			20-729			30-37			30-92			30-147	
	20-668			20-730			30-38			30-93			30-148	
	20-669			20-731			30-39			30-94			30-149	
	20-670			20-732			30-40			30-95			30-150	
	20-671			20-733			30-41			30-96			30-151	
	20-672			20-734			30-42			30-97			30-152	
	20-673			20-735			30-43			30-98			30-153	
	20-674			20-736			30-44			30-99			30-154	
	20-675			20-737			30-45			30-100			30-155	
	20-676			20-738			30-46			30-101			30-156	
	20-677			20-739			30-47			30-102			30-157	
	20-678			20-740			30-48			30-103			30-158	
	20-679			20-741			30-49			30-104			30-159	
	20-680			20-742			30-50			30-105			30-160	
	20-681			20-743			30-51			30-106			30-161	
	20-682			20-744			30-52			30-107			30-162	
	20-683			20-745			30-53			30-108			30-163	
	20-684			20-746			30-54			30-109			30-164	
	20-685						30-55			30-110			30-165	
	20-686		●	30-1	(1)		30-56			30-111			30-166	
	20-687		●	30-2	(1)		30-57			30-112			30-167	
	20-688		●	30-3	(1)		30-58			30-113			30-168	
	20-689		●	30-4	(1)		30-59			30-114			30-169	
	20-690			30-5			30-60			30-115			30-170	
				30-6			30-61			30-116			30-171	
●	20-701	(1)		30-7			30-62			30-117			30-172	
●	20-702	(1)		30-8			30-63			30-118			30-173	
	20-703			30-9			30-64			30-119			30-174	
	20-704			30-10			30-65			30-120			30-175	
	20-705			30-11			30-66			30-121			30-176	
	20-706			30-12			30-67			30-122			30-177	
	20-707			30-13			30-68			30-123			30-178	
	20-708			30-14			30-69			30-124			30-179	
	20-709			30-15			30-70			30-125			30-180	
	20-710			30-16			30-71			30-126			30-181	
	20-711			30-17			30-72			30-127			30-182	
	20-712			30-18			30-73			30-128			30-183	
	20-713			30-19			30-74			30-129			30-184	
	20-714			30-20			30-75			30-130			30-185	
	20-715			30-21			30-76			30-131			30-186	
	20-716			30-22			30-77			30-132			30-187	
	20-717			30-23			30-78			30-133			30-188	
	20-718			30-24			30-79			30-134			30-189	
	20-719			30-25			30-80			30-135			30-190	
	20-720			30-26			30-81			30-136			30-191	
	20-721			30-27			30-82			30-137			30-192	
	20-722			30-28			30-83			30-138			30-193	
	20-723			30-29			30-84			30-139			30-194	

Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision	Mark	Page	Time of Revision
	30-195													
	30-196													
	30-197													
	30-198													
	30-199													
	30-200													
	30-201													
	30-202													
	30-203													
	30-204													
	30-205													
	30-206													
	30-207													
	30-208													
	30-209													
	30-210													
	30-211													
	30-212													
	30-213													
	30-214													
	30-215													
	30-216													
	30-217													
	30-218													
	30-219													
	30-220													
	30-221													
	30-222													
	30-223													
	30-224													
	30-225													
	30-226													
	30-227													
	30-228													
	30-229													
	30-230													
	30-231													
	30-232													
●	30-233	(1)												
●	30-234	(1)												
●	90-1	(1)												
●	90-2	(1)												
●	90-3	(1)												
●	90-5	(1)												
●	90-7	(1)												
○	90-7.1	(1)												
○	90-7.3	(1)												
○	90-7.5	(1)												
○	90-7-7	(1)												
●	90-9	(1)												
●	90-11	(1)												
●	90-13	(1)												

General

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop. For ease of understanding, the manual is divided into the following sections. These sections are further divided into each main group of components.

General

This section lists the general machine dimensions, performance specifications, component weights, and fuel, coolant and lubricant specification charts.

Structure and function

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

Testing, adjusting and troubleshooting

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs. Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

Disassembly and assembly

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

Maintenance standard

This section gives the judgement standards when inspecting disassembled parts.

NOTE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your distributor for the latest information.

How to read the shop manual

Volumes

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- **Chassis volume:**
Issued for every machine model
- **Engine volume:**
Issued for each engine series
- **Electrical volume:**
Each issued as one to cover all models
- **Attachment volume:**
Each issued as one to cover all models

These various volumes are designed to avoid duplication of information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment be available.


Distribution and updating

Any additions, amendments or other changes will be sent to your distributors. Get the most up-to-date information before you start any work.

Filing method


1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show how to read the page number.

Example 1 (Chassis volume):



3. Additional pages: Additional pages are indicated by a point (.) and number after the page number. File as in the example.

Example:



Revised edition mark

When a manual is revised, an edition mark (① ② ③...) is recorded on the bottom of the pages.

Revisions

Revised pages are shown at the LIST OF REVISED PAGES between the title page and SAFETY page.

Symbols

So that the shop manual can be of ample practical use, important safety and quality portions are marked with the following symbols:

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire or when working posture is important, etc.
	Tightening torque	Places that require special attention for tightening torque during assembly.
	Coat	Places to be coated with adhesives and lubricants etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.

Hoisting instructions

Hoisting



Heavy parts (25kg or more) must be lifted with a hoist, etc. In the DISASSEMBLY AND ASSEMBLY section, every part weighing 25 kg or more is indicated clearly with the symbol:



If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:

1. Check for removal of all bolts fastening the part to the relative parts.
2. Check for existence of another part causing interface with the part to be removed.


Wire Ropes

3. Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)		
Rope diameter	Allowable load	
	mm	kN / tons
10	9.8	1.0
11.2	13.7	1.4
12.5	15.7	1.6
14	21.6	2.2
16	27.5	2.8
18	35.3	3.6
20	43.1	4.4
22.4	54.9	5.6
30	98.1	10.0
40	176.5	18.0
50	274.6	28.0
60	392.2	40.0

The allowable load value is estimated to be 1/6 or 1/7 of the breaking strength of the rope used.

4. Sling wire ropes from the middle portion of the hook. Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion




5. Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load



Slings with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident

6. Do not sling a heavy load with ropes forming a wide hanging angle from the hook. When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles. When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subject to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.



Coating materials

The recommended coating materials prescribed in the shop manuals are listed below.



Category	Code	Part No.	Quantity	Container	Main applications, features
Adhesives	LT-1A	790-129-9030	150 g	Tube	<ul style="list-style-type: none"> Used to prevent rubber gaskets, rubber cushions and cork plugs from coming out
	LT-1B	790-129-9050	20 g (2 pes.)	Polyethylene container	<ul style="list-style-type: none"> Used in places requiring an immediately effective, strong adhesive. Used for plastics (except polyethylene, polypropylene, tetrafluoroethylene, and vinyl chloride), rubber, metal and non-metal.
	LT-2	09940-00030	50 g	Polyethylene container	<ul style="list-style-type: none"> Features: Resistance to heat, chemicals Used for anti-loosening and sealant purposes for bolts and plugs.
	LT-3	790-129-9060 (Set of adhesive and hardening agent)	Adhesive: 1 kg Hardening agent: 500 g	Can	<ul style="list-style-type: none"> Used as adhesive or sealant for metal, glass or plastic.
	LT-4	790-129-9040	250 g	Polyethylene container	<ul style="list-style-type: none"> Used as sealant for machined holes.
	Holtz MH 705	790-126-9120	75 g	Tube	<ul style="list-style-type: none"> Used as heat-resisting sealant for repairing engine.
	Three bond 1735	179-129-9140	50 g	Polyethylene container	<ul style="list-style-type: none"> Quick hardening type adhesive. Cure time: within 5 sec. to 3 min. Used mainly for adhesion of metals, rubbers, plastics and woods.
	Aron-alpha 201	790-129-9130	2 g	Polyethylene container	<ul style="list-style-type: none"> Quick hardening type adhesive. Quick cure type (max. strength after 30 minutes). Used mainly for adhesion of rubbers, plastics and metals.
	Loctite 648-50	79A-129-9110	50 cc	Polyethylene container	<ul style="list-style-type: none"> Features: Resistance to heat, chemicals Used at joint portions subject to high temperature.
Gasket sealant	LG-1	790-129-9010	200 g	Tube	<ul style="list-style-type: none"> Used as adhesive or sealant for gaskets and packing of power train case, etc.
	LG-3	790-129-9070	1 kg	Can	<ul style="list-style-type: none"> Features: Resistance to heat Used as sealant for flange surfaces and bolts at high temperature locations; used to prevent seizure. Used as sealant for heat resistant gasket for at high temperature locations such as engine pre-combustion chamber, exhaust pipe.


Category	Code	Part No.	Quantity	Container	Main applications, features
Gasket sealant	LG-4	790-129-9020	200 g	Tube	<ul style="list-style-type: none"> • Features: Resistance to water, oil • Used as sealant for flange surface, thread. • Also possible to use as sealant for flanges with large clearance. • Used as sealant for mating surfaces of final drive case, transmission case.
	LG-5	790-129-9080	1 kg	Polyethylene container	<ul style="list-style-type: none"> • Used as sealant for various threads, pipe joints, flanges. • Used as sealant for tapered plugs, elbows, nipples of hydraulic piping.
	LG-6	09940-00011	250 g	Tube	<ul style="list-style-type: none"> • Features: Silicon based, resistant to heat, cold. • Used as sealant for flange surface, thread. • Used as sealant for oil pan, final drive case, etc.
	LG-7	09920-00150	150 g	Tube	<ul style="list-style-type: none"> • Features: Silicon based, quick hardening type. • Used as sealant for flywheel housing, intake manifold, oil pan, thermostat housing, etc.
	Three bond 1211	790-129-9090	100 g	Tube	<ul style="list-style-type: none"> • Used as heat-resisting sealant for repairing engines.
Molybdenum disulphide lubricant	LM-G	09940-00051	60 g	Can	<ul style="list-style-type: none"> • Used as lubricant for sliding parts (to prevent squeaking).
	LM-P	09940-00040	200 g	Tube	<ul style="list-style-type: none"> • Used to prevent seizure or scuffing of the thread when press fitting or shrink fitting. • Used as lubricant for linkage, bearings, etc.
Grease	G2-LI	SYG2-400LI SYG2-350LI SYG2-400LI-A SYG2-160LI SYGA160CNLI	Various	Various	<ul style="list-style-type: none"> • General purpose type
	G2-CA	SYG2-400CA SYG2-350CA SYG2-400CA-A SYG2-160CA SYG2-160CNCA	Various	Various	<ul style="list-style-type: none"> • Used for normal temperature, light load bearing at places in contact with water or steam.
	Molybdenum disulphide lubricant	SYG2-400M	400 g (10 per case)	Belows type	<ul style="list-style-type: none"> • Used for places with heavy load.

Standard tightening torque

Standard tightening torque of bolts and nuts

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in DISASSEMBLY AND ASSEMBLY.

Thread diameter of bolt	Width across flats		
		Nm	kgm
6	10	13.2 ± 1.4	1.35 ± 0.15
8	13	31.4 ± 2.9	3.20 ± 0.3
10	17	65.7 ± 6.8	6.70 ± 0.7
12	19	112 ± 9.8	11.5 ± 1.0
14	22	177 ± 19	18 ± 2.0
16	24	279 ± 29	28.5 ± 3
18	27	383 ± 39	39 ± 4
20	30	549 ± 58	56 ± 6
22	32	745 ± 78	76 ± 8
24	36	927 ± 98	94.5 ± 10
27	41	1320 ± 140	135 ± 15
30	46	1720 ± 190	175 ± 20
33	50	2210 ± 240	225 ± 25
36	55	2750 ± 290	280 ± 30
39	60	3280 ± 340	335 ± 35

Thread diameter of bolt	Width across flats	 CDL00373	
		Nm	kgm
6	10	7.85 ± 1.95	0.8 ± 0.2
8	13	18.6 ± 4.9	1.9 ± 0.5
10	14	40.2 ± 5.9	4.1 ± 0.6
12	27	82.35 ± 7.85	8.4 ± 0.8

Tightening torque of hose nuts

Use these torques for hose nuts.

Nominal No.	Thread diameter	Width across flat	Tightening torque	
	mm	mm	Nm	kgm
02	14	19	24.5 ± 4.9	2.5 ± 0.5
03	18	24	49 ± 19.6	5 ± 2
04	22	27	78.5 ± 19.6	8 ± 2
05	24	32	137.3 ± 29.4	14 ± 3
06	30	36	176.5 ± 29.4	18 ± 3
10	33	41	196.1 ± 49	20 ± 5
12	36	46	245.2 ± 49	25 ± 5
14	42	55	294.2 ± 49	30 ± 5

Tightening torque of split flange bolts

Use these torques for split flange bolts.

Thread diameter	Width across flat	Tightening torque	
mm	mm	Nm	kgm
10	14	65.7 ± 6.8	6.7 ± 0.7
12	17	112 ± 9.8	11.5 ± 1
16	22	279 ± 29	28.5 ± 3

Tightening torques for hoses (taper seal type and face seal type)

- Unless there are special instructions, tighten the hoses (taper the hoses (taper seal type and face seal type) to the torque below.
- Apply the following torque when the threads are coated (wet) with engine oil.

Nominal No. of hose	Width across flat	Tightening torque Nm {kgm}		Taper seal Thread size (mm)	Face seal	
		Range	Target		Nominal No. - Number of threads, type of thread	Thread diameter (mm) (Referenced)
02	19	34 - 54 {3.5 - 5.5}	44 {4.5}	-	9/16 - 18UN	14.3
		34 - 63 {3.5 - 6.5}		14	-	-
03	22	54 - 93 {5.5 - 9.5}	74 {7.5}	-	11/16 - 16UN	17.5
	24	59 - 98 {6.0 - 10.0}	78 {8.0}	18	-	-
04	27	84 - 132 {8.5 - 13.5}	103 {10.5}	22	13/16 - 16UN	20.6
05	32	128 - 186 {13.0 - 19.0}	157 {16.0}	24	1 - 14UNS	25.4
06	36	177 - 245 {18.0 - 25.0}	216 {22.0}	30	1 - 3/16 - 12UN	30.2
(10)	41	177 - 245 {18.0 - 25.0}	216 {22.0}	33	-	-
(12)	46	197 - 294 {20.0 - 30.0}	245 {25.0}	36	-	-
(14)	55	246 - 343 {25.0 - 35.0}	294 {30.0}	42	-	-

Tightening torque for 107 engine series (bolts and nuts)

- Unless there are special instructions, tighten the metric bolts and nuts of the 107 engine series to the torque below.

Thread diameter	Tightening torque			
	mm	Nm	kgm	Nm
6	10 ± 2	1.02 ± 0.20	8 ± 2	0.81 ± 0.20
8	24 ± 4	2.45 ± 0.41	10 ± 2	1.02 ± 0.20
10	43 ± 6	4.38 ± 0.61	12 ± 2	1.22 ± 0.20
12	77 ± 12	7.85 ± 1.22	24 ± 2	2.45 ± 0.41
14	-	-	36 ± 5	3.67 ± 0.51

Tightening torque for 107 engine series (eye joints)

Use these torque values for eye joints (unit: mm).

Thread diameter	Tightening torque	
	Nm	kgm
6	8 ± 2	0.81 ± 0.20
8	10 ± 2	1.02 ± 0.20
10	12 ± 2	1.22 ± 0.20
12	24 ± 4	2.45 ± 0.41
14	36 ± 5	3.67 ± 0.51

Tightening torque for 107 engine series (tapered screws)

Use these torque values for tapered screws (unit: inch).

Thread diameter	Tightening torque	
	Nm	kgm
1/16	3 ± 1	0.31 ± 0.10
1/8	8 ± 2	0.81 ± 0.20
1/4	12 ± 2	1.22 ± 0.20
3/8	15 ± 2	1.53 ± 0.41
1/2	24 ± 4	2.45 ± 0.41
3/4	36 ± 5	3.67 ± 0.51
1	60 ± 9	6.12 ± 0.92