



ENGINE REPAIR MANUAL

667TA/EEG

667TA/EEC

667TA/EBF

667TA/EED

667TA/EBJ

667TA/EDJ

Issued 11-2006

Book/Form Number 87519804 NA

Copyright © 2006. CNH America LLC. All Rights Reserved.

Printed in U.S.A. • Bur

Source Code No. unknown

ENGINE REPAIR MANUAL

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History			
Issue	Issue Date	Applicable Machine	Remarks
First Edition	11-2006	667TA/EEG 667TA/EEC 667TA/EBF 667TA/EED 667TA/EBJ 667TA/EDJ	87519804 NA

ENGINE REPAIR MANUAL**TABLE OF CONTENTS**

CHAPTER 1

DIAGNOSTICS

TABLE OF CONTENTS	1-1
CNH- EST DIAGNOSTIC TOOL	1-3
TROUBLESHOOTING	1-4

CHAPTER 2

667TA ENGINE OVERHAUL

TABLE OF CONTENTS	2-1
ENGINES	2-5
CODING OF SOURCE ENGINES	2-6
ENGINE PROPERTIES	2-6
GENERAL ENGINE FEATURES	2-7
CRANK GEAR COMPONENTS AND CYLINDER ASSEMBLY	2-9
VALVE GEAR - CYLINDER ASSEMBLY	2-12
TORQUE SPECIFICATIONS	2-14
SPECIAL TOOLS	2-16
667TA ENGINES	2-17
DESCRIPTION OF MAIN ENGINE COMPONENTS	2-18
EGR EXHAUST GAS RECIRCULATION SYSTEM	2-22
ENGINE LUBRICATION	2-30
ENGINE COOLING	2-35
HIGH PRESSURE ELECTRONIC INJECTION SYSTEM (COMMON RAIL)	2-37
EDC7UC31 -ELECTRONIC CONTROL UNIT OPERATION	2-38
FUEL SUPPLY SYSTEM	2-40
COMMON RAIL	2-50
COMMON RAIL PRESSURE RELIEF VALVE	2-51
ELECTRO-INJECTOR	2-52
LOCATION OF THE MAIN ELECTRICAL COMPONENTS	2-55
CHECKING THE FUEL SYSTEM	2-67
ENGINE OVERHAUL ON THE BENCH	2-72
CHECKS AND SPECIFICATIONS ON ENGINE CRANKCASE	2-82
CRANKSHAFT	2-87
ENGINE FLYWHEEL	2-102
CYLINDER HEAD	2-107
VALVES	2-108
VALVE GUIDE	2-109
VALVE SEATS	2-110
VALVE SPRINGS	2-112
CYLINDER HEAD	2-112
RODS AND TAPPETS	2-115
CHAPTER 3	
CHARGING AND START-UP	
TABLE OF CONTENTS	3-1
STARTER MOTOR	3-3
ALTERNATOR	3-6

NOTES

CHAPTER 1

667TA

TIER III

DIAGNOSTICS

ENGINE REPAIR MANUAL
CHAPTER 1 - DIAGNOSTICS

CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

Revision History			
Issue	Issue Date	Applicable Machines	Remarks
First Edition	11-2006	667TA/EEG 667TA/EEC 667TA/EBF 667TA/EED 667TA/EBJ 667TA/EDJ	87519804 NA

CHAPTER 1
DIAGNOSTICS
TABLE OF CONTENTS

CNH- EST DIAGNOSTIC TOOL 1-3

TROUBLESHOOTING 1-4

 Engine Won't Start 1-4

 Engine Overheats 1-5

 Engine Lacks Power And Runs Erratically 1-6

 Engine Exhaust Smoke Black Or Dark Grey 1-7

 Engine Exhaust Smoke Grey (Verging On White) 1-7

 Engine Exhaust Smoke Light Blue 1-7

 Engine Knocks Irregularly 1-8


 Engine Stops 1-9

 Excessive Or Insufficient Oil Pressure 1-9

 Excessive Fuel Consumption 1-9

NOTES

CNH- EST DIAGNOSTIC TOOL



BS06K009

Figure 1-1

The EST system allows diagnoses on machines by detecting the operating parameters of electronic control components (control units, sensors etc.) and check flow rates, pressures and temperatures. It is also capable of reading fault codes on the engine. To help with troubleshooting the engine failure mode.

TROUBLESHOOTING

ENGINE WON'T START

