

# Chrysler Reference Booklet Servicing Ignition Systems

Full download: <http://manualplace.com/download/chrysler-reference-booklet>

**SERVICE REFERENCE BOOK**

# IGNITION SYSTEM SERVICING



*Prepared by*  
**CHRYSLER CORPORATION**  
PLYMOUTH, DODGE, DE SOTO  
AND CHRYSLER DIVISIONS  
Vol. 3                      No. 12

Copyright 1950  
Chrysler Corporation


This is the cut pages sample. Download all 36 page(s) at: [ManualPlace.com](http://ManualPlace.com)



<b>INTRODUCTION</b>	<b>PAGE</b>
Requirements of Good Engine Performance .....	3
High Compression Engines .....	5
<b>IGNITION SYSTEM IMPROVEMENTS</b>	
Coil .....	7
Resistor-Type Spark Plugs .....	8
Spark Plug Heat Range .....	10
<b>CLUES TO SPARK PLUG PERFORMANCE</b>	
Appearance .....	12
<b>SERVICING SPARK PLUGS</b>	
Cleaning .....	14
Adjusting .....	16
Testing .....	17
<b>IGNITION SYSTEM SERVICE</b>	
Battery .....	20
Open Circuit Voltage Tester .....	21
Voltage Drop Test of Primary Circuit .....	22
Checking the Coil .....	26
Checking the Distributor .....	27
Checking High Tension Wire Terminals .....	30
<b>CHECKING IGNITION TIMING</b> .....	32
<b>ROAD TEST</b> .....	34
<b>QUESTIONS</b> .....	35

# TECH SEZ:

## DON'T JUMP TO CONCLUSIONS!



It takes many things, all put together, to give good engine performance. So, when you tackle a job of restoring an engine to proper operating condition, you'll be off to a good start if you remember that engine performance depends upon:

- good compression
- proper carburetion, and . . .
- good ignition.

Now, nobody needs to tell you that jumping to conclusions will only waste your time. That's because poor performance is hardly ever caused by only one particular condition. It's almost always caused by a combination of a lot of little things that finally add up enough to remind the owner that he ought to have his car looked at.

Therefore, when engine efficiency is off, something in compression, carburetion or ignition is out of order. So, first find out how far away from standard the engine performance is. That means checking existing conditions to find just what factors are off. Next, track down each possible cause of the below-standard condition.