



A TEREX BRAND

Parts Manual

Serial Number Range

GS-1530

from SN GS3010A-110000

GS-1532

from SN GS3011C-10000

GS-1930

GS-1932

Part No. 229145

Rev B3

April 2012

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:

<http://www.genielift.com>
 e-mail: awp.techpub@terex.com

Serial Number Information


Genie Industries offers the following Parts Manuals for these models:

| Title | Part No |
|---|---------|
| Genie GS-1530, GS-1532, GS-1930 and GS-1932 Parts Manual (to serial number 59999)..... | 39529 |
| Genie GS-1530, GS-1532, GS-1930 and GS-1932 Parts Manual (from serial number 60000 to 75999)..... | 96315 |
| Genie GS-1530, GS-1532, GS-1930 and GS-1932 Parts Manual (from serial number 76000 to 99999)..... | 97384 |

Copyright © 2011 by Terex Corporation

229145 Rev A June 2011
 Fourth Edition, First Printing

"Genie" and "GS" are registered trademarks of Teres South Dakota Inc. in the USA and many other countries.

 Printed on recycled paper



Model: GS-1930
Serial number: GS3011A-100100
Model year: 2005 Manufacture date: 08/12/11
Electrical schematic number: ES0141
Machine unladen weight: 2,714 lb / 1,231 N

Rated work load (including occupants): 500 lb / 227 kg

Maximum allowable inclination of the chassis:
N/A

Gradeability: N/A

Maximum allowable side force : 100 lb / 445 N
Maximum number of platform occupants:2

Country of manufacture: USA
This machine complies with:

ANSI A92.6
B354.2-01

Genie Industries
18340 NE 76th Street
Redmond, WA 98052
USA



11 000111



GS30 11 A - 100100

Model

Model year

Sequence number

Facility code
(used only for model manufactured in multiple facilities)



Serial number
(stamped on chassis)

Serial label

Serial number
(stamped on chassis)




Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number.....3
 Parts Stocking List.....7
 How to Order Parts.....8
 Service Parts Fax Order Form.....9

Electronic Version
 Click on any page number to view the figure.

100 Decals

101.1 Decals with Words, GS-1530, Battery Side, ANSI & Australia.....10
 102.1 Decals with Words, GS-1530, Ground Controls Side, ANSI & Australia.....12
 103.1 Decals with Words, GS-1530, Platform, ANSI.....14
 104.1 Decals with Words, GS-1530, Platform, Australia.....16
 105.1 Decals with Symbols, GS-1530 Battery Side, ANSI & CE.....18
 106.1 Decals with Symbols, GS-1530 Ground Control Side, ANSI & CE.....20
 107.1 Decals with Symbols, GS-1530 Platform, ANSI.....22
 108.1 Decals with Symbols, GS-1530 Platform, CE.....24
 109.1 Decals with Words, GS-1532, Battery Side, Australia.....26
 110.1 Decals with Words, GS-1532 Ground Controls Side, Australia.....28
 111.1 Decals with Words, GS-1532 Platform, Australia.....30
 112.1 Decals with Symbols, GS-1532 Battery Side, CE.....32
 113.1 Decals with Symbols, GS-1532 Ground Control Side, CE.....34
 114.1 Decals with Symbols, GS-1532 Platform, CE.....36
 115.1 Decals with Words, GS-1930 Battery Side, ANSI & Australia.....38
 116.1 Decals with Words, GS-1930 Ground Controls Side, ANSI & Australia.....40
 117.1 Decals with Words, GS-1930 Platform, ANSI.....42
 118.1 Decals with Words, GS-1930 Platform, Australia.....44
 119.1 Decals with Symbols, GS-1930 Battery Side, ANSI & CE.....46
 120.1 Decals with Symbols, GS-1930 Ground Control Side, ANSI & CE.....48

121.1 Decals with Symbols, GS-1930 Platform ANSI.....50
 122.1 Decals with Symbols, GS-1930 Platform CE.....52
 123.1 Decals with Words, GS-1932 Battery Side, Australia.....54
 124.1 Decals with Words, GS-1932 Ground Controls Side, Australia.....56
 125.1 Decals with Words, GS-1932 Platform, Australia.....58
 126.1 Decals with Symbols, GS-1932 Battery Side, CE.....60
 127.1 Decals with Symbols, GS-1932 Ground Control Side, CE.....62
 128.1 Decals with Symbols, GS-1932 Platform CE.....64

200 Drive Chassis Components

201.1 Steer Linkage and Wheels, GS-1530/1532/1930/1932.....66
 202.1 Non-steer Axle Installation, All Models.....68
 203.1 Level Sensor Installation, All Models.....70
 204.1 Pothole Protection Assembly, GS-1530/1532/1930/1932.....72
 205.1 Battery Pack Module.....74
 206.1 Battery Charger.....76
 207.1 Power Unit Module.....78
 208.1 Ground Controls, All Models.....80
 209.1 Electrical Wiring.....82
 210.1 Power Cables.....84
 211.1 Function Manifold and Accumulator Components, GS-1530/1532/1930/1932.....86

300 Scissor Components

301.1 Scissor Assembly Installation.....88
 302.1 Scissor Assembly, GS-1530/1532.....90
 303.1 Scissor Assembly, GS-1930/1932.....92

400 Platform Components

401.1 Platform Components, GS-1530.....94
 402.1 Platform Components, GS-1532.....98
 403.1 Platform Components, GS-1930.....102
 404.1 Platform Components, GS-1932.....106
 405.1 Platform Gates, GS-1530/1532/1930/1932.....110
 406.1 Power to Platform.....114
 407.1 Platform Controls.....116
 408.1 Joystick Controller.....118

500 Hydraulic Components

501.1 Hydraulic Components.....120
 502.1 Function Manifold, GS-1530, GS-1532, GS-1930, GS-1932.....122
 503.1 Check Valve Manifold, GS-1530, GS-1532, GS-1930, GS-1932.....124
 504.1 Brake Release Hand Pump Manifold.....126

505.1 Hydraulic Power Unit, All Models.....128
 506.1 Lift Cylinder Assembly, All Models.....130
 507.1 Hydraulic Hoses and Fittings, GS-1530, GS-1532,
 GS-1930, GS-1932.....132

600 Accessories

601.1 Alarm, Horn and Flashing Beacons.....134
 602.1 Air Line to Platform.....136
 603.1 Platform Work Light.....138
 604.1 Voltage Inverter, GS-1530, GS-1532, GS-1930,
 GS-1932.....140

700 Platform Overload Components

701.1 Platform Overload, GS-1530, GS-1532, GS-1930,
 GS-1932.....142

Indices

Part Number Index.....144
 Part Description Index.....147

Cross References

Fittings Cross Reference.....152

Required Parts

The following parts are required to perform maintenance procedures as outlined in the Genie GS-30 Service Manual.

| Description | Part No. |
|--|----------|
| Filter Element, 10 Micron..... | 44788 |
| Dielectric Grease..... | 66399 |
| Chevron Ultra-duty Grease (Lithium) or equivalent, EP NLGI 1.....(source locally) | 78546 |
| Breather Cap, Hydraulic Tank..... | 78546 |
| Cotter Pin, Castle Nut, Steer-end Wheels, GS-30 and Non-steer end Wheels, All Models | 42079 |

Recommended Parts

| Description | Part No. |
|--|----------|
| Genie Blue Paint, 1 Gallon | 32150 |
| Genie Blue Paint, 12 Ounce Aerosol..... | 1484 |
| Genie Gray Paint, 1 Gallon..... | 32151 |
| Genie Gray Paint, 12 Ounce Aerosol | 1268 |

Manuals

Genie Industries offers the following support documents for these models:

| Title | Part No. |
|---|----------|
| Genie GS-1530, GS-1930 Operator's Manual, 6th Edition, ANSI Models (from serial number GS3010A-110000 and GS3011C-10000)..... | T107026 |
| Genie GS-1530, GS-1532, GS-1930 and GS-1932 Operator's Manual, 7th Edition, CE Models (from serial number GS3010A-110000 and GS3011C-10000)..... | T107027 |
| Genie GS-1530, GS-1532, GS-1930 and GS-1932 Operator's Manual, 7th Edition, Australia Models (from serial number GS3010A-110000 and GS3011C-10000)..... | T107028 |
| Genie GS-30 Service Manual, 5th Edition..... | 228901 |
| EMI Safety Manual..... | 27581 |

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Terex or Genie product:

- Machine model number
- Machine serial number
- Part number
- Part description and quantity
- Purchase order number
- "Ship to" address
- Desired method of shipment
- Name and telephone number of the authorized distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Terex or Genie Industries.

Machine Information

Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number

North America

Telephone (425) 556-6551
 Toll Free (877) 367-5606 in U.S.A. and Canada
 Fax (425) 556-8659
 Toll Free Fax (888) 274-6192

Europe

Parts Telephone (31) (165) 519 313
 Parts Fax (31) (165) 511 148

Australia

Parts Telephone (61) (7) 3456 4444
 Parts Fax (61) (7) 3456 4466

South America

Parts Telephone (55) (11) 4082 5600
 Parts Fax (55) (11) 4082 5630

101.1 Decals with Words, GS-1530, Battery Side, ANSI & Australia

Battery Side

NOTE:
Part numbers with "(FR)" indicates French translation is available

