

H59140

-UN-30JUL99



JOHN DEERE 914P' BELT PICKUP WITH PLATFORM

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

SERIAL NUMBER PLATE

USE ALL NUMBERS, LETTERS, AND SPACES SHOWN ON THE SERIAL NUMBER PLATE IN WARRANTY CORRESPONDENCE.

PICKUP PLATFORM (625001-)

ON THESE PLATFORMS, THE SERIAL NUMBER PLATE IS LOCATED ON THE LEFT-HAND SIDE OF THE FRAME.

EXAMPLE:
PICKUP PLATFORM

(FIRST LINE) H0 - FACTORY (HARVESTER WORKS)
 0912 - PLATFORM MODEL
 X - CONFIGURATION/MODEL SUFFIX
 625001 - PLATFORM SEQUENCE NUMBER (SERIAL NUMBER)
(SECOND LINE) PICKUP PLATFORM - PRODUCT TYPE

NOTE: BELT PICKUPS DO NOT HAVE SERIAL NUMBERS. CHANGES TO BELT PICKUPS ARE SHOWN BY YEARS.

IMPORTANT

THIS PARTS CATALOG CONTAINS COMPLETE PARTS INFORMATION ON THE THREE-ROLLER BELT AND PICKUP PLATFORM. IT IS IMPORTANT THAT THE CORRECT SERIAL NUMBER BE USED WHEN ORDERING PARTS.

SERIAL NUMBER LISTING INFORMATION

SERIAL NUMBER INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED, FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
-000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

*COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS
ALL RIGHTS RESERVED*

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION CAN BE FOUND IMMEDIATELY AFTER THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™
DIAL-A-MATIC™
HARVESTRAK™

POSI-TORQ™
TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE L. H. MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 05 - GENERAL INFORMATION

SECTION 10 - ROLLERS AND SUPPORTS

SECTION 15 - FRAME, STRIPPERS, DIVIDERS AND PLATES

SECTION 20 - HEADER HEIGHT CONTROL

SECTION 25 - AUGER AND DRIVE

SECTION 30 - HYDRAULICS

SECTION 35 - IDLERS, TIGHTENERS AND SHIELDS

SECTION 40 - BELTS, CHAINS, SHEAVES, SPROCKETS AND DECALS

SECTION 45 - NUMERICAL INDEX

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
A			E		
B17	ADAPTOR, BACK SHAFT - NEW HEADS TO OLD LEVEL LAND COMBINES.....	25 - 10	B8	EXTENSIONS, FLIGHT, AUGER	25 - 1
A23	ADAPTOR, DIAL-A-MATIC (CONVERSION TO 16- PIN CONNECTOR)	20 - 2	F		
A10	ARMS, FINGER HOLD-DOWN	10 - 2	B13	FINGERS, AUGER.....	25 - 6
B10	AUGER ADJUSTMENT BRACKETS.....	25 - 3	A10	FINGERS, HOLD-DOWN.....	10 - 2
B11	AUGER AND SHAFT.....	25 - 4	A15	FLAP, STRIPPER (132" BELT PICKUP)	15 - 1
B13	AUGER BEARINGS.....	25 - 6	A16	FLAP, STRIPPER (154" BELT PICKUP)	15 - 2
B11	AUGER COVER.....	25 - 4	B8	FLIGHT, AUGER, EXTENSIONS	25 - 1
B13	AUGER CRANK.....	25 - 6	B9	FLIGHT, WINDROW SPREADER	25 - 2
B13	AUGER FINGERS	25 - 6	A12	FRAME, IDLER ROLLERS	10 - 4
B8	AUGER FLIGHT EXTENSIONS	25 - 1	A18	FRAME, MAIN AND RUNNERS	15 - 4
B11	AUGER HUB	25 - 4	G		
B13	AUGER SHAFTS	25 - 6	A9	GAUGE WHEELS	10 - 1
B3	AUTO BELT SPEED	20 - 6	A20	GRAIN SLIDE.....	15 - 6
A22	AUTOMATIC HEIGHT CONTROL SENSOR, LINKAGE AND HANGER.....	20 - 1	B9	GUSSETT, WINDROW SPREADER.....	25 - 2
B			H		
B17	BACK SHAFT ADAPTOR - NEW HEADS TO OLD LEVEL LAND COMBINES.....	25 - 10	A22	HANGER, AUTOMATIC HEIGHT CONTROL.....	20 - 1
A20	BACK SHEETS	15 - 6	A24	HEADER HEIGHT CONTROL SHAFT, BEARINGS AND BRACKETS (685056-)	20 - 3
B15	BACKSHAFT	25 - 8	B1	HEADER HEIGHT CONTROL WIRING HARNESS	20 - 4
B13	BEARINGS, AUGER	25 - 6	A10	HOLD-DOWN FINGERS	10 - 2
A24	BEARINGS, HEADER HEIGHT CONTROL (685056-)	20 - 3	B22	HOSES, HYDRAULIC	30 - 2
A13	BEARINGS,CENTER AND IDLER ROLLERS DRIVE	10 - 5	A13	HOUSINGS, BEARINGS, IDLER DRIVE ROLLER.....	10 - 5
B3	BELT SPEED, AUTO.....	20 - 6	B11	HUB, AUGER	25 - 4
A17	BELTS AND FINGERS	15 - 3	B21	HYDRAULIC LINES AND BRACKET	30 - 1
A20	BOTTOM SHEET	15 - 6	B22	HYDRAULIC LINES AND HOSES	30 - 2
B21	BRACKET, HYDRAULIC LINES	30 - 1	B24	HYDRAULIC MOTOR COUPLER	30 - 4
B24	BRACKET, HYDRAULIC MOTOR.....	30 - 4	B24	HYDRAULIC MOTOR MOUNTING BRACKET.....	30 - 4
B10	BRACKETS, AUGER ADJUSTMENT	25 - 3	I		
A24	BRACKETS, HEADER HEIGHT CONTROL (685056-)	20 - 3	A12	IDLER ROLLERS.....	10 - 4
C			L		
B19	CABLE, STORAGE, POWER SHAFT.....	25 - 12	B5	LIGHTS, MARKER	20 - 8
A12	CENTER DRIVE.....	10 - 4	B6	LIGHTS, STUBBLE	20 - 9
C4	CHAIN, DRIVE, ON R.H. SIDE	40 - 1	B21	LINES, HYDRAULIC	30 - 1
B21	COUPLER, BRACKET, HYDRAULIC LINES	30 - 1	B22	LINES, HYDRAULIC	30 - 2
B24	COUPLER, HYDRAULIC MOTOR.....	30 - 4	A22	LINKAGE, AUTOMATIC HEIGHT CONTROL.....	20 - 1
B11	COVER, AUGER	25 - 4	M		
B13	CRANK, AUGER	25 - 6	B18	MAIN DRIVE SHAFT	25 - 11
D			A18	MAIN FRAME AND RUNNERS.....	15 - 4
C5	DECALS (685151-)	40 - 2	B5	MARKER LIGHTS	20 - 8
A23	DIAL-A-MATIC SENSING BOX (FOR CONVERSION TO 16-PIN CONNECTOR)	20 - 2	B24	MOTOR, COUPLER.....	30 - 4
B1	DIAL-A-MATIC WIRING HARNESS	20 - 4	B24	MOTOR, MOUNTING BRACKET	30 - 4
B1	DIAL-A-MATIC, HEADER HEIGHT CONTROL.....	20 - 4	B23	MOTOR, REEL (EATON).....	30 - 3
B1	DIAL-A-SPEED CONTROL	20 - 4	A23	MOUNTING, SENSING BOX, DIAL-A-MATIC (FOR CONVERSION TO 16-PIN CONNECTOR).....	20 - 2
C4	DRIVE CHAIN ON RIGHT-HAND SIDE	40 - 1			
B18	DRIVE SHAFT, MAIN	25 - 11			
A12	DRIVE, CENTER	10 - 4			