



Sprinter

Maintenance Booklet



Mercedes-Benz

Thank you for choosing the new Sprinter

We hope you enjoy your Sprinter. Vehicle safety and operational reliability are two very important factors. To maintain them, regular maintenance services are necessary.

We continuously strive to improve our product and ask for your understanding that we reserve the right to make changes in the periodic maintenance work for our vehicles.

The information in this booklet is accurate as of the press date. At the time of your scheduled maintenance appointments with your authorized Sprinter dealer, your vehicle will be serviced in accordance with the most up-to-date version of the maintenance work information corresponding to your vehicle's age or mileage. Please check with your authorized Sprinter dealer for any changes to the periodic maintenance work required for your vehicle.

PLEASE NOTE

WE STRONGLY RECOMMEND THAT YOU HAVE YOUR VEHICLE SERVICED BY AN AUTHORIZED SPRINTER DEALER WHO IS FULLY EQUIPPED TO PROVIDE THIS SERVICE AND THAT GENUINE MERCEDES-BENZ PARTS BE USED.

EMISSION CONTROL COMPONENTS AND SYSTEMS CAN BE MAINTAINED, REPLACED, OR REPAIRED BY ANY AUTOMOBILE REPAIR WORKSHOP OR INDIVIDUAL USING CERTIFIED PARTS.

THE USE OF DEFECTIVE OR NON-EQUIVALENT PARTS CAN RESULT IN YOUR EMISSIONS PERFORMANCE WARRANTY CLAIM BEING DENIED.

Symbols

The following symbols are used in this Maintenance Booklet:

- ⚠ Highlights hazards that may result in damage to your vehicle.
- ℹ Helpful tips or other useful information.
- ▷ Page This symbol informs you where you can find further information on a topic.
- ▷▷ This continuation symbol indicates that a warning or procedure is continued on the next page.

Vehicle distributor/Vehicle warrantor/Parts distributor

Mercedes-Benz USA LLC

One Mercedes Drive

Montvale, NJ 07645-0350

Customer Assistance Center:

1-877-762-8267

Mercedes-Benz USA LLC is a Daimler company

General information	2
Vehicle data	2
Protecting the environment	2
<hr/>	
Maintenance Booklet	4
Introduction	4
Active Service System (ASSYST)	4
Tire rotation	5
Arduous operating conditions	5
Wear items	6
Approved engine oils and filters	6
Regular checks	6
Notes on the warranty	7
Service records	7
Parts/operating materials	7
Emission system maintenance	8
Emission control system caution - diesel engines	8
BlueEFFICIENCY® exhaust gas aftertreatment using DEF	8
Description of emission system maintenance jobs	8
Changing the engine oil and filter	9
Replacing the air filter	9
Replacing the fuel filter	9
Checking the diesel particle filter	9
Emptying and refilling DEF	9
Maintenance service descriptions	9
Vehicle maintenance service work (including emission system maintenance)	9
Maintenance service descriptions ...	10
Additional work	12
Confirmations	12
Tire rotation	12
Delivery inspection	15
Maintenance service confirmations	16

Vehicle data

▶	▶
Model	Vehicle identification number (VIN)
▶	▶
Date of the first registration	Paint and code
▶	▶
License plate	License plate
▶	▶
License plate	License plate
▶	▶
License plate	License plate
▶	▶
License plate	License plate

Protecting the environment

Natural resources form the basis of our existence on this planet. The objectives of our policy are for these resources to be used sparingly and in a manner which takes the requirements of both nature and humanity into account.

Our declared policy is integrated environmental protection. This policy starts at the root causes and encompasses in its management decisions all the consequences for the environment which could arise from production processes or the products themselves.

You too can help to protect the environment by operating your Sprinter in an environmentally responsible manner.

Fuel consumption and the wear of your engine, brakes and tires are largely dependent on operating conditions and your individual driving style. To reduce fuel consumption and wear, note the following:

- avoid short trips.
- always ensure that the tire pressure is correct.
- avoid frequent and abrupt acceleration.
- avoid carrying unnecessary ballast.
- remove ski attachments and roof racks if they are no longer being used.
- do not warm up the engine when the vehicle is stationary.
- shift gears such that each gear is used only up to ²/₃ of its maximum engine speed.
- monitor the fuel consumption.

A regularly serviced vehicle will also help protect the environment. Observe the maintenance intervals indicated by the ASSYST service interval display, as well as any other maintenance work that is described in this booklet.