

PERKINS

Diesel Engines Identification and Serial Numbers

Use the bookmarks for navigation



<http://engine.od.ua/Perkins>

**workshop
manual for
100 SERIES**

103-12/103-13/103-15/104-19/104-22

**FOR PERAMA M35
REFER TO 103-15 IDI**
(unless shown otherwise)

This publication is written for worldwide use. In territories where legal requirements govern engine smoke emission, noise, safety factors, etc., then all instructions, data and dimensions given must be applied in such a way that, after servicing (preventive maintenance) or repairing the engine, it does not contravene the local regulations when in use.

CONTENTS

	PAGE
ABBREVIATIONS and CODES	4
FOREWORD	5
SAFETY PRECAUTIONS	6
ENGINE PHOTOGRAPHS	7
SECTION I	
Description	1-1
SECTION II	
General Engine Data	2-1
SECTION III	
Dismantling Sequence	3-1
SECTION IV	
Disassembly, inspection, fits and clearances of component assemblies	4-1
Rocker Arm and Lever	4-1
Cylinder Head and Valves	4-2
Valve Guide and Seats	4-3
Piston	4-5
Piston Ring	4-6
Piston Rod	4-7
Oil Running Clearance	4-9
Main Bearing	4-9
Crankshaft	4-11
Crankshaft Rectification	4-11
Flywheel and Ring Gear	4-14
Camshaft	4-15
Timing Gear	4-15
Oil Pump	4-15
Oil Filter	4-16
Water Pump	4-16
Thermostat	4-16
Radiator	4-17
Fuel Filter	4-17
Fuel Lift Pump	4-18
Governor	4-19
Atomizers	4-20
Air Cleaner	4-21
SECTION V	
Reassembly	5-1
Timing	5-5
SECTION VI	
Electrical Systems	6-1
Alternator	6-1
Starter	6-8
Troubleshooting	6-8
Glow Plug	6-17
Thermoswitch	6-17
Oil Pressure Switch	6-17
Wiring Diagrams	6-18
SECTION VII	
Troubleshooting	7-1
SECTION VIII	
Service Standards	8-1
SECTION IX	
Recommended Torque Settings	9-1
SECTION X	
Perama Supplement	10-1
SECTION XI	
Conversion Formulas	11-1